

Column #88 August 2002 by Jon Williams:

# **Digital Data Recording**

My first job after military service was working for a large turf irrigation company. With a background in electronics, my focus was, of course, directed at irrigation controllers [sprinkler timers]. I got pretty good at fixing them and was quickly promoted to the testing group were I got to work with new designs. Working with new ones was much more fun that fixing the broken ones.

Keep in mind that a sprinkler controller is a real-time device designed to sequentially activate selected stations [outputs] at some predetermined time. In our lab, the standard piece of equipment used to verify this behavior was a paper strip chart recorder (this was 18 years ago). We'd program the controller to run a test sequence and start the strip-chart recorder, noting the time that the test was started. In the morning we would verify the controller activity by reading the strip-chart markings.

Why am dredging up what is – electronically – ancient history? Well, a recent posting on the BASIC Stamp mailing list caused me to remember my time in the test lab. A Stamp user was looking to build an event recorder using the BASIC Stamp. The post made me think about the good old days of paper strip-charts and the PC system we ultimately designed to replace them. I wondered what I could [simply] do with a stock BS2. As it turned out, the project is pretty neat.

## **Just Save The Changes**

A big problem with the old strip chart recorders is that they used paper to record activity and would happily spit out loads of paper – even if nothing was happening. If we equate paper to memory, this is really just a waste. A more efficient plan is simply to note the time when something changes.

And that's what we'll do here. Our project this month, is a simple event recorder that will monitor up to eight inputs and record changes in the state of these inputs to an external EEPROM. We'll use a real-time-clock for accurate timing and our design will scan the inputs every second.

### Inside the "Box"

I envisioned this project as something that would be used remotely – a smart "black box." This being the case, the interface to the user is provided via the PC through the Stamp programming port. The heart of the circuit (Figure 88.1) is simply the Stamp and a couple of 8-pin dip components (the EEPROM and RTC). The circuit and battery can be easily packaged in a very small plastic or metal box.

I will leave input conditioning up to you. For my test, I used a simple N.O. switch circuit as shown in Figure 88.2. If you want to monitor high-voltage devices or AC, the switch could be replaced by the contacts of a relay. Or, even better, you could use an optical isolator.

The hardware's pretty simple, isn't it? Well, the code really is too, albeit fairly long. As presented, the program uses up almost all of the Stamp's code space. Most of the program is fairly modular and we'll be taking advantage of some of the I2C code developed a couple of months ago – this time we'll put it to real use.

Before we get into the detailed explanation, let's review what the program should do:

- Read the number of records stored from the Stamp's EEPROM
- Read the start date (month, day, year) from the Stamp's EEPROM
- Draw the menu
- Wait for user input update time while waiting
- Respond to the user input





Figure 88.1: EEPROM and RTC with BS2

The Nuts and Volts of BASIC Stamps (Volume 3) • Page 199

Figure 88.2: Pushbutton Circuit



Response from the user can be:

- "T": Enter new time (hours, minutes, seconds)
- "D": Enter new start date (month, day, year)
- "R" : Start recording
- "V": View stored records
- "C" : Clear records

The last part of our planning is the storage of an event. As discussed earlier, we will only store changes that are detected. Here's how the bytes in an event record are structured:

- 0 : Day (offset from start date)
- 1 : Hour
- 2 : Minutes
- 3 : Seconds
- 4 : Inputs

Page 200 • The Nuts and Volts of BASIC Stamps (Volume 3)

Let me just explain byte 0 a bit further. Instead of storing the event date in a record (which would take four bytes), we simply store an offset (number of days) from the start date of recording. This trims three bytes from the record, allowing more records to be stored. It also means that we don't have to send the date to or retrieve it from the PCF8583; the start date is simply recorded in the Stamp's memory for future reference. Let's get on with the code.

In the variables section you'll notice a comment about not changing the order of a group of variables. In this program we will take advantage of the Stamp's implicit array structure of variable memory. A group of variables of the same size can be accessed as an array by using the first of the group as the array name and applying an index. Here's the group I'm referring to:

dayOfs hours minutes seconds scan

In the code, we can access to the same group using these names:

dayOfs(0) dayOfs(1) – same as hours dayOfs(2) – same as minutes dayOfs(3) – same as seconds dayOfs(4) – same as scan

As you've certainly deduced by now, we'll use a loop counter to iterate through these variables.

Let's move on to the EEPROM section; another place with something a little different. Storing data in the Stamp's EEPROM is easy and we do it quite frequently. I want to point out a little-used modifier of the DATA statement: Word. This let's use store a word-sized variable as easily as putting it into a variable. The compiler will store the variable as two bytes, using the "Little Endian" approach (low byte first). Keep in mind that this modifier only works with DATA and not with WRITE or READ. For WRITE and READ we still must deal with bytes.

The initialization section is straightforward, simply reading the number of records stored and the start date from the Stamp's EEPROM. A short PAUSE is inserted to allow the DEBUG window to open before we get draw the menu.




Figure 88.3: DEBUG Menu

Drawing the menu is easy and since we're using the DEBUG window, we'll take advantage of the cursor positioning command and, later, the ability to clear a line from the cursor position to the right. These commands only work with the DEBUG window, so if you decide to change the program to work with a standard terminal, you'll need to write your own positioning and "clean up" code.

After the menu is displayed, we grab the current time from the PCF8583 – so let's go there. Jump down the routine called Get\_Clock. This routine uses the low-level I2C code to access the seconds, minutes and hours data from the PCF8583. When retrieving consecutive bytes from the

Page 202 • The Nuts and Volts of BASIC Stamps (Volume 3)

PCF8583 (and other memory-type devices), we must first set the starting address with a write command. Once the address is set, we can perform sequential reads from that address. The PCF8583 will automatically increment its address pointer so we can do subsequent reads without having to send the next address.

Since the PCF8583 uses BCD for the time registers, we will convert to decimal with a bit of code that takes advantage of the HighNib and LowNib variable modifiers. This really isn't necessary for the program, but as most of us are more comfortable dealing with decimal numbers, it make sense to do it.

With the time in hand, we'll put it in the display along with the current start date and wait for the user to press a key. If no key is pressed within 900 milliseconds, the SERIN line times out and goes back to the Show\_Time\_Date code. What this does is create a "live" display, showing us the current time in the PCF8583.

When a key is pressed, it is decoded with a LOOKDOWN table. This will convert the response from a character to a value between zero and nine – if the key is valid. If the key isn't valid, the LOOKDOWN table will have no affect. Next we divide by two, giving us a possible [legal] value between zero and four that will be used by BRANCH for our menu routines. If the key was legal, BRANCH will work. If not, the BRANCH statement will fall through and the code will restart at Main.

The next section deals with code to handle each of the menu commands. The first two routines are identical, so we'll just discuss the first: Set\_Time.

When we want to enter a new time, the screen is cleared and we're asked to enter the hours. To keep things simple (for the Stamp), we'll use the 24 hour format. The DEC2 modifier is used with SERIN to limit the number of characters accepted. If the value entered is out of range, we clear the entry and try again. The same technique is used to get the minutes and seconds.

Once a valid time has been entered, it is sent to the PCF8583 with the Put\_Clock subroutine. This routine works very much like Get\_Clock; just going the other direction (data to PCF8583).

The heart of the program is, of course, recording data. When this option is selected, we'll clear the days offset counter then collect the current inputs and invert them. The reason for this is that we want to force the recording code to create an entry at the beginning. This way we have stored the starting time and initial state of the inputs.

Let me get away from code for a bit a tell you about the Interrupt\ output of the PCF8583. This output is used to indicate alarms from the device (by being pulled low). By default, it outputs a 1

The Nuts and Volts of BASIC Stamps (Volume 3) • Page 203

#### Column #88: Digital Data Recording

Hz square wave. This is perfect for us to trigger our new scan cycle. Each time this output goes low, we know it's a new second. Monitoring the Interrupt\ line is more efficient that continously reading the time and looking for a change.

The code will loop at Wait\_For\_Int until Stamp pin 2 is pulled low. When this happens, we grab the current time from the PCF8583. At first, this may not seem necessary if there was no new event. We have to do it though since we're keeping track of the days ourselves. So, if the current hours is zero (midnight) and the current seconds value is also zero, we've just hit a new day and we increment the daysOfs variable. If not, we simply skip ahead and look at the inputs.

Since inputs can be "noisy" the code at Check\_Inputs will debounce them. We've used this code before; it simply loops a few times and makes sure that an input doesn't change (bounce) during the loop. Any non-changing input is passed through the loop as a good input.

If there has been a change in the inputs, we'll save the change and record the event to our 24LC256 with the Put Record subroutine. Let's go there.

The Put\_Record subroutine updates the record count and checks to make sure we still have room in the 24LC256 for data. If not, the program stops, otherwise we'll save the current scan time and inputs. The current record number is stored in the Stamp's EEPROM so we can retrieve it after a power loss or reset. The next step is to setup for the Put\_Byte subroutine by selecting our device type and the address size.

The Put\_Byte routine is a general-purpose update from older code that lets us use it for either the 24LC256 or the PCF8583 (if we want to set something other than the time). The update includes passing the device as a variable and a flag for the number of bytes in the internal address. The device code is actually supposed to be the write code for the device, but the program masks out the lower bit (read bit), just in case of an error. After getting an ACK from the device (it's ready), we'll check the address size. For the 24LC256 we'll send two bytes (high byte first); for the PCF8583 we would only send one byte. After that, it's a simple matter of sending the data byte and generating a stop. This code, as well as Get\_Byte, are good copy-and-paste code chunks for programs that use I2C devices.

Back to Put\_Record. A loop is used to iterate through the bytes in our event record. Now we can fully understand the earlier discussion of keeping the event variables in specific order in our definition section. It's not enough that they're defined, they have to be defined consecutively so that this loop code will send the correct information to the 24LC256. The 24LC256 address for a given byte in the record is calculated and finally stored with Put Byte.

With the record stored, we'll display the change on screen and then check to the state of "interrupt" pin. As I told you earlier, what we'll see on the input of pin 2 is a 1 Hz square wave generated by the PCF8583. If the storage and display of our record takes less than 500 milliseconds (I measured it at about 290 milliseconds with a BS2), then pin 2 will still be low when we're done. What we don't want to do, then, is go back to Wait\_For\_Interrupt – because we'll just do things again unnecessarily. So, we'll just wait for this pin to go back high, then we'll jump to Wait For Interrupt.

To stop recording we'll reset the Stamp or cycle the power. Back to the menu, we should see the correct number of stored records indicated. Pressing "V" will display them on screen. The code at View\_Recs is responsible for the display. It uses a loop and Get\_Record to retrieve the data from the 24LC256.

Finally, we will want to clear our records for a new cycle. This is a simple matter of clearing the variable and writing zeros to the EEPROM locations that hold our record count. There's no need to actually erase the 24LC256 – this would simply be a waste of its available write cycles.

## **Improvements**

What you'll notice is that there isn't a whole lot of code space left for improvements – mostly because of all the DEBUG statements used to create our interactive display. We're going to solve that next time by using an external control program with Visual Basic. Until then, Happy Stamping!

```
· ______
   File..... EventRecord.BS2
   Purpose... Simple Event Recorder
  Author.... Jon Williams
   E-mail.... jwilliams@parallaxinc.com
   Started... 26 JUN 2002
  Updated... 28 JUN 2002
   {$STAMP BS2}
' Program Description
' This program scans the upper eight inputs for changes and, when detected,
' records the new inputs with the day [offset] and time to an {\tt EEPROM}
' Event Record Structure:
  0 : days offset from start date
  1 : hours
  2 : minutes
' 3 : seconds
' 4 : input scan
' Revision History
' I/O Definitions
             CON 0
                                           ' I2C serial data line
SDA
SCL CON 1
IntPin VAR In2
NewInputs VAR InH
TermIO CON 16
                                          ' I2C serial clock line
                                           ' interrupt input pin from RTC
                                           ' inputs on pins 8 - 15
                                           ' Terminal IO
' Constants
PCF8583 CON \$10100000 ' device code for RTC
```

Page 206 • The Nuts and Volts of BASIC Stamps (Volume 3)

EE24LC256	CON	%10100010	' device code for EEPROM
7.07/	COM	0	11 1 -4 1-1
ACK	CON	0	' acknowledge bit
NAK	CON	1	' no ack bit
RecSize	CON	5	' five bytes per event record
MemSize	CON	32768	'assuming 1 24LC256
			assuming 1 24LC236
MaxRecs	CON	MemSize / RecSize	
ByteSize	CON	0	' byte-sized address (RTC)
WordSize	CON	1	word-sized address (EEPROM)
			, , , , , , , , , , , , , , , , , , , ,
Yes	CON	0	
No	CON	1	
TermBaud	CON	84	' 9600-8-N-1 (matches DEBUG)
CrsrXY	CON	2	' DEBUG Position Control
ClrRt	CON	11	' clear line to right
CIINC	0014		crear rime to right
' Variables			
'			
device	VAR	Byte	' device to write/read
devAddr	VAR	Word	' address in device
addrSize	VAR	Bit	' (bytes in address) - 1
i2cReq			' register address
2		Byte	
i2cData	VAR	Byte	data to/from device
i2cWork	VAR	Byte	' work byte for TX routine
i2cAck	VAR	Bit	' ACK bit from device
records	VAR	Word	' events stored
recNum	VAR	Word	counter for view display
			± ±
oldInputs	VAR	Byte	' last event input data
' do not change	order o	f next five variables	
' program uses implicit array structure of user memory			
1 - 5 40			· <u>·</u>
days0fs	VAR	Byte	' offset from start date
hours	VAR	Byte	' time of event
mins	VAR	Byte	
secs	VAR	Byte	
		<del>-</del>	1
scan	VAR	Byte	' event data
month	VAR	recNum.LowByte	' start date
day	VAR	recNum.HighByte	
year	VAR	Word	
1 · · · =			
response	VAR	Word	' user response
idx	VAR	Nib	

```
' EEPROM Data
NumRecs DATA Word 0 'stored records
StartMonth DATA 6 'start date of recording
StartDay DATA 28
StartYear DATA Word 2002
' Initialization
Init:
 READ NumRecs, records.LowByte
                                                ' retrieve record count
 READ (NumREcs + 1), records.HighByte
                                               ' retrieve start date
  READ StartMonth, month
  READ StartDay, day
  READ StartYear, year.LowByte
  READ (StartYear + 1), year.HighByte
  PAUSE 250
                                                  ' let DEBUG window open
' Program Code
Main:
  DEBUG CLS
                                                  ' display menu
  DEBUG "=======", CR
  DEBUG " BASIC Stamp Event Recorder ", CR
  DEBUG "=======", CR
  DEBUG CrsrXY, 0, 6
  DEBUG "[T] Set Current Time", CR DEBUG "[D] Set Start Date", CR
  DEBUG "[R] Start Recording", CR
  DEBUG "[V] View (", DEC records, ") Records", CR
  DEBUG "[C] Clear Records", CR
  DEBUG CrsrXY, 0, 12, "--> ", ClrRt
                                                  ' show current time & date
Show_Time_Date:
 GOSUB Get Clock
DEBUG CrsrXY, 4, 4
```

Page 208 • The Nuts and Volts of BASIC Stamps (Volume 3)

```
GOSUB Display_Time
  DEBUG " "
  GOSUB Display Date
Get User Input:
                                                     ' wait for response
 DEBUG CrsrXY, 4, 12
SERIN TermIO, TermBaud, 900, Show_Time_Date, [response]
  LOOKDOWN response, ["tTdDrRvVcC"], response
  response = response / 2
  BRANCH response, [Set Time, Set Date, Go Record, View Recs, Clear Recs]
  GOTO Main
' Menu Routines
' --- Time ---
Set Time:
 DEBUG CLS, "Set Current Time"
Enter Hours:
 DEBUG CrsrXY, 0, 2, "Enter Hours (0..23)..... ", ClrRt
 SERIN TermIO, TermBaud, [DEC2 hours]
 IF (hours > 23) THEN Enter Hours
Enter Minutes:
  DEBUG CrsrXY, 0, 3, "Enter Minutes (0..59)...", ClrRt
  SERIN TermIO, TermBaud, [DEC2 mins]
  IF (mins > 59) THEN Enter Minutes
Enter Seconds:
 DEBUG CrsrXY, 0, 4, "Enter Seconds (0..59)...", ClrRt SERIN TermIO, TermBaud, [DEC2 secs]
  IF (secs > 59) THEN Enter Seconds
  GOSUB Put Clock
                                                     ' send new time to PCF8583
  GOTO Main
' --- Date ---
Set Date:
 DEBUG CLS, "Set Start Date"
Enter Month:
 DEBUG CrsrXY, 0, 2, "Enter Month (1..12)... ", ClrRt SERIN TermIO, TermBaud, [DEC2 month]
  IF (month < 1) OR (month > 12) THEN Enter Month
```

```
Enter Day:
 DEBUG CrsrXY, 0, 3, "Enter Day (1..31)..... ", ClrRt SERIN TermIO, TermBaud, [DEC2 day]
IF (day < 1) OR (day > 31) THEN Enter Day
Enter Year:
 DEBUG CrsrXY, 0, 4, "Enter Year (2002+)....", ClrRt
  SERIN TermIO, TermBaud, [DEC4 year]
 IF (year < 2002) THEN Enter Year
 WRITE StartMonth, month
                                               ' save start date in EEPROM
 WRITE StartDay, day
 WRITE StartYear, year.LowByte
 WRITE (StartYear + 1), year.HighByte
 GOTO Main
' --- Record ---
Go Record:
 DEBUG CLS, "Recording... ", CR, CR
 daysOfs = 0
                                               ' start today
 oldInputs = ~NewInputs
                                               ' force record on start
Wait For Int:
 IF (IntPin = No) THEN Wait For Int
                                               ' wait for new second
                                              ' get current time
 GOSUB Get Clock
 IF (hours <> 0) OR (secs <> 0) THEN Check Inputs
 daysOfs = daysOfs + 1
                                               ' increment day counter
                                            ' if > 255 stop
 IF (daysOfs = 0) THEN Stop_Recording
Check Inputs:
 scan = %11111111
  FOR idx = 1 TO 5
                                     ' debounce inputs
  scan = scan & NewInputs
   PAUSE 5
 IF (scan = oldInputs) THEN Wait For No Int ' if same, skip
 oldInputs = scan
                                               ' save current scan
                                               ' save record in 24LC256
 GOSUB Put Record
 DEBUG DEC3 daysOfs, " "
                                              ' display record
 GOSUB Display Time
DEBUG " -> ", BIN8 scan, CR
Wait For No Int:
 GOTO Wait For Int
```

Page 210 • The Nuts and Volts of BASIC Stamps (Volume 3)

```
' --- View ---
View Recs:
 IF (records = 0) THEN Main
                                            ' oops...
 DEBUG CLS
 DEBUG "Records", CR
                                             ' print header
 DEBUG "Start Date: "
 GOSUB Display Date
 DEBUG CR, CR
 DEBUG "Day Time Inputs ", CR DEBUG "--- -----, CR
                                           ' print records
 FOR recNum = 0 TO (records - 1)
  GOSUB Get Record
   DEBUG DEC3 daysOfs, " "
   GOSUB Display_Time
  DEBUG " ", BIN8 scan, CR
 SERIN TermIO, TermBaud, [response]
GOTO Main
' --- Clear ---
Clear Recs:
 records = 0
                                              ' clear variable
  WRITE NumRecs, 0
                                              ' clear EEPROM
 WRITE (NumRecs + 1), 0
 GOTO Main
' Subroutines
Display Time:
 DEBUG DEC2 hours, ":", DEC2 mins, ":", DEC2 secs
 RETURN
Display Date:
 DEBUG DEC2 month, "/", DEC2 day, "/", DEC4 year
Put Record:
                                           ' update record count
records = records + 1
```

```
IF (records > MaxRecs) THEN Stop Recording ' check limit
                                          ' store count in local EEPROM
 WRITE NumRecs, records.LowByte
 WRITE (NumRecs + 1), records.HighByte
 device = EE24LC256
                                          ' setup for Write Byte
 addrSize = WordSize
 FOR idx = 0 TO (RecSize - 1)
                                          ' byte to store
  i2cData = daysOfs(idx)
   devAddr = ((records - 1) * RecSize) + idx ' caculate address in EE
                                          ' write it
  GOSUB Write Byte
 NEXT
 RETURN
Get Record:
 device = EE24LC256
                                           ' setup for Read Byte
 addrSize = WordSize
 FOR idx = 0 TO (RecSize - 1)
  GOSUB Read Byte
                                          ' go get it
                                          ' place in user variable
  daysOfs(idx) = i2cData
 NEXT
 RETURN
Stop Recording:
 END
· ------
' High Level I2C Subroutines
' Byte to be written is passed in i2cData
' -- address passed in devAddr
Write Byte:
GOSUB I2C Start
                                          ' send Start
 i2cWork = (device & %11111110)
GOSUB I2C_TX_Byte
                                           ' send write command
 IF (i2cAck = NAK) THEN Write Byte
                                          ' wait until [ee] not busy
 IF (addrSize = ByteSize) THEN Wr Low Addr
 i2cWork = devAddr / 256
GOSUB I2C TX Byte
                                         ' send address high byte
Wr Low Addr:
 \frac{1}{12}cWork = devAddr // 256
                                         ' send address low byte
 GOSUB I2C TX Byte
                                    ' send data
i2cWork = i2cData
```

Page 212 • The Nuts and Volts of BASIC Stamps (Volume 3)

```
GOSUB I2C TX Byte
  GOSUB I2C Stop
  RETURN
' Byte read is returned in i2cData
' -- address passed in devAddr
Read Byte:
 GOSUB I2C Start
                                                 ' send Start
                                                 ' send write command
 i2cWork = (device & %11111110)
 GOSUB I2C_TX_Byte
 IF (i2cAck = NAK) THEN Read Byte
                                                 ' wait until [ee] not busy
 IF (addrSize = ByteSize) THEN Rd Low Addr
 i2cWork = devAddr / 256
                                                 ' send address high byte
 GOSUB I2C TX Byte
Rd Low Addr:
 i2cWork = devAddr // 256
                                                ' send address low byte
 GOSUB I2C TX Byte
 GOSUB I2C Start
 i2cWork = (device | 1)
                                                ' send read command
 GOSUB I2C TX Byte
 GOSUB I2C RX Byte Nak
 GOSUB I2C Stop
 i2cData = i2cWork
 RETURN
' Write seconds, minutes and hours .. sequntial mode
' -- variables are converted to BCD before sending to PCF8583
Put Clock:
 GOSUB I2C Start
 i2cWork = PCF8583
                                                 ' send device address
 GOSUB I2C TX Byte
 i2cWork = 2
                                                 ' start with seconds reg
 GOSUB I2C TX Byte
 i2cWork = ((secs / 10) << 4) | (secs // 10)
 GOSUB I2C TX Byte
 i2cWork = ((mins / 10) << 4) | (mins // 10) GOSUB I2C_TX_Byte
 i2cWork = ((hours / 10) << 4) | (hours // 10)
 GOSUB I2C TX Byte
  GOSUB I2C Stop
 RETURN
^{\mbox{\tiny I}} Read seconds, minutes and hours .. sequntial mode
' -- variables are converted from BCD storage format
```

## Column #88: Digital Data Recording

```
Get Clock:
  GOSUB I2C Start
  i2cWork = PCF8583
                                                    ' send device address
  GOSUB I2C TX Byte
  i2cWork = 2
                                                   ' send seconds reg #
  GOSUB I2C_TX_Byte
GOSUB I2C_Start
                                                   ' restart
  i2cWork = (PCF8583 | 1)
                                                   ' send read command
  GOSUB I2C TX Byte
  GOSUB I2C RX Byte
                                                    ' read back seconds
  secs = i2cWork.HighNib * 10 + i2cWork.LowNib
  GOSUB I2C_RX_Byte
  mins = i2cWork.HighNib * 10 + i2cWork.LowNib
  GOSUB I2C RX Byte Nak
                                                    ' final byte - send NAK
  hours = i2cWork.HighNib * 10 + i2cWork.LowNib
  GOSUB I2C Stop
  RETURN
' Low Level I2C Subroutines
' --- Start ---
I2C Start:
                                                   ' I2C start bit sequence
  INPUT SDA
  INPUT SCL
 LOW SDA
                                                   ' SDA -> low while SCL high
Clock Hold:
 IF (Ins.LowBit(SCL) = 0) THEN Clock Hold
                                                  ' device ready?
  RETURN
' --- Transmit ---
I2C TX Byte:
 SHIFTOUT SDA, SCL, MSBFIRST, [i2cWork\8] ' send byte to device SHIFTIN SDA, SCL, MSBPRE, [i2cAck\1] ' get acknowledge bit
  RETURN
' --- Receive ---
I2C RX Byte Nak:
 i2cAck = NAK
                                                   ' no ACK = high
 GOTO I2C RX
I2C RX Byte:
                                                ' ACK = low
i2cAck = ACK
```

Page 214 • The Nuts and Volts of BASIC Stamps (Volume 3)