

technical support





Toll-free sales 888-512-1024

Looking for a BASIC Stamp? Click here for a page, which contains comparisons for all of our featured BASIC Stamps. Meet your every Stamp need.

<u>Search</u>

TECHNICAL SUPPORT

- Home
- Knowledge Base
- Tip of the Week
- Parallax PDF Documents
- Discussion Groups
- E-mail Support
- Phone Support
- Authorized Consultants

BASIC Stamp Knowledge Base

- General Information
- Trouble-Shooting Information Coming Soon
- Functionality Information
- Programming Information
- Stamp Specifications Sheet

Contact UsSearchShopping CartReturn/Exchange PoliciesTerms of UsePrivacy PolicyShipping Information

© 2002, 2003 Parallax, Inc. all rights reserved.



Toll-free sales 888-512-1024

Looking for a BASIC Stamp? Click here for a page, which contains comparisons for all of our featured BASIC Stamps. Meet your every Stamp need.

Search

General Information

General Information

TECHNICAL SUPPORT

- Home
- Knowledge Base
- Tip of the Week
- Parallax PDF Documents
- Discussion Groups
- E-mail Support
- Phone Support
- Authorized Consultants
- What is the BASIC Stamp?
- Does the BASIC Stamp lose its program when I remove the battery or power supply?
- Does the BASIC Stamp come in different versions?
- What is the difference between the BASIC Stamp Rev. D (sometimes just called "BASIC Stamp") and the BASIC Stamp 1?
- How big is the BASIC Stamp?
- How big are the BASIC Stamp Carrier Boards?
- How do I power the BASIC Stamp?
- How much current does the BASIC Stamp consume?
- Is the BASIC Stamp sensitive to static electricity?
- Are there any production possibilities with the BASIC Stamp?
- What items do I need to get started with the BASIC Stamp?
- How can I make my own BASIC Stamp circuit?
- What kind of microchips are used in the BASIC Stamp?

What is the BASIC Stamp?


The BASIC Stamp is a microcontroller developed by Parallax, Inc. which is easily programmed using a form of the BASIC programming language. It is called a "Stamp" simply because it is close to the size of an average postage stamp, except for the BS2p40 which is much longer due to it's additional I/O pins.

Does the BASIC Stamp lose its program when I remove the battery or power supply?

No, your PBASIC code is stored inside a serial EEPROM on-board the BASIC Stamp. EEPROMs provide non-volatile storage; they retain memory even without power. The EEPROM used in the BASIC Stamp 1 and 2 is guaranteed to function properly for 40 years and for 10,000,000 write cycles per memory location. The EEPROM used in the BASIC Stamp 2e and 2sx, 2p is guaranteed for 1,000,000 write cycles per memory location.

Does the BASIC Stamp come in different versions?

Yes. Currently there are seven functional versions of the BASIC Stamp and ten physical versions. The BASIC Stamp line consists of the following: BASIC Stamp 1, BASIC Stamp 2, BASIC Stamp 2, BASIC Stamp 2sx, BASIC 2e, BASIC Stamp 2pe, BASIC Stamp 2p24, and the BASIC Stamp 2p40. The BASIC Stamp 1 is available in three package types (physical versions) as shown in figures 1a, 1b and 1c below. The BASIC Stamp 1 Rev. D is a through-hole, socketed package (with prototyping area). The BS1-IC is a 14pin SIP with surface-mounted components. The OEMBS1 is a 14-pin SIP in a larger board layout meant for OEM use (for recreating the entire BASIC Stamp 1 circuitry). It's important to note the three versions are functionally equivalent (with the exception of the lack of a Reset pin on the BASIC Stamp 1 Rev. D) but are just in physically different packages. The BASIC Stamp II, BASIC Stamp IIe, BASIC Stamp IIsx, BASIC Stamp IIpe and the BASIC Stamp IIp24 are available in a 24-pin DIP, and we also have the BASIC Stamp IIp40 with surface-mounted components (see Figures 2a, 3 and 4. They are called the BS2-IC, BS2E-IC, BS2SX-IC, BS2PE, BS2P24 and the BS2P40, respectively. The BS2-IC and BS2-SX, are also available in an OEM version (Figure 2b) that is a 20-pin SIP package.






Figure 1c -OEMBS1




Figure 2a – BS2-IC




Figure 3 – BS2E-IC




Figure 2b – OEMBS2




Figure 4 – BS2SX-IC

What is the difference between the BASIC Stamp Rev. D (sometimes just called "BASIC Stamp") and the BASIC Stamp I?

The original version of the BASIC Stamp I was simply called, "BASIC Stamp". That name was sufficient until the arrival of the new physical package type, as well as the second model in the Stamp line, the BASIC Stamp 2. At that point, the original version was split into two package types, the Rev. D and the BS1-IC; both of which are considered to be the "BASIC Stamp 1". The "BASIC Stamp 2" is known as the BS2-IC, the "BASIC Stamp 2e" is known as the BS2E-IC, and the "BASIC Stamp 2sx" is known as the BS2SX-IC. Today, the term "BASIC Stamp" is too generic and really could be applied to any one of the units in the product line. Long-time Parallax customers, however, still frequently refer to the BASIC Stamp 1 as the BASIC Stamp, thus, in many cases, there is no difference between the term BASIC Stamp and the BASIC Stamp 1. To keep things clear, we prefer the names: "BASIC Stamp 1", "BASIC Stamp 2", "BASIC Stamp 2e", and "BASIC Stamp 2sx", or more specifically, "Rev. D", "BS1-IC", "BS2-IC", "BS2E-IC", "BS2SX-IC", "BS2PE", BS2P24" and the "BS2P40-IC" and try to use the term "BASIC Stamp" to refer to the entire line of microcontrollers.

How big is the BASIC Stamp?

The BASIC Stamp rev. D measures 2.5" (65 mm) L x 1.52" (39 mm) W x 0.4" (10 mm) D. The BS1-IC measures 1.4" (35 mm) L x 0.58" (15 mm) W x 0.13" (3mm) D. The BS2-IC measures 1.2" (30 mm) L x 0.62" (16 mm) W x 0.35" (9mm) D. The BS2E-IC measures 1.2" (30 mm) L x 0.62" (16 mm) W x 0.35" (9 mm) D.

The BS2SX-IC measures 1.2" (30 mm) L x 0.62" (16 mm) W x 0.35"(9 mm) D. The BS2PE-IC measures 1.2" (30 mm) L x 0.62" (16 mm) W x 0.35"(9 mm) D. The BS2P24-IC measures 1.2" (30 mm) L x 0.62" (16 mm) W x 0.35"(9 mm) D. The BS2P40-IC measures 2.0" (51 mm) L x 0.62" (16 mm) W x 0.35"(9 mm) D.

How big are the BASIC Stamp Carrier Boards?

The BASIC Stamp 1 Carrier Board measures 2.5" (65 mm) L x 1.5" (38 mm) W x 0.5" (13 mm) D.

The BASIC Stamp 2 Carrier Board measures 2.8" (71 mm) L x 3.1" (79 mm) W x 0.6" (15 mm) D.

The Board of Education measures 4.25" (107 mm) L x 3.1" (77mm) W x 0.6" (15mm) D. The Super Carrier Board measures 4.25" (107mm) L x 3.1" (77mm) W x 0.6" (15mm) D. The Basic Stamp Activity Board measures 4.25" (107mm) L x 3" (76mm) W x 0.5" (18mm) D.

The BS2p 24 Demo Board measures 4.5" (114mm) L x 3.1" (77mm) W x 0.5" (18mm) D. The BS2p 40 Demo Board measures 6" (153mm) L x 3.1" (77mm) W x 0.5" (18mm) D. The Javelin Stamp Demo Board measures 4.25" (107mm) L X 3.25 (83mm) W x 0.6 (15mm) D.

How do I power the BASIC Stamp?

The Stamp runs on 5 to 15 volts DC. All Stamps feature an on-board 5-volt regulator which will convert an input 6 to 15 volts (on the VIN pin) down to the 5 volts that its components require. If your power supply is 6 to 15 volts, you should connect it directly to the VIN and GND pins or to the battery clips on the development board. The VIN and GND pins are pin number 1 and 2 on the BASIC Stamp rev. D or BS1-IC or pin 24 and 23 on the BS2-IC, BS2E-IC, BS2SX-IC, BS2p-IC, BS2pe, and Javelin-IC. If your power supply delivers a regulated 5 volts, you should connect it directly to the +5V and GND pins (14 and 2 on the BASIC Stamp rev. D, 5 and 2 on the BS1-IC, and 21 and 23 on the BS2-IC, BS2SX-IC, BS2P24, BS2PE, and JS1-IC (Javelin Stamp).

NOTE: When using battery or wall-pack power supplies, it is recommended to limit the voltage to 9 volts on the Stamp 1 and Stamp 2, and 7.5 volts on the Stamp 2e, Stamp 2sx, Stamp 2p, Stamp 2pe, and Javelin Stamp.

How much current does the BASIC Stamp consume?

The BASIC Stamp 1 consumes 2 mA in running mode and 20 μ A in sleep mode, not including any circuitry on the I/O pins. The BS2-IC consumes 8 mA in running mode and 100 μ A in sleep mode, not including any circuitry on the I/O pins. The BS2e-IC consumes 20 mA in running mode and 100 μ A in sleep mode, not including any circuitry on the I/O pins. The BS2SX-IC consumes 60 mA in running mode and 200 μ A in sleep mode, not including any circuitry on the I/O pins. The BS2p-IC consumes 40 mA in running mode and 400 μ A in sleep mode not including any circuitry on the I/O pins. The BS2pe-IC consumes 15 mA in running mode and 60 μ A in sleep mode, not including any circuitry on the I/O pins. The Javelin-IC consumes 60 mA in running mode and 13 μ A in sleep mode, not including any circuitry on the I/O pins.

Is the BASIC Stamp sensitive to static electricity?

While many electronic devices, including Stamps, can be damaged by static electricity, the Stamp is generally less sensitive to static. We do, however, recommend taking all of the usual precautions when handling all Stamps in static prone environments.

Are there any production possibilities with the BASIC Stamp?

Yes, we offer the major components of the Stamp circuit (the interpreter, the EEPROM and the resonator) separately at a discounted price for tight integration into your products. For initial development purposes, request the OEMBS1, OEMBS2, and OEMBS2sx product. These are "OEM" versions of the modules with an easy to follow circuit layout and all the components provided in through-hole format. The "OEM" versions provide a great "base" unit, which you can build yourself, to test the circuit and help in your own designs. Our web site includes information regarding details on pricing and availability.

What items do I need to get started with the BASIC Stamp?

The items you need are: 1) the BASIC Stamp Windows Editor programming software; 2) the programming cable (a DB-9 serial cable for all BASIC Stamp 2s and a parallel to three-pin cable for BASIC Stamp 1s; 3) the BASIC Stamp User's Manual; 4) the BASIC Stamp module itself, and optionally 5) the appropriate development board or kit.

For for details on these items see "Ken and Mike's Guide to Getting Started".

How can I make my own BASIC Stamp circuit?

Parallax sells the BASIC Stamp's interpreter chip in three different package type: DIP, SOIC and SSOP (if available). Any of these can be used to create your own BASIC Stamp circuit for purposes of deeply embedding it within an application. For initial development purposes, we sell OEM versions of the BS1, BS2, assemble and unassembled and the BS2SX assembled only. These are "OEM" versions of the modules with an easy to follow circuit layout and all the components provided in through-hole format. The "OEM" versions provide a great "base" unit, which you can build yourself, to test the circuit and help in your own designs.

What kind of microchips are used in the BASIC Stamp?

The BASIC Stamp 1 uses a PIC16C56 from Microchip Technology Inc. The BASIC Stamp 2 uses a PIC16C57 Microchip Technology Inc. The BASIC Stamps 2e, and 2sx use an SX28AC from Ubicom. The 2pe, 2p24, 2p40, and Javelin Stamp use the SX48BD.

Contact Us
Return/Exchange Policies

Search
Terms of Use
Shipping Information

Shopping Cart Privacy Policy

Home

© 2002, 2003 Parallax, Inc. all rights reserved.

Return to Top







Toll-free sales 888-512-1024

Looking for a BASIC Stamp? Click here for a page, which contains comparisons for all of our featured BASIC Stamps. Meet your every Stamp need.

Search

Functionality Information

Functionality Information

TECHNICAL SUPPORT

- Home
- Knowledge Base
- Tip of the Week
- Parallax PDF Documents
- Discussion Groups
- E-mail Support
- Phone Support
- Authorized Consultants
- What kind of operating environment does the BASIC Stamp require?
- What are the main differences between the BASIC Stamps?
- Is the BASIC Stamp II better than the BASIC Stamp 1?
- Is the BASIC Stamp IIsx better than the BASIC Stamp 2?
- How many I/O pins does the BASIC Stamp have?
- What can I use the I/O pins for?
- Can the I/O pins be used to control relays, solenoids and other similar devices?
- Can I control LEDs with the I/O pins?
- How much current can the I/O pins handle?
- What is the input impedance of the BASIC Stamp's I/O pins?
- How fast does the BASIC Stamp execute its PBASIC code?
- How fast does the Javelin Stamp execute its code?
- What is the VIN pin used for?
- How does the VDD pin work?
- How does the reset pin (RES) work?
- How does the ATN (Attention) pin work (BASIC Stamp 2, BASIC STAMP 2E and BASIC Stamp 2sx)?
- How much current can the BASIC Stamp's on-board regulator provide?
- Can the BASIC Stamp generate a sine wave?
- Can the BASIC Stamp generate a sine wave on two pins at once?
- Can the BASIC Stamp generate more than one sine wave on a pin at the same time?
- Can the BASIC Stamp generate square waves?
- Does the BASIC Stamp include a real time clock function?
- Does the BASIC Stamp have a built-in timer?
- Does the BASIC Stamp support interrupts?
- Does the BASIC Stamp 2, BASIC STAMP 2e or BASIC Stamp 2sx have the same bsave/bsload feature available in the BASIC Stamp 1?

What kind of operating environment does the BASIC Stamp require?

The BASIC Stamp modules will work in 0° to 70° C temperatures with up to 70%, non-condensing humidity. While the modules may continue to function outside these ranges, it is not guaranteed or recommended.

Parallax also sells the BASIC Stamp 1 and BASIC Stamp 2 in industrial (-40° to 85° C) and extended (-40° to 125° C) ranges. (At the time of this writing, this option is not available for the BS2E-IC or BS2SX-IC). Additionally, it is best to keep the BASIC Stamps away from, or shielded from, any nearby RF interference as this may impact the accuracy of its I/O functions.

What are the main differences between the BASIC Stamps

The BASIC Stamp 1 has 8 I/O pins, room for 80 to 100 lines of code, executes approximately 2000 instructions per second and requires a parallel interface for programming.

The BASIC Stamp 2 has 16 I/O pins, 2 dedicated serial port pins (1 input, 1 output), room for 500 to 600 lines of code, executes approximately 4000 instructions per second and requires a serial interface for programming.

The BASIC Stamp 2e has 16 I/O pins, 2 dedicated serial port pins (1 input, 1 output), room for 4000 lines of code, executes approximately 4000 instructions per second and requires a serial interface for programming.

The BASIC Stamp 2sx has 16 I/O pins, 2 dedicated serial port pins (1 input, 1 output), room for 4000 lines of code, executes approximately 10000 instructions per second and requires a serial interface for programming.

The BASIC Stamp 2p24 has 16 I/O pins, 2 dedicated serial port pins (1 input, 1 output), room for 4000 lines of code, executes approximately 12000 instructions per second and requires a serial interface for programming.

The BASIC Stamp 2pe has 16 I/O pins, 2 dedicated serial port pins (1 input, 1 output), room for 4000 lines of code, executes approximately 4000 instructions per second and requires a serial interface for programming.

Is the BASIC Stamp 2 better than the BASIC Stamp 1?

Yes and no, depending on your application. The BASIC Stamps from the BASIC Stamp 2 to the ASIC Stamp 2pe have twice the number of I/O pins with the exception of the BS2p40 which has 32 I/O pins, twice the execution speed, 5 times the memory (code) space, a serial port and 5 times the resolution on time sensitive commands. In many cases, these BASIC Stamps fit our customer's applications better than the BASIC Stamp 1. In some cases, however, this is not true. For example, you may have a need for only a couple of inputs and outputs with which you need to perform relatively simple, non speedcritical tasks. This is a perfect application for the BASIC Stamp 1; the BASIC Stamp 2 on up would be overkill if used in this way. A slightly different example would be if you have a variable pulse width signal you need to monitor. The BASIC Stamp 1 can detect and measure a pulse as little as 10 µS wide and as long as 0.65535 seconds wide. The BASIC Stamp 2 and above has 5 times the resolution, so it can measure a pulse as little as 2 µS wide, however, only as long as 0.13107 seconds wide of course with the faster Stamps the pulse width would vary you may want to refer to the BASIC Stamp Manual Version 2.0 off of our website, you will the information in the PULSIN command. While the better resolution may be helpful, the smaller maximum pulse width measuring capability may prove disadvantageous to your application.

The BASIC Stamp 2 series is the most popular BASIC Stamp and has the widest support base of free material on the web and from Parallax.

Is the BASIC Stamp 2sx better than the BASIC Stamp 2?

Yes and no, depending on your application. The BASIC Stamp IIsx executes instructions 2.5 times as fast, has 8 times the memory (code) space and 2.5 times the resolution on time sensitive commands. In some cases, the BASIC Stamp IIsx fits applications better than the BASIC Stamp II. For example, you may have a need for additional program

space that doesn't exist in the Stamp II. Another example would be if you have a variable pulse width signal you need to monitor. The BASIC Stamp II can detect and measure a pulse as little as $2 \mu S$ wide and as long as 0.13107 seconds wide. The BASIC Stamp IIsx has 2.5 times the resolution, so it can measure a pulse as little as $800 \mu S$ wide, however, only as long as 0.05243 seconds wide. While the better resolution may be helpful, the smaller maximum pulse width measuring capability may prove disadvantageous to your application. A full comparison of the Stamps can be found at the end of this document.

How many I/O pins does the BASIC Stamp have?

The BASIC Stamp 1 has 8 I/O pins while the BASIC Stamp 2, BASIC Stamp 2e, BASIC Stamp 2sx, BASIC Stamp 2pe, and the BASIC Stamp 2p24 have 16 I/O pins plus 2 special serial port pins (1 input, 1 output) the BASIC Stamp IIp40 has 32 I/Os.

What can I use the I/O pins for?

The BASIC Stamp's I/O pins are perfectly suited for digital input and output with TTL/CMOS level (0 to 5 volt) signals. However, you can use some special commands and techniques to input and output limited analog signals. For example, the RCTIME and PWM commands can be used to read a variable resistance or output a variable voltage from 0 to 5 volts. The I/O pins can not be used to read analog voltages by themselves, however, but this can be done by interfacing the I/O pins to an A to D converter chip.

Can the I/O pins be used to control relays, solenoids and other similar devices?

Yes, however, due to the demanding current and voltage requirements of some of these components, driver circuitry will need to be used to properly isolate the I/O pins from harmful effects. For examples of this, refer to BASIC Stamp I Application Note #6 and BASIC Stamp Article #6, "Silicon Steroids for Stamps".

Can I control LEDs with the I/O pins?

Yes. Simply use a 470 ohm resister in series with the LED to limit the current draw through the I/O pin (see "How much current can the I/O pins handle?"). Also, keep in mind that most LEDs require a lot of current in relation to what the BASIC Stamp can provide. If you attach and power 3 or more LEDs at one time from the BASIC Stamp's I/O pins, you are likely to see flaky and unpredictable results caused by voltage sag, I/O pin damage and/or hardware resets. Driver circuitry or low current LEDs will need to be used if you require such an application.

How much current can the I/O pins handle?

On the BASIC Stamp 1 and BASIC Stamp 2, each I/O pin is capable of sourcing 20 mA and sinking 25 mA. The total across all I/O pins should not exceed 40 mA source or 50 mA sink at any given time, however. One exception to this rule exists with the BS2-IC. If the BS2-IC is powered by an external 5-volt regulator capable of delivering at least 100 mA, the total across each group of 8 I/O pins (0 - 7 and 8 - 15) can reach 40 mA source or 50 mA sink providing a total of 80 mA source or 100 mA sink overall. On the BS2sx, Bs2e, BS2p, BS2pe, and Javelin, each I/O pins is capable of sourcing and sinking 40 mA, and the total across all I/O pins should not exceed 80 mA.

What is the input impedance of the BASIC Stamp's I/O pins?

Approximately 1 Meg Ohm.

How fast does the BASIC Stamp execute its PBASIC code?

On average, the BASIC Stamp 1 executes 2,000 instructions per second, the BASIC Stamp 2 executes 4,000 instructions per second, the BASIC Stamp 2e executes approx. 4,000 instructions per second, the BASIC Stamp 2sx executes 10,000 instructions per second, the BASIC Stamp 2p executes 12,000 instructions per second, and the BASIC Stamp 2pe executes 6,000 instructions per second. This is only an estimate as the true execution speed depends upon many factors including, the particular set of instructions used and the type of arguments provided to the instructions. Some instructions execute at a much faster rate while others, especially those that have to deal with external signal measurement or specific protocol speeds, will execute much slower.

How fast does the Javelin Stamp execute its code?

The Javelin executes on average approx. 8,500 instructions per second. This is only an estimate as the true execution speed depends upon many factors including, the particular set of instructions used and the type of arguments provided to the instructions. Some instructions execute at a much faster rate while others, especially those that have to deal with external signal measurement or specific protocol speeds, will execute much slower.

What is the VIN pin used for?

The Vin (Voltage Input) pin is used to power the Stamps from a 6 to 15 volt source. The Vin pin is the positive connection while the Vss pin is the negative, or ground, connection. When powered from the Vin pin the Stamp regulates the voltage down and outputs +5 volts on the Vdd pin. For optimal operation, it is recommended to keep the voltage below 12 volts for the BASIC Stamp 1 and 2, and around 7.5 volts for the BASIC Stamp 2sx, 2e, 2p, 2pe, and Javelin.

How does the VDD pin work?

The Vdd pin (+5V) outputs 5 volts when the Stamp is powered by a 6 to 15 volt source using the Vin and Vss (ground) pins. The Vdd pin can be used to power other circuitry if the overall current consumption is within the capabilities of the Stamp's regulator. The Vdd pin can also be used to power the Stamp from an external 5-volt regulator. In this case, the Vdd pin is the +5 volt connection and the Vss (ground) pin is the negative connection of the regulator (leave Vin disconnected).

How does the reset pin (RES) work?

The reset pin is internally controlled by the Stamp's brownout detector. It is normally high (+5V), which allows the Stamp to run its program normally, and is pulled low when the power supply voltage drops below 4.2 volts (safely putting the Stamp to sleep). This pin can be monitored to detect when a reset condition occurs, or, you can pull the line to ground to force a reset. After the reset pin is allowed to rise to +5 volts, the Stamp wakes up and starts executing its program from the first line of code. Do not drive this pin high; it

should be left electrically disconnected (floating) when you want the Stamp to run normally. This pin has an inverse relationship to the ATN (Attention) pin on the BASIC Stamp 2, BASIC STAMP 2e, BASIC Stamp 2sx, BASIC Stamp 2p, BASIC Stamp 2pe, and Javelin.

How does the ATN (Attention) pin work (BASIC Stamp II, BASIC STAMP IIe and BASIC Stamp IIsx)?

The ATN pin is used strictly for programming the BASIC Stamp and Javelin and should not be connected to anything other than the DTR pin of the programming connector and/or filtering capacitors. The ATN pin is an input and has an inverse relationship with the reset (RES) pin. >When the ATN pin is left unconnected, or is driven low, it causes the RES pin to go high (allowing the BASIC Stamp and Javelin). When the ATN pin is driven high it causes the RES pin to go low (performing a hardware reset on the BASIC Stamp or Javelin). The BASIC Stamp editor and Javlin IDE software toggles this pin from low to high and then low again at the start of the programming process to perform a hardware reset on the module and begin the bi-directional programming communication. It is important to be aware of a particular artifact of the DTR pin on a standard serial port: upon port selection by standard software (terminal packages, development tools, etc.), the DTR pin is driven high by default. If the same connections for programming the BASIC Stamp and Javelin are used to communicate with it via a serial port, the default state of the DTR pin will cause the BASIC Stamp to be held in permanent reset and its program will not execute. (This is the case on the Stamp II Carrier Board). This problem can be fixed in a number of ways: 1) disconnect the DTR to ATN pin connection when trying to communicate serially to the BASIC Stamp, or 2) explicitly set the DTR pin to low after selecting the port if the terminal package or development tool allows this, or 3) modify the programming connection to include a 0.1 uF capacitor in series with the DTR to ATN pin connection and a 0.1 uF capacitor from ATN to ground (VSS). The last two options will allow you to use the same connection for both programming and serial communications. (The Super Carrier Board, BASIC Stamp Activity Board Bs2p Demo boards, Javelin demo board, Stamp CI, and Board of Education use the last method).

How much current can the BASIC Stamp's on-board regulator provide?

The built in 5-volt regulator on the BASIC Stamp I and BASIC Stamp II can supply 50 mA of current if powered by a 12-volt source. The BASIC Stamp IIsx's regulator can supply 150 mA if powered by a 7.5-volt source. The BASIC Stamp I consumes 2 mA in running mode and the BASIC Stamp II consumes 7 mA. This leaves 48 mA and 43 mA respectively for use with other circuitry via the VDD pin and the I/O pins. The BASIC Stamp IIsx consumes 65 mA, leaving 85 mA for use with other circuitry via the VDD pin and the I/O pins.

Can the BASIC Stamp generate a sine wave?

Only the BASIC Stamp 2, BASIC Stamp 2e, BASIC Stamp 2p24, BASIC Stamp 2p40, BASIC Stamp 2pe, and BASIC Stamp 2sx can generate sine waves.

The BASIC Stamp 2, 2e, and 2ep uses the FREQOUT command to generate from 0 Hz to 32,767 Hz.

The BASIC Stamp 2sx uses the FREQOUT command to generate from 0 Hz to 81,917

Parallax: Tech; Functional Information

Hz.

The BASIC Stamp 2p24 and p40 uses the FREQOUT command to generate from 0 Hz to 123.531 Hz.

Note that the output from the FREQOUT command appears to be static when viewed on an oscilloscope. This is due to the nature of the underlying algorithm that generates the frequency, however, when averaged out over time, the result is a sine wave. You may achieve a cleaner signal by attaching the I/O pin to an appropriate RC filter circuit.

Can the BASIC Stamp generate a sine wave on two pins at once?

No. The BASIC Stamp is a single-task device and thus will execute only one FREQOUT command at a time.

Can the BASIC Stamp generate more than one sine wave on a pin at the same time?

Yes, the BASIC Stamp 2, 2e, 2e, 2sx, 2p24, and 2p40 FREQOUT command can generate two frequencies at the same time, on the same pin. This can be used to create harmonics, which greatly improve the sound output.

Can the BASIC Stamp generate square waves?

Yes, however, it is limited. The SOUND command in the BASIC Stamp 1 generates square waves which vary from 94.8 Hz to 10,550 Hz (non-linearly). The BASIC Stamp 2, 2e, 2sx, 2p24, 2p40, and 2pe however, does not include any functions to generate an accurately timed square wave. It can be done manually as long as fast timing is not an issue. This can be done with multiple lines of code that simply set a pin high or low and pause for the appropriate duration in-between transitions. The timing will vary somewhat depending upon your loop execution speeds.

Does the BASIC Stamp include a real time clock function?

No. If you need to keep track of time, especially dates and time, it is best to interface a real time clock to the BASIC Stamp. Many are available from various manufacturers. The real time clocks with a serial interface are usually the best choice, as they require fewer I/O pins from the BASIC Stamps to function properly. Parallax sells the DS1302 chip in the Component Shop to address this issue.

Does the BASIC Stamp have a built-in timer?

Yes, however, it is used for timing functions within the BASIC Stamps interpreter and there is no direct access to it through any PBASIC commands. Refer to BASIC Stamp 1 Application Note #20, "An Accurate Timebase" for one possible solution to timing problems.

Does the BASIC Stamp support interrupts?

No, the interpreter chip used in the BASIC Stamp does not support interrupts. In many cases, a fast polling routine may be used to accomplish the same effect, however, depending on the number and size of the tasks involved in some applications, this will not be fast enough and the BASIC Stamp may not be a plausible solution.

Does the BASIC Stamp 2, BASIC STAMP 2e, BASIC Stamp 2sx, BS2p24, BS2p40, and the BS2pe, have the same bsave/bsload feature available in the BASIC Stamp 1?

Yes and No, With the BS1 it uses the bsave/bsload feature. The BS2 on up, we have improved on the editor. On

Parallax: Tech; Functional Information

the latest editor version 1.33 you can find it under, File/Generate Object code you can generate files that are similar to the bsave/bsload but you will notice the improvements to the file.

Contact UsSearchShopping CartReturn/Exchange PoliciesTerms of UsePrivacy PolicyShipping Information

Home © 2002, 2003 Parallax, Inc. all rights reserved. Return to Top







Toll-free sales 888-512-1024

Looking for a BASIC Stamp? Click here for a page, which contains comparisons for all of our featured BASIC Stamps. Meet your every Stamp need.

Search

Programming Information

Programming Information

TECHNICAL SUPPORT

- Home
- Knowledge Base
- Tip of the Week
- Parallax PDF Documents
- Discussion Groups
- E-mail Support
- Phone Support
- Authorized Consultants
- How do I program the BASIC Stamp?
- How do I connect the BASIC Stamp to my computer for programming?
- How does my program get stored in the BASIC Stamp?
- How do I erase the BASIC Stamp's program space?
- How do I reprogram the BASIC Stamp?
- How big of a program can I store in the BASIC Stamp?
- Can I expand the program memory?
- Can I expand the data memory?
- How difficult is it to program the BASIC Stamp?
- How difficult is it to program the Javelin Stamp?
- Can I program the BASIC Stamp in Visual BASIC or QBASIC?
- What is PBASIC?
- Can I embed assembly language routines in my PBASIC code?
- How much space does each PBASIC command take?
- How do I know how much space my PBASIC program consumes?
- Why doesn't the Memory Map feature show me data I have already stored in the BASIC Stamp 2, 2e or 2sx's EEPROM?
- How do I debug my PBASIC programs?
- How do I print out my PBASIC programs?
- Can I read-out, or upload, the PBASIC program which is already stored in the BASIC Stamp?
- Since the BASIC Stamp 2, 2e and 2sx use the serial port for programming, can I use a simple terminal program to download my PBASIC code?
- Will a program and circuitry designed for the BASIC Stamp 1 work with the BASIC Stamp 2, 2e or 2sx?
- Can I program the BASIC Stamp 2, 2e or 2sx with the BASIC Stamp 1 editor (stamp.exe)?
- How do I make my PBASIC program start over or continue running forever?
- How do I set an I/O pin to input or output mode?
- How do I make an I/O pin output a high or a low?
- How do I input or output data in parallel on the I/O pins?
- Why do the BASIC Stamp's output pins toggle briefly when I use the SLEEP, NAP or END commands or allow my program to end naturally?
- The LET command is not available on the BASIC Stamp 2, 2e and 2sx. Does this mean the BASIC Stamp 2, 2e and 2sx cannot perform mathematical operations?

- Can the BASIC Stamp store data, such as temperature readings, for review or use at a later time?
- How can I store a word value into the internal EEPROM?
- How does the fpin (flow control pin) work in the SERIN and SEROUT commands on the BASIC Stamp 2, 2E and 2sx?
- How are arithmetic expressions evaluated within the BASIC Stamp?
- Does the BASIC Stamp handle signed numbers and arithmetic?
- How can I define an alias to an I/O pin or another variable?
- How do I reference a specific bit within a byte or word variable?
- How do I define a string variable?
- How do I define aliases to specific bytes within a word array on the BASIC Stamp 2,
 2e and 2sx?

How do I program the BASIC Stamp?

You can write your PBASIC program using the Basic Stamp 1, 2, 2e, 2sx, 2p, and 2pe editor on a standard IBM compatible PC. Currently there are Basic Stamp editors for DOS, Windows, and Macintosh. After you write the code for your application, you simply connect the BASIC Stamp to the computer's parallel port (Basic Stamp 1) or serial port (Basic Stamp 2, 2e, 2sx, 2p, and 2pe), provide power to the BASIC Stamp and press ALT-R (DOS version) or CTRL-R (Windows version) within the appropriate BASIC Stamp editor to download your program into the BASIC Stamp's EEPROM. As soon as the program has been downloaded successfully, it begins executing its new program from the first line of code.

How do I program the Javelin Stamp?

You can write your Javelin program using the Javelin IDE on a standard IBM compatible PC in Windows only. Windows 95 is the minimum OS that can be used to program the Javelin Stamps. After you write the code for your application, you simply connect the Javelin Stamp to the computer's serial port, provide power to the Javelin Stamp and press CTRL-R within the Javelin Stamp IDE to download your program into the Javelin Stamp's EEPROM. As soon as the program has been downloaded successfully, it begins executing its new program from the first line of code.

How do I connect the Stamp to my computer for programming?

The Basic Stamp 1 (rev. D or BS1-IC) requires a three-wire connection to any available parallel port on your PC. The Basic Stamp 2, 2e, 2sx, 2p, 2pe and Javelin require a standard, straight-through, serial cable connection to a 9-pin or 25-pin serial port on your PC. Only 6 wires are used for programming the Basic Stamp 2, 2e, 2sx, 2p, 2pe, and Javelin 4, of which are absolutely required (RX, TX, DTR, GND). You can not use a null-modem cable to program the Stamps. Refer to the schematics in our Stamp Manuals for the details of the cable connections.

How does my program get stored in the Stamp?

Your code is tokenized (compressed) and stored within the Stamp's EEPROM memory. This memory is non-volatile, meaning it retains its program even without power. Every

time the Stamp receives power, it starts running its code starting with the first executable line. This EEPROM can be rewritten immediately, without any lengthy erase cycle or procedure, by simply re-downloading the code from the Stamp editor again. Each location in the EEPROM is guaranteed for 10,000,000 write cycles before it wears out for the BS 1 and BS 2. The BS 2e, BS 2sx, BS 2p, and BS 2pe EEPROM is guaranteed for 100,000 write cycles before it wears out. The Javelin EEPROM is guaranteed for 1,000,000 write cycles before it wears out. Source code elements like comments and constant and variable names are not stored in the Stamp, thus you may feel free to use as many comments and descriptive symbol names in your code as you like without worrying about increasing your code size.

How do I erase the BASIC Stamp's program space?

An erase cycle is performed at the beginning of every programming process (in the Basic Stamp 1) or during the programming process (in the Basic Stamp 2, 2e, 2sx, 2p, and 2pe), thus, by downloading from the BASIC Stamp editor the necessary areas of the EEPROM are erased and then reprogrammed with the current PBASIC program in the editor. The Basic Stamp 2, 2e, 2sx, 2p, and 2pe only erase data in 16-byte increments. It is possible to completely erase the EEPROM by downloading the following line of code (in a program by itself):

DATA 0(2048)

How do I erase the Javelin Stamp's program space?

There is no single command for erasing the code from the Javelin's EEPROM. It is possible to write a simple program that can clear the EEPROM.

How do I reprogram the Stamp?

Simply re-connect it to the computer, run the BASIC Stamp editor and press ALT-R (DOS software) or CTRL-R (Windows software) using a code. For the Javelin, simply reconnect it to the computer, run the Javelin Stamp IDE and press CTRL-R using a code

How big of a program can I store in the BASIC Stamp?

The BASIC Stamp 1 has 256 bytes of program storage; enough for 80 to 100 lines of PBASIC1 code. The BASIC Stamp 2 has 2048 bytes of program storage; enough for 500 to 600 lines of PBASIC2 code. The Stamps 2e, 2sx, and 2p each have 16,384 bytes of program storage separated into 8 pages of 2048 bytes. Each page (or code section) can hold 500 to 600 lines of PBASIC code, respectively, for an overall total of approx. 4000 instructions. The BS2pe has 16384 bytes of program space and 16384 byte of dedicated data storage space, unused program space can be used for data storage as well. Each page (or code section) can hold 500 to 600 lines of PBASIC code, respectively, for an overall total of approx. 4000 instructions. The Javelin Stamp has 32768 bytes of program space which can be used for program variable storage.

Can I expand the program memory?

No, the program memory is not expandable as the interpreter chip expects the memory to be a specific, fixed size.

Can I expand the data memory?

Yes, you may interface external EEPROMs, or other memory devices to the Stamp's I/O pins to gain more data storage area. You will have to include the appropriate code within your program to interface to the particular device you choose.

How difficult is it to program the BASIC Stamp?

When compared to other programmable microcontrollers, the BASIC Stamps are perhaps the easiest to use because of their simple, but powerful, language structure and straightforward method of downloading and debugging. If you have some experience programming in BASIC, C or Pascal, you should find the learning process with the BASIC Stamp to be a simple one. If, however, you have never had any programming experience, you may have to spend some extra time studying the examples and application notes before you feel comfortable with the BASIC Stamp.

How difficult is it to program the Javelin Stamp?

This will depend on how well you know Java. If you are familiar with Java or "C" you will find the Javelin Stamp to be enjoyable to program. On the other hand, if you have never programmed in a structured language it could be a very difficult transition.

Can I program the BASIC Stamp in Visual BASIC or QBASIC?

No. The Stamp is a microcontroller, not a miniature PC. It does not have a graphical user interface, a hard drive or a lot of RAM. The Basic Stamp must only be programmed with PBASIC, and the Javelin Stamp with the Javelin's Java-like language, which has been specifically designed to exploit all of the stamp's capabilities.

What is PBASIC?

PBASIC (Parallax BASIC) is a hybrid form of the BASIC programming language in which many people are familiar. Currently there are three versions of PBASIC: PBASIC1 for the BASIC Stamp 1, PBASIC2 for the BASIC Stamp 2 and PBASIC2sx for the BASIC Stamp 2sx. Each version is specifically tailored to take advantage of the inherent features of the hardware it runs on. PBASIC is called a hybrid because, while it contains some simplified forms of standard BASIC commands, it also has special commands to efficiently control the I/O pins.

Can I embed assembly language routines in my PBASIC code?

No. The BASIC Stamp is a PBASIC interpreter only and cannot except assembly language routines.

How much space does each PBASIC command take?

Each command takes a variable amount of space within the BASIC Stamp's EEPROM. It varies due to complexities of the command itself and the types of arguments you supply each command. Generally, each command takes 2 to 4 bytes of memory space,

however, commands like SERIN, SEROUT, LOOKUP and LOOKDOWN, which accept a variable length list of arguments, may take tens of bytes or more.

How do I know how much space my PBASIC program consumes?

On the BASIC Stamp I, enter the following code at the start of your PBASIC1 program:

READ 255,B0 DEBUG #B0

Upon running the program, a number will display in the debug window of the editor. Use the following equation to determine how many bytes are used by your PBASIC1 code: 255 - # - 6; where # is the number displayed on the debug window. Note, the "- 6" in the equation results from the fact that the above two lines of code take 6 bytes of program space, thus without those two lines, your program takes 6 fewer bytes of space.

On the BASIC Stamp 2, 2e or 2sx, from within the editor and with your PBASIC program on the screen, press ALT-M (DOS software) or CTRL-M (Windows software) to view the memory map screens. In the DOS software, the first screen shows your RAM space, the second screen shows an expanded view of the program (EEPROM) space and the third screen shows a detailed view of the program space. Press the spacebar to alternate between the three screens. In the Windows software, all EEPROM and RAM is shown on one window.

Why doesn't the Memory Map feature show me data I have already stored in the BASIC Stamp 2, 2e or 2sx's EEPROM?

The memory map feature (ALT-M, DOS software or CTRL-M, Windows software) shows only what the memory space will look like immediately after you program the Stamp 2, 2e or 2sx. The editor determines this by examining your PBASIC source code within the editor, not the PBASIC code in the Stamp. It does not read the BASIC Stamp's EEPROM. It will only display data in the EEPROM that you've explicitly defined with DATA commands; no data which is operated upon by READ and WRITE commands can be shown since those are run-time, rather than compile-time, functions.

How do I debug my PBASIC programs?

You may use two features of the BASIC Stamp editor to debug your PBASIC program: 1) Syntax checking, and 2) the DEBUG command. Syntax checking alerts you to any syntactical errors and is automatically performed on your code the moment you try to download to the BASIC Stamp. Any syntax errors will cause the download process to abort and the editor will display an error message with a highlight cursor pointing to the source of the error in your code. Logical errors are sometimes more difficult to find but may be more easily discovered by using the DEBUG command. Debug operates similar to the PRINT command in the BASIC language and can be used to print the current status of specific variables within your PBASIC program as it is executed within the BASIC stamp. If your PBASIC code includes a DEBUG command, the editor opens up a special window at the end of the download process to display the results for you. In the Windows editor, the Debug window (called the Debug Terminal) can be left open, while you edit your code.

How do I print out my PBASIC programs?

The BASIC Stamp DOS editors do not have a print option built-in, however, the source file created by the editor is simply a DOS text file. This means it can be printed with the standard PRINT or TYPE commands as in:

```
PRINT source.bas

-or-

TYPE source.bas > LPT1
```

where source.bas is the name of your PBASIC program. The Windows software features built-in printing support.

Can I read-out, or upload, the PBASIC program which is already stored in the BASIC Stamp?

No. For security reasons, this feature was not made available. It is possible to read the tokenized form of the PBASIC code out of the BASIC Stamp's EEPROM, but there is no easy way to "reassemble" it into usable source code.

Since the BASIC Stamp 2, 2e and 2sx use the serial port for programming, can I use a simple terminal program to download my PBASIC code?

No. The download process requires a very fast, bi-directional communication between the BASIC Stamp and PC to program and verify the contents of the BASIC Stamp's memory.

Will a program and circuitry designed for the BASIC Stamp I work with the BASIC Stamp 2, 2e or 2sx?

Yes, however, some changes, usually in the PBASIC code only, will have to be made for it to run properly or to take advantage of some of the new features of the BASIC Stamp II, IIe or IIsx. For help in performing these modifications or for insight into how the PBASIC1 language differs from PBASIC2, review Appendix C in the BASIC Stamp Manual.

Can I program the BASIC Stamp 2, 2e or 2sx with the BASIC Stamp 1 editor stamp.exe)?

No. The BASIC Stamp 2, 2e and 2sx requires the BASIC Stamp 2, 2e and 2sx editor (stamp2.exe, stamp2e.exe or stamp2sx.exe in DOS, stampw.exe in Windows) due to the enhancements in the PBASIC2 language and the serial, rather than parallel, programming interface. Similarly, you cannot program the BASIC Stamp 1 with the BASIC Stamp 2, 2e or 2sx editors.

How do I make my PBASIC program start over or continue running forever?

All BASIC programs will simply end if one or more of their executable paths don't lead them to a continuous loop. In the simplest case, a program can be made to continue endlessly by adding a label (a unique name followed by a colon ':') to the start of code

and adding a GOTO statement at the end of code directing logical execution back to that label. Without this, the BASIC Stamp will run the program only once and then will remain unresponsive until the power is cycled or a reset condition is created.

How do I set an I/O pin to input or output mode?

There are many ways to set the I/O pin directions. The most readable and intuitive method is to use the INPUT and OUTPUT commands. For example:

```
INPUT 5
OUTPUT 6
```

will set I/O pin 5 to an input and I/O pin 6 to an output. By default, upon reset or startup, all I/O pins are inputs, thus only the second line of code above is really necessary.

Another method for setting the pin directions is to use the predefined variable DIRS or any one of its derivatives. The following code is functionally equivalent to the first example:

```
DIR5 = 0
DIR6 = 1
```

DIR0 through DIR15 (or DIR7 on the BASIC Stamp I) are bit variables which control the direction of the corresponding I/O pin. DIRS is a 16-bit variable (or 8-bit variable on the BASIC Stamp I) in which each bit represents the direction of the corresponding I/O pin. A '1' bit means output and a '0' bit means input. The advantage of this method of declaring pin directions is that multiple pin directions can be defined at once:

```
DIRS = %00101110
```

The above line of code defines I/O pins 7, 6, 4 and 0 as inputs and 5, 3, 2 and 1 as outputs. Review the BASIC Stamp manual for more examples of this.

How do I make an I/O pin output a high or a low?

As with setting I/O pin directions, there are many ways to set the I/O pin states. The most readable and intuitive method is to use the HIGH and LOW commands. For example:

```
HIGH 5
LOW 6
```

will first set I/O pin 5 to output mode and then set it to a high (+5V) state. The second line will first set I/O pin 6 to output mode and then set it to a low (0V) state. Notice that these commands automatically set the pin direction for you; it's not necessary to manually set the pins to output when using the HIGH and LOW commands. Keep in mind that if a pin is set to input, its logical state, high or low, remains the same internally within the BASIC Stamp but will no longer affect the voltage on the I/O pin.

Another method for setting the pin state is to use the predefined variable OUTS (or PINS in the BASIC Stamp I) or any one of its derivatives. The following code is functionally

equivalent to the first example:

```
DIR5 = 1
DIR6 = 1
OUT5 = 1
OUT6 = 0
```

Notice here that we had to explicitly define the I/O pins as outputs first. If we had left the pins as inputs, the OUT5 and OUT6 lines would have changed the state of the pins internally, but those changes would not appear externally from the BASIC Stamp. OUT0 through OUT15 (or PIN0 through PIN7 on the BASIC Stamp I) are bit variables which control the logical state of the corresponding I/O pin. OUTS is a 16-bit variable (PINS is an 8-bit variable on the BASIC Stamp I) in which each bit represents the state of the corresponding I/O pin. A '1' bit means high and a '0' bit means low. The advantage of this method of declaring pin states is that multiple pin states can be defined at once:

```
DIRS = %00101110
OUTS = %00001010
```

The above line of code defines I/O pins 7, 6, 4 and 0 as inputs and 5, 3, 2 and 1 as outputs. And sets I/O pins 7, 6, 5, 4, 2 and 0 to logical 0's and I/O pins 3 and 1 to logical 1's. Only pins 5, 3, 2 and 1 will output the voltage set in the OUTS variable because they are the only pins defined as outputs by the DIRS variable. Review the BASIC Stamp manual for more examples of this.

How do I input or output data in parallel on the I/O pins?

All BASIC Stamps have predefined variables that refer to the I/O pins. On the BASIC Stamp I, the PINS variable refers to all eight I/O pins. Thus code such as:

```
SYMBOL Snapshot = B0
Snapshot = PINS
```

would copy the current state of all I/O pins (an 8-bit byte) into the variable Snapshot. Similarly:

```
DIRS %11111111 'Set all eight pins as outputs PINS = 150
```

would set the eight output pins to the binary form of 150, or %10010110.

On the BASIC Stamp II, IIe and IIsx, the PINS variable was replaced with the INS and OUTS variables. Both INS and OUTS refer to all sixteen pins, while their derivatives, INL, INH, OUTL and OUTH refer to the low and high bytes (groups of 8 pins). For example, the following code will input 8-bits in parallel from the lower 8 pins:

```
Snapshot VAR BYTE Snapshot = INL
```

The following code will output 8-bits in parallel from the upper 8 pins:

Why do the BASIC Stamp's output pins toggle briefly when I use the SLEEP, NAP or END commands or allow my program to end naturally?

Inside the BASIC Stamp's interpreter chip is a watchdog timer whose main purpose is to reset the interpreter chip if, for some reason, it should stop functioning properly. The SLEEP and NAP commands also utilize the watchdog timer to periodically (every 2.3 seconds to be exact) "wake-up" the BASIC Stamp from its low-power mode. Upon reset, the I/O pins are set to inputs for approximately 18 mS before returning to their previous directions and states. If you have an output pin set to a logical 1 state (+5V) and you use the SLEEP command, every 2.3 seconds during sleep mode that I/O pin will switch to an input for 18 mS causing a momentary signal loss. This "power glitch" is easily viewable with an LED and a 470 ohm resister tied to an I/O pin and switched on just before entering sleep mode. In many cases this problem can be remedied by tying a pull-up or pull-down resistor to the I/O pin in question to provide a constant source of power should the I/O pin change directions. Allowing a PBASIC program to end naturally, or using the END command, will exhibit the same "power glitch" behavior because the interpreter chip enters a low-power state. The BASIC Stamp 2, 2e, 2sx, 2p24, 2p40, and the 2pe includes the STOP command which acts just like END, except output pins remain driven.

The LET command is not available on the BASIC Stamp 2, 2e and 2sx, 2p24 and 2p40. Does this mean these BASIC Stamps cannot perform mathematical operations?

No. The LET command on the BASIC Stamp 1 was optional; i.e.: you could leave it out of the variable assignment statement or equation and it would work normally. To save some space in the interpreter code of the BASIC Stamp 2, 2e, 2sx, 2p24, 2p40, and the 2pe the LET command was removed completely, however, the mathematical ability was not removed and, in fact, it is greatly improved on the BASIC Stamp 2, 2e, 2sx, 2p24, 2p40, and the 2pe.

Can the BASIC Stamp store data, such as temperature readings, for review or use at a later time?

Yes. The READ and WRITE commands allow the BASIC Stamp to manipulate memory locations in its EEPROM. Any space in the built-in EEPROM that is not occupied by PBASIC code may be used for data storage and is just as non-volatile as the PBASIC code itself. You may also attach external EEPROMs of various sizes to gain an even greater data storage area. The READ and WRITE commands will not function on external EEPROMs so you must write the appropriate code to interface with the device.

How can I store a word value into the internal EEPROM?

The internal EEPROM of the BASIC Stamp (used for both program and data storage) is organized and accessed in units of bytes only. Since a word value is actually two bytes it requires two consecutive memory locations to store it in EEPROM. You must break the word value into its lower and upper byte parts and use two WRITE commands to store the value, or two READ commands to retrieve it.

The following code demonstrates this for the BASIC Stamp 1:

```
W0 = 1250
WRITE 0, B0
WRITE 1, B1
```

The following code demonstrates this for the BASIC Stamp 2, 2e, 2sx, 2p24, 2p40, and the 2pe:

```
Temp VAR WORD
Temp = 1250
WRITE 0, Temp.LOWBYTE
WRITE 1, Temp.HIGHBYTE
```

How does the fpin (flow control pin) work in the SERIN and SEROUT commands on the 2, 2e, 2sx, 2p24, 2p40, and the 2pe?

The optional fpin argument in the SERIN and SEROUT commands allows the use of an I/O pin as a hardware flow control line between two BASIC Stamp II, IIe and IIsx's at baud rates of up to 19.2 kBps. The flow control pin is always controlled by the receiving device (SERIN) and monitored by the sending device (SEROUT). The logical state of this pin and its meaning depend on the data mode, true or inverted, as specified within the baudmode parameter. If true data mode is selected, the receiving BASIC Stamp 2, 2e, 2sx, 2p24, 2p40, and the 2pe holds the fpin low to indicate it is ready to receive or high to indicate it is not ready to receive. If inverted data mode is selected, the receiving BASIC Stamp 2, 2e, 2sx, 2p24, 2p40, and the 2pe holds the fpin high to indicate it is ready to receive or low to indicate it is not ready to receive.

Assuming true data mode: the fpin is set to output high the moment the SERIN command is first encountered and remains high until the SERIN command is complete at which point the fpin is set to low and remains there until the SERIN command is executed again. The transmitting BASIC Stamp II, IIe or IIsx's SEROUT command monitors this line and halts transmission whenever a low on the fpin is detected.

How are arithmetic expressions evaluated within the BASIC Stamp?

All expressions are evaluated using 16-bit, integer arithmetic. Even if byte and bit variables are used in expressions they are first expanded to 16-bits and then the expression is evaluated.

In the BASIC Stamp 1, mathematical expressions are evaluated strictly from left to right. No order-of-precedence is utilized, parentheses are not allowed and expressions must be on a line by themselves; i.e.: they can not be used as an argument for a command. For example, the expression: W0 = 10 - 2 * 3 results in the value 24 being stored into W0 (not the value 4 as you might think). To evaluate this expression properly, specify it as: W0 = 0 - 2 * 3 + 10.

In the BASIC Stamp 2, 2e, 2sx, 2p, and 2pe, mathematical expressions are evaluated from left to right, as in the BASIC Stamp 1. No order-of-precedence is utilized, however, unlike the BASIC Stamp 1, parentheses are allowed and expressions may be used as arguments within commands. For example, the expression: Answer = 10 - 2 * 3 results in

the value 24 being stored into Answer, however: Answer = 10 - (2 * 3) results in the value 4.

Does the BASIC Stamp handle signed numbers and arithmetic?

Yes. The BASIC Stamp uses twos-compliment notation for signed numbers. This means that the expression: 0 - 10 + 5 will result in -5 if viewed as a signed number, however, most instructions see the number as a positive value, in this case 65531 (the twos-compliment value for -5). All mathematical operators, except division, will work properly with signed numbers in the BASIC Stamp and signed numbers can be formatted for output properly using the SDEC, SHEX and SBIN formatters within DEBUG and SEROUT statements on the BASIC Stamp 2, 2e, 2sx, 2p, and 2pe. Be careful how you use signed numbers elsewhere. For example, if the value -5 is stored in a variable called Temp, and you use the following statement:

```
IF Temp < 0 THEN Loop
```

it will evaluate to false and will not branch to Loop because -5 is actually 65531 in twoscompliment form and thus 65531 is not less than 0.

How can I define an alias to an I/O pin or another variable?

In the BASIC Stamp 1 you could specify the following:

```
SYMBOL Counter = B0
SYMBOL Index = B0
SYMBOL LED = PIN0
```

To designate the symbol Index as an alias to the Counter variable and the symbol LED as an alias to I/O pin 0. Since Counter and Index use the same register, B0, anytime Counter is changed, Index will change in the same way. The symbol LED will always contain either a 1 or a 0 depending on the logical state of I/O pin 0.

In the BASIC Stamp 2, 2e or 2sx you could specify the following:

```
Counter VAR BYTE
Index VAR Counter
LED VAR IN0
```

to designate the symbol Index as an alias to the Counter variable and the symbol LED as an alias to I/O pin 0. Since Index uses the same memory space as Counter, anytime Counter is changed, Index will change in the same way. The symbol LED will always contain either a 1 or a 0 depending on the logical state of I/O pin 0.

How do I reference a specific bit within a byte or word variable?

On the BASIC Stamp I there is only one general purpose word register, W0, and two general purpose byte registers, B0 and B1, which are bit addressable. The predefined symbols Bit0 through Bit15 refer to the corresponding bits within W0 as well as B0 and B1 since those two byte variables correspond to the lower and upper bytes of W0

respectively. Thus Bit0 is the lowest bit of both W0 and B0 while Bit8 is the lowest bit of B1 (and the 9th bit of W0).

On the BASIC Stamp 2, 2e, 2sx, 2p, and 2pe all the variables are bit addressable, as well as nibble addressable. You can reference a specific part of a variable by specifying the variable name followed by a dot '.' and then the name of the portion you're interested in. For example, bit 2 of a word variable called Temp can be referenced with the notation: Temp.BIT2. Additionally, the second nibble of Temp can be referenced with: Temp.NIB1. The valid modifiers are: BIT0 through BIT15, LOWBIT, HIGHBIT, and NIB0 through NIB3, LOWNIB, HIGHNIB, and BYTE0 through BYTE3, LOWBYTE and HIGHBYTE.

How do I define a string variable?

A string variable is simply an array of bytes. Only the BASIC Stamp 2, 2e, 2sx, 2p, and 2pe allows the explicit definition of arrays. If, for example, you want to define a string variable called Text to hold 6 characters, use the following code:

Text VAR BYTE(6)

The elements of an array can be accessed by specifying the array name followed by an open parenthesis, an index value and a close parenthesis. The first element is always index 0. For example, the second element, or character in this case, can be referenced with: Text (1) and the last element with: Text (5). Byte arrays are useful for receiving a string of characters via the SERIN command using the STR modifier. The BASIC Stamp 2, 2e, 2sx, 2p, and 2pe allows you to define arrays of bits, nibbles and words as well.

How do I define aliases to specific bytes within a word array on the BASIC Stamp II, Ile and Ilsx?

The BASIC Stamp II, Ile and Ilsx uses a very relaxed and flexible indexing scheme when it comes to arrays of RAM space. When trying to define aliases in this way it is best to view the entire RAM space as one array of word, byte, nibble and bit registers. The BASIC Stamp II, Ile and Ilsx organizes variables in the RAM space from largest entities (word declarations) to smallest entities (bit declarations), regardless of the order you define them, to be most efficient. The relaxed nature of indexing allows a user to cross array boundaries at will, or by accident, quite easily. For example, the following code defines two distinct byte variables:

Result VAR BYTE Temp VAR BYTE

Normally you would reference the Result and Temp variables by name, as in: Result = 10. Even though this variable is not an array, you can still access it as such. The code: Result(0) = 10 is equivalent to the previous example. The most interesting, and powerful, feature is that you can index beyond the boundaries of this byte variable, as in Result(1) = 20. This statement actually modifies the byte of RAM immediately following the Result variable. The next byte happens to have been defined as Temp, in this case, thus the variable Temp will now equal 20. By carefully defining variables we can take advantage of this flexible feature to define byte sized aliases to specific locations within a word array. Suppose we have the need for an array of three words in which the first three bytes have a special meaning; we'd like to be able to easily manipulate those bytes as well as access

the three distinct word elements.

VAR WORD Array Speciall VAR Array.LOWBYTE Special 2 VAR Array.HIGHBYTE Special3 VAR BYTE TheRest VAR BYTE(3)

Remember: the BASIC Stamp II, Ile and Ilsx will always organize RAM space from biggest elements to smallest. In the example above we defined a single word variable called array this becomes assigned to the very first word in RAM space, word 0). The next two definitions create aliases to the first and second bytes of Array (no additional RAM space is allocated here since we're pointing at previously allocated space, byte 0 and byte 1). Next we define a single byte variable (this becomes assigned to the first byte of RAM immediately following the Array variable, byte 2). Finally, we define an array of three bytes (which are assigned to the next three bytes of RAM immediately following the previous byte declaration, byte 3, byte 4 and byte 5). Visually, our RAM space now appears like this:

Array (WORD 0) WORD 1 WORD 2

Now, Array(0), Array(1) and Array(2) refer to the three words of our array and Special1, Special2 and Special3 refer to the first three bytes within our three byte array.

BASIC Stamp Specifications (click to see chart)

Contact Us Search **Shopping Cart** Terms of Use Return/Exchange Policies **Privacy Policy**

Shipping Information

Return to Top Home © 2002, 2003 Parallax, Inc. all rights reserved.

Stamp Specifications (revised 09/02)

Released Products	Rev.D / BS1-IC	BS2-IC	BS2e-IC
Package	PCB w/Proto / 14-pin SIP	24-pin DIP	24-pin DIP
Package Size (L x W x H)	2.5" x 1.5" x .5" / 1.4" x .6" x .1"	1.2" x 0.6" x 0.4"	1.2" x 0.6" x 0.4"
Environment	0° - 70° C* (32° - 158° F) **	0° - 70° C* (32° - 158° F) **	0° - 70° C* (32° - 158° F) **
Microcontroller	Microchip PIC16C56c	Microchip PIC16C57c	Scenix SX28AC
Processor Speed	4 MHz	20 MHz	20 MHz
Program Execution Speed	~2,000 instructions/sec.	~4,000 instructions/sec.	~4,000 instructions/sec.
RAM Size	16 Bytes (2 I/O, 14 Variable)	32 Bytes (6 I/O, 26 Variable)	32 Bytes (6 I/O, 26 Variable)
Scratch Pad RAM	N/A	N/A	64 Bytes
EEPROM (Program) Size	256 Bytes, ~80 instructions	2K Bytes, ~500 instructions	8 x 2K Bytes, ~4,000 inst.
Number of I/O pins	8	16 + 2 Dedicated Serial	16 + 2 Dedicated Serial
Voltage Requirements	5 - 15 vdc	5 - 15 vdc	5 - 12 vdc
Current Draw @ 5V	2mA Run / 20μA Sleep	8 mA Run / 100 μA Sleep	20 mA Run / 100 μA Sleep
Source / Sink Current per I/O	20 mA / 25 mA	20 mA / 25 mA	30 mA / 30 mA
Source / Sink Current per unit	40 mA / 50 mA	40 mA / 50 mA per 8 I/O pins	60 mA / 60 mA per 8 I/O pins
PBASIC Commands	32	36	39
PC Programming Interface	Parallel Port	Serial Port (9600 baud)	Serial Port (9600 baud)
DOS Text Editor	STAMP.EXE	STAMP2.EXE	STAMP2E.EXE
Windows Text Editor	N/A	Stampw.exe (v1.04 and up)	Stampw.exe (v1.096 and up)

Released Products	BS2p24 -IC	BS2p40 -IC	BS2pe-IC
Package	24-pin DIP	40-pin DIP	24-pin DIP
Package Size (L x W x H)	1.2" x 0.6" x 0.4"	2.1" x 0.6" x 0.4"	1.2" x 0.6" x 0.4"
Environment	0° - 70° C* (32° - 158° F) **	0° - 70° C* (32° - 158° F) **	0° - 70° C* (32° - 158° F) **
Microcontroller	Scenix SX48AC	Scenix SX48AC	Ubicom SX48AC
Processor Speed	20 MHz Turbo	20 MHz Turbo	8 MHz Turbo
Program Execution Speed	~12,000 instructions/sec.	~12,000 instructions/sec.	~6000/sec.
RAM Size	38 Bytes (12 I/O, 26 Variable)	38 Bytes (12 I/O, 26 Variable)	38 Bytes (12 I/O, 26 Variable)
Scratch Pad RAM	128 Bytes	128 Bytes	128 Bytes
EEPROM (Program) Size	8 x 2K Bytes, ~4,000 inst.	8 x 2K Bytes, ~4,000 inst.	16 x 2K Bytes (16 K for source)
Number of I/O pins	16 + 2 Dedicated Serial	32 + 2 Dedicated Serial	16 + 2 Dedicated Serial
Voltage Requirements	5 - 12 vdc	5 - 12 vdc	5 - 12 vdc
Current Draw @ 5V	40 mA Run / 400 μA Sleep	40 mA Run / 400 μA Sleep	15mA Run / 60µA Sleep
Source / Sink Current per I/O	30 mA / 30 mA	30 mA / 30 mA	30 mA / 30 mA
Source / Sink Current per unit	60 mA / 60 mA per 8 I/O pins	60 mA / 60 mA per 8 I/O pins	60 mA / 60 mA per 8 I/O pins
PBASIC Commands	55	55	55
PC Programming Interface	Serial Port	Serial Port	Serial Port
DOS Text Editor	STAMP2P.EXE	STAMP2P.EXE	N/A
Windows Text Editor	Stampw.exe (v1.1 and up)	Stampw.exe (v1.1 and up)	Stampw.exe (v1.33 and up)

^{*} Industrial Models Available - Environment is -40° - 85° C (-40° - 185° F)**

** 70% Non-Condensing Humidity

BS2sx-IC
24-pin DIP
1.2" x 0.6" x 0.4"
0° - 70° C* (32° - 158° F) **
Scenix SX28AC
50 MHz
~10,000 instructions/sec.
32 Bytes (6 I/O, 26 Variable)
64 Bytes
8 x 2K Bytes, ~4,000 inst.
16 + 2 Dedicated Serial
5 - 12 vdc
60 mA Run / 200 μA Sleep
30 mA / 30 mA
60 mA / 60 mA per 8 I/O pins
39
Serial Port (9600 baud)
STAMP2SX.EXE
Stampw.exe (v1.091 and up)

Javelin Stamp
24-pin DIP
1.24" x 0.60" x 0.45"
0° - 70° C* (32° - 158° F) **
Ubicom SX48AC
25 MHz Turbo
~8,500 instructions/sec. ***
32768 Bytes
N/A
32768 Bytes
16
5 vdc (reg), 6-24 vdc (unreg)
60mA Run / 13µA Sleep
30 mA / 30 mA
60 mA / 60 mA per 8 I/O pins
0 (Java)
Serial Port
N/A
Javelin Stamp IDE