

Column #72, April 2001 by Jon Williams:

Searching The 1-Wire™ Bus

A few months ago, Parallax introduced their newest Stamp, the BS2p microcontroller. I'm happy to report that, after a bit of a rocky production start (getting raw parts was tough), it's in full production now and doing very well. I really love the BS2p – it is definitely my favorite Stamp of the bunch.

Of its many neat new features, the BS2p has native support for Dallas 1-WireTM components. Remember that 1-WireTM components are uniquely identified by an eight-byte serial number. The first byte indicates the device (called the Family Code), the next six bytes are the serial number and finally, the last byte is a CRC of the first seven. This unique serial number allows up to 150 devices to coexist on a single-wire bus that can be up to 100 meters long – and those numbers grow with proper cabling and drive circuitry.

Working with a single 1-WireTM device is easy since we can simply ignore its serial number (by using the SKIP ROM command). When two or more devices are on the bus, however, we need to know the serial number of each so that we can communicate with them individually. Issuing the SKIP ROM command on a bus with more than one device will cause data collisions and a big, garbled mess of data coming back to the Stamp.

Practicalities

When we're simply experimenting, individually reading the serial numbers from our 1-WireTM devices and embedding them into our project code is no big deal. It would be a problem, however, if our project turned into a real product and we were going to manufacture a hundred units a day. Manually recording individual serial numbers just isn't practical; there's got to be a better way. So what do we do when we have multiple devices on the 1-WireTM bus and we don't want to record the serial numbers manually?

Dallas Semiconductor knew this would be an issue in the design phase of the 1-WireTM bus and implemented a command that is common to all 1-WireTM parts that is called SEARCH ROM (\$F0). With SEARCH ROM and a bit of code, we can individually identify any number (up to the limits of our EE storage space) of 1-WireTM devices connected to the BS2p. The search algorithm code seems easy now, but trust me, it was a bear....

Get Ready For A KISS

For a really good description of the 1-WireTM search algorithm, please download the *iButton Standards* documentation from Dallas Semiconductor. It was in this document that I found a description and flowchart that actually helped me implement the 1-WireTM search algorithm. Here's my "*Keep It Simple, Stamp-Guy*" description of the process:

The 1-WireTM bus is reset and the SEARCH ROM command is issued. Two bits are read from the bus (this process actually takes place 64 times – once for each bit in the serial number). Each 1-WireTM device will return a bit, then its compliment. Since the design of the 1-WireTM bus causes the output of the devices to logically AND with each other, four possible combinations of bits will be returned to the Stamp:

- 00 bus conflict (some zeros retuned; some ones returned)
- 01 all devices have a zero in this bit position
- 10 all devices have a one in this bit position
- 11 there are no devices present

The second two combinations are the easiest to deal with. We simply note the bit in our temporary serial number variable, then write the bit back to the bus. This keeps the devices online (this will make more sense in a moment).

When 00 is returned, there has been a conflict, that is, some devices have a zero in this bit position and some have a one (ANDing them together will return zero). In the beginning, the algorithm will arbitrarily select zero as the "hot bit" and write it back to the bus. When this happens, any device that just returned a one bit will be disabled until a new search is initiated. The bit location of the collision is saved.

As the search continues, a new collision location is compared with the last. If the new location is in the same spot as the last (this would only happen on a new device search), one is selected as the "hot bit" and the process continues. If the new location is greater than the last, a zero is used (because we're probably in the same device as the last collision). If the new location is less than the previous, the last known bit value is used.

Yes, it can be a bit confusing and if anything like me, it may take a few days to sink in. The nice part is that it does work. As each device is identified and stored, it is taken offline. We know that we've found all the available devices when there are no reported bus collisions. If there are no devices connected to the bus, the pull-up will case 11 to be returned, indicating that there are no devices. You must be sure that your bus pin is pulled-up (through 4.7K). If it's not, 00 could be returned and the algorithm will attempt to search forever (I know this from having knocked a resistor loose in a late-night programming session).

Implementing The Search Algorithm

Have you ever been told not to believe anything unless you see it in writing? Me too. What I learned when it came to implementing the search algorithm for 1-Wire™ parts, is that not everything is writing is worth reading or helpful. Now, I'm not trying to knock Dallas Semiconductor. They're home-town guys, build cool parts and have been very nice to me. That said (or typed, as it were), I was a bit frazzled after staying up until 4 AM one morning trying to make the search algorithm work. I wasn't alone. A good friend and great BS2p programmer couldn't make it work either.

I felt just a bit better when I called one of Dallas' Applications Engineers later that morning (after a few hours of sorely needed sleep) and heard him refer to the 1-WireTM search algorithm as a nightmare. Really. It's not easy. The good news for you is that after finding a third document on the algorithm, I was able to implement it successfully. So, the hard work is done and as you'll see in just a bit, you can easily integrate the 1-WireTM search algorithm in your own BS2p programs. As I indicated earlier, the *iButton Standards* manual had the right combination of text and flowchart to make sense of the algorithm. After spending a long sleepless night, the right docs helped me get the code working in under an hour.




Figure 72.1: Searching the 1-wire bus debug screen

The Code In All Its Parts

Last month we talked about using extra program slots to hold additional code and data. This month we're going to put that theory to practical use with our project.

Remember me mentioning – okay, harping on -- program design; you know, knowing what your program is supposed to do before you actually write it? Well, here's what I wanted to do this month:

- Check to see if the 1-WireTM bus has been searched for devices
- If not, search the bus (and use an external program for portability)
- If a device is found and the CRC is good, write the serial number into the caller's EE space
- If there are any CRC errors, ignore the bad device and report errors to the calling program
- When the bus has been searched, display the number and type of devices found

I broke the project into three separate files since I wanted to reuse the search algorithm and I didn't want to burden my main project file with all the string data that describes the

devices. What we'll do here is take advantage of information passing between programs (using PUT and GET) as well as the new BS2p command, STORE, that allows one program to READ or WRITE the EEPROM from another.

The main project file (Program Listing 72.1) is called SRCHDEMO.BSP. At the top you'll see the \$STAMP directive that causes the support files, OWSEARCH.BSP and DSNAMES.BSP, to be opened, syntax-checked and downloaded to the BS2p.

Let's get back to the main program. After defining useful constants and the variables we need, EEPROM space is allocated for possible 1-WireTM devices. There is a location labeled Num_OW that is initialized to \$FF to indicate that the bus has not been searched. I'm hedging here that I will never need to have 255 devices on my 1-WireTM bus. When the search routine is complete, this location will be updated with the number of devices found. Keep in mind that the value of \$FF is written to this location only on download. If it is modified later, the program will run with the new information.

At the next location, 80 bytes are set aside for serial number storage. At eight bytes per device, this is enough room for ten devices. Of course, more could be allocated. As your program grows, be sure to use the Memory Map facility of the compiler to make sure you'll have EEPROM space for data that you want to store.

Okay, let's move on to initialization. The first thing we do is look at that location called Num_OW. The first time this program runs we will find a value of \$FF (put there during download). This indicates the necessity of a search. Before we run the search, we'll grab our own calling program (just in case we do an update and are not in slot 0). This information, the pin number for the 1-WireTM bus and the starting location for serial number storage are passed to the search program using PUT. The search program is launched with the RUN command.

The search program (OWSEARCH.BSP – Program Listing 72.2) initializes by grabbing its own slot number, the calling program's slot number, the 1-WireTM bus pin and the start of data storage in the caller. Then the search begins. When a device is located, the CRC is checked to make sure that what we got back was, in fact, valid data. The CRC algorithm is also described in the Dallas documentation and, as you can plainly see, is very easy to implement.

The CRC can be calculated manually, bit-by-bit, but it's much easier to use a table-drive algorithm when there is storage space available. We have plenty of space, so the CRC table is stored in this slot. If the CRC check is good (the process returns a zero when

good), the device count is incremented and the serial number is written in the caller's EEPROM space.

This is possible only in the BS2p with the new STORE command. Now you can see why we have to keep track of our own program slot as well as the caller's. When reading the CRC table, we have to use our own slot number; when writing serial numbers to the caller, we have to point to the caller first.

When the searching is complete, the number of devices found is written in the caller's EEPROM (just ahead of the serial number table) and any CRC errors are passed back through the scratchpad with PUT. Then we return to the caller which, in our case, will display a list of any found devices.

When the RUN command is issued, the slot is run. The difference is that any EEPROM changes made by code are maintained. So, the search demo code will have different values in its EEPROM than when we downloaded it. At the very least, the number of devices reported will be something other than \$FF.

The rest of the demo program is very simple: Errors are reported and then the found devices, if any, are displayed (serial numbers and device types). Since I didn't want to burden my main program with the device name strings, I used another module (DSNAMES.BSP – Program Listing 72.3) to hold them. When you look at this listing you'll see that it consists of one constant definition and a whole lot of EEPROM storage. The trick was to devise a way of finding the description string for a given device.

There's probably a dozen good ways to do it and here's what I decided to do: The string descriptions are stored first, with each string being identified with a useful label, in this case, the device part number. After the strings, pointers to their starting locations are stored. This is done mathematically – and automatically – thanks to the nature of the Stamp compiler.

The Stamp compiler converts DATA labels into numbers that can be used in math expressions. So, the formula for the storage address of the string pointers is:

(device id * 2) + base address

You'll notice that I use the Word directive to cause the Stamp to store two bytes at the calculated pointer location. This is necessary since the string definitions require far more than 255 bytes of EEPROM, hence, will require two bytes for addressing. So the pointer location stores the EEPROM location of the first character its respective string. Each

string is terminated with a zero so we can find its end. The base address was set to \$600 as this is the highest starting location we can use with a possible device number of \$FF. This allows string storage all the way up to \$599 (1536 bytes).

A description is displayed by sending the device number to the subroutine called DisplayDeviceType. This code uses the math previously described to calculate the pointer to the device string. Two reads are required to get the starting address of the string. Once we have the starting address, we read a character, display it and then increment the address until a zero is located. You'll probably recognize this technique as we've used it many times before. The difference here is the ability to use different program slots to store the strings. This is a great opportunity to create a multilingual application — with different languages being stored in different program slots. Change the slot number to read from and you can change the language of your displays.

Okay, that's enough for this month. Seemingly simple code, but lots of good stuff going on with it and a pretty good demonstration of the usefulness of the new STORE command. I suggest you spend some time studying what we've done here – there are a lot of good code bits. And you can see why I like the BS2p so much. With the ability to handle 1-WireTM and I2C devices easily combined with the reading and writing across EEPROM banks, it's a winner.

Does This Make Any Sense?

I was thinking the other day and it occurred to me that this column has been around for a few years now. First there was Scott, then me, then Lon – now back to me. Between the three of us, we've shared a lot of good tricks.

Don't worry, we're not going away, just considering what to do next to keep you interested and entertained. A friend recently suggested that spend a bit of time on inexpensive sensors and how to integrate them into Stamp projects. So that's what we'll do – for a while, anyway.

My buddies at the DPRG (Dallas Personal Robotics Group) gave me a nifty little light sensor (light to frequency) from TAOS: the TSL230. The great news is that it's easy to use and will work with any Stamp 2. But that's not the only part we'll be working with next month, so come back and join me.

As always, I wish you Happy Stamping.

```
' Program Listing 72.1
' Nuts & Volts - Stamp Applications, April 2001
' {$STAMP BS2p,OWSEARCH.BSP,DSNAMES.BSP}
' ----[ Title ]-----------------
' File..... SRCHDEMO.BSP
' Purpose... Demonstrates Dallas 1-Wire Search Algorithm
' Author.... Jon Williams
' E-mail.... jonwms@aol.com
' Started... 27 FEB 2001
' Updated... 05 MAR 2001
' ----[ Program Description ]-----
' The purpose of this program is to demonstrate the use of external
' program slots to hold code code or subroutines. When first downloaded
' to the BS2p, the number of Dallas 1-Wire devices is unknown (flag value
' of $FF). This program reads that flag and if it is $FF, the search
 program slot is called to conduct the search. Search results are
 written directly to the this program's EE (thanks to the BS2p STORE
' function).
' When the search is complete, a list of all found devices is displayed
' in a DEBUG window.
' ----[ Revision History ]------
' 28 FEB 2001 - Version 1 complete and tested
' ----[ I/O Definitions ]-------
OWpin
            CON 15
                                ' 1-Wire bus
' ----[ Constants ]-----
                 1
2
                                ' search program slot
SearchPgm
             CON
                             ' search program -.
' DalSemi OW device names
NamesPgm
             CON
' 1-Wire Support
OW FERst
            CON
                 %0001
                                 ' Front-End Reset
OW_FERST CON %0001
OW_BERST CON %0010
OW_BitMode CON %0100
                                 ' Back-End Reset
            CON %0010
OW HighSpd CON %1000
```

Page 408 • The Nuts and Volts of BASIC Stamps (Volume 2)

```
' read ID, serial num, CRC
' look for specific device
' skip ROM (one device)
ReadROM
               CON $33
                         $55
MatchROM
                CON
                         $CC
SkipROM
                CON
                                           ' search
SearchROM
                CON
                         $F0
thisSlot VAR Nib 'this program's slot (0 - 7)
devices VAR Byte '1-Wire devices found
addr VAR Word 'EE address of device SN
offset VAR Nib 'offset byte of device SN
idx VAR Byte 'loop counter
dByte VAR Byte 'data byte
devType VAR Byte 'device type (first byte of SN)
devName VAR Byte 'device identifier
strPtr VAR Word 'string pointer
char VAR Byte 'string character to print
crcErrors VAR Byte 'indicates problems with search
thisSlot
devices
                                   ' data from 1-Wire device
' CRC of returned data
tempROM VAR Byte(8) crcVal VAR Byte
Num OW DATA $FF
                                            ' number of 1-Wire devices
                                       ' number of 1-wife deciding ' space for 10 1-Wire SN's
OW_Data DATA 0(80)
 ' ----[ Initialization ]-------
Initialize:
  READ Num_OW,dByte ' ROM codes present?

IF (dByte < $FF) THEN Main ' yes, run this program
  DEBUG CLS
  PAUSE 5
  DEBUG "Searching for 1-Wire devices...", CR
  GET 127, thisSlot
                                            ' get this pgm slot #
                                            ' save it
  PUT 126, thisSlot
  PUT 125,OWpin
                                            ' save OW I/O
  PUT 124,0W Data
                                            ' save data storage start
  PUT 123,0
                                            ' clear CRC errors
  RUN SearchPqm
                                            ' run the search program
```

```
Main:
 GET 123, crcErrors
 IF (crcErrors = 0) THEN ShowDevices
  DEBUG "Warning: CRC errors during search.", CR
ShowDevices:
  READ Num OW, devices
                                    ' get number of devices
  DEBUG CR, DEC devices, " device"
  IF (devices = 1) THEN SkipEss
 DEBUG "s"
SkipEss:
  DEBUG " present.", CR
  IF devices = 0 THEN Done
  FOR idx = 1 TO devices
                                    ' display each one
   DEBUG CR, DEC2 idx," : "
   addr = 8 * (idx - 1) + OW Data ' calculate device address
   STORE thisSlot ' point to local EEPROM

FOR offset = 0 TO 7 ' eight bytes per device

READ (addr + offset),dByte ' read it from EEPROM
     DEBUG HEX2 dByte
                                    ' show it
    READ addr, devType
                                    ' get device type
   GOSUB DisplayDeviceType
                                   ' display it
  NEXT
Done:
 DEBUG CR
 END
' This subroutine is used to display the part number and description of
' a connected device. The text data and pointers to it are stored in the
' EE of a different program slot.
DisplayDeviceType:
 DEBUG " -> "
  addr = devType * 2 + $600
                                 ' calulate string pointer addr
                                    ' point to names EEPROM
  STORE NamesPgm
                                    ' get the string location
  READ addr, strPtr.LowByte
 READ addr+1, strPtr.HighByte
ReadAChar:
  READ strPtr, char
                                    ' read character from string
  IF (char = 0) THEN DevTypeDone
                                    ' at end? (0 = Yes)
                                    ' no, print the char
  DEBUG char
                                   ' point to next char
 strPtr = strPtr + 1
```

Page 410 • The Nuts and Volts of BASIC Stamps (Volume 2)

```
GOTO ReadAChar

DevTypeDone:
RETURN
```

```
' Program Listing 72.2
' Nuts & Volts - Stamp Applications, April 2001
' {$STAMP BS2p}
' ----[ Title ]-----
' File..... OWSEARCH.BSP
' Purpose... Searches 1-Wire bus for device ROM codes
' Author.... Jon Williams
' E-mail.... jonwms@aol.com
' Started... 26 FEB 2001
' Updated... 05 MAR 2001
' ----[ Program Description ]-----
' This program will search for all connected Dallas 1-Wire devices. The
' calling program passes its slot number, the 1-Wire buss pin and the
' start of EEPROM space for the storage of Dallas 1-Wire serail numbers.
' If a device is found, the 8-byte serial number is recorded in the
' EEPROM of the calling program slot. The search will continue until all
' devices have been found. The program will then jump back to the caller.
' REFERENCE: iButton Standards documentation, ROM Search Figure 5-3
           Dallas Semiconductor
           www.dalsemi.com
' 28 FEB 2001 - Tested and working per Dallas specification
' ----[ Constants ]------
' 1-Wire Support
OW FERst
           CON %0001
                                 ' Front-End Reset
          CON
OW BERst
                   %0010
                                 ' Back-End Reset
```

```
OW BitMode
              CON
                      %0100
OW_HighSpd
              CON
                      %1000
                                    ' read ID, serial num, CRC
ReadROM
              CON
                      $33
              CON
                      $55
                                   ' look for specific device
MatchROM
SkipROM
              CON
                      $CC
                                    ' skip ROM (one device)
                                    ' search
                     $F0
SearchROM
              CON
               CON
Yes
                      1
No
              CON
                      0
' ----[ Variables ]-----
                                    ' this program slot
thisSlot
              VAR
                      Nib
                    Nib
                                    ' calling program
caller
              VAR
             VAR Nib
VAR Byte
                                    ' BS2p pin for OW bus
ow_pin
                                    ' start of EE data
dStart
            VAR Byte
VAR Bit
                                ' previous collision local' done with this search?
' more devices on bus?
' result of bit read
' current bit position
' holds ROM search
                                   ' previous collision location
lastDisc
doneFlag
moreDevs
             VAR Bit
             VAR Nib
result
bitIndex
             VAR Byte
tempROM
             VAR Byte(8)
                                    ' collision in this search
discMarker
             VAR
                    Byte
devCount
              VAR
                   Byte
                                     ' devices found
addr
              VAR
                     Byte
                                     ' EE address to store
offset
              VAR
                     Byte
                                     ' loop counter
crcVal
              VAR
                      Byte
                                     ' CRC test value
crcErrors
              VAR
                                     ' Errors on search
                      Byte
' ----[ EEPROM Data ]-----
CRC table
DATA
       0,94,188,226,97,63,221,131,194,156,126,32,163,253,31,65
DATA
       157, 195, 33, 127, 252, 162, 64, 30, 95, 1, 227, 189, 62, 96, 130, 220
DATA 35,125,159,193,66,28,254,160,225,191,93,3,128,222,60,98
       190, 224, 2, 92, 223, 129, 99, 61, 124, 34, 192, 158, 29, 67, 161, 255
DATA
DATA 70,24,250,164,39,121,155,197,132,218,56,102,229,187,89,7
DATA 219,133,103,57,186,228,6,88,25,71,165,251,120,38,196,154
DATA
       101,59,217,135,4,90,184,230,167,249,27,69,198,152,122,36
DATA 248,166,68,26,153,199,37,123,58,100,134,216,91,5,231,185
DATA
       140,210,48,110,237,179,81,15,78,16,242,172,47,113,147,205
DATA
       17,79,173,243,112,46,204,146,211,141,111,49,178,236,14,80
DATA
       175,241,19,77,206,144,114,44,109,51,209,143,12,82,176,238
DATA
       50,108,142,208,83,13,239,177,240,174,76,18,145,207,45,115
DATA 202,148,118,40,171,245,23,73,8,86,180,234,105,55,213,139
```

Page 412 • The Nuts and Volts of BASIC Stamps (Volume 2)

```
DATA 87,9,235,181,54,104,138,212,149,203,41,119,244,170,72,22
      233,183,85,11,136,214,52,106,43,117,151,201,74,20,246,168
DATA
DATA 116,42,200,150,21,75,169,247,182,232,10,84,215,137,107,53
Initialize:
 GET 127,thisSlot
                                ' location of this code
 GET 126, caller
                                ' calling program
                                ' OW bus pin
 GET 125,ow_pin
 GET 124, dStart
                                ' start of data storage in caller
 crcErrors = 0
FirstSearch:
 lastDisc = 0
                                ' no previous search, no problems
 doneFlag = No
                                ' this search is not done
NextSearch:
 moreDevs = Yes
                                ' assume there are move devices
 IF (doneFlag = No) THEN ResetBus ' intialize for search
 doneFlag = No
 GOTO SearchDone
ResetBus:
 bitIndex = 1
                                ' initialize starting bit
 discMarker = 0
                                ' no bit collisions yet
 OWOUT ow pin,OW FERst,[SearchROM] ' reset and start search
ReadBit:
 OWIN ow pin, OW BitMode, [result.Bit1, result.Bit0]
 IF (result <> %11) THEN CheckGoodBit ' if %11, no devices
 GOTO ExitSearch
CheckGoodBit:
 IF (result > %00) THEN RecordBit ' if %00, we had a collision
 IF (bitIndex <> lastDisc) THEN Con_GT ' same as last, set bit to 1
 tempROM.LowBit(bitIndex-1) = 1
 GOTO SendBit
Con GT:
 IF (bitIndex < lastDisc) THEN Con LT ' new location, set bit to 0
 tempROM.LowBit(bitIndex-1) = 0
discMarker = bitIndex
                                ' mark the location
```

```
GOTO SendBit
Con LT:
 IF (tempROM.LowBit(bitIndex-1) = 1) THEN SkipMark
 discMarker = bitIndex ' mark if bit was 0
SkipMark:
 GOTO SendBit
RecordBit:
  ' write bus bit to our array
 tempROM.LowBit(bitIndex-1) = result.Bit1
SendBit:
  ' send bit back to bus to keep desired devices online
 OWOUT ow pin, OW BitMode, [tempROM.LowBit(bitIndex-1)]
 bitIndex = bitIndex + 1
                                 ' point to next bit
 IF (bitIndex < 65) THEN ReadBit ' done with this device?
 lastDisc = discMarker
                                 ' save collsion marker
 moreDevs = No
                                 ' assume we're done
 IF (lastDisc > 0) THEN SkipDone
 GOTO SearchDone
                                 ' record current device
SkipDone:
 moreDevs = Yes
                                 ' there are more devices
SearchDone:
 GOSUB CRCcheck
 addr = 8 * (devCount - 1) + dStart ' calculate starting address
 STORE caller
                                  ' point to caller EE
 FOR offset = 0 TO 7
  WRITE (addr + offset), tempROM(offset)
' write serial number to caller
 NEXT
DoNext:
 IF (moreDevs = Yes) THEN NextSearch ' if more, go get them
ExitSearch:
 PUT 123, crcErrors
                                  ' flag any search errors
                                  ' point to caller EE
 STORE caller
 WRITE (dStart - 1), devCount ' record # devices found
                                 ' return to calling program
 RUN caller
 END
```

Page 414 • The Nuts and Volts of BASIC Stamps (Volume 2)

```
' Program Listing 72.3
' Nuts & Volts - Stamp Applications, April 2001
' {$STAMP BS2p}
' ----[ Title ]-----
' File..... DSNAMES.BSP
' Purpose... Stores string names of DalSemi 1-Wire devices
' Author.... Jon Williams
' E-mail.... jonwms@aol.com
' Started... 01 MAR 2001
' Updated... 05 MAR 2001
' ----[ Program Description ]-----
' There is no actual code in this module. This program stores the names
' of various Dallas Semiconductor 1-Wire devices. The device family code
' is used to map the strings in EEPROM. The pointer to a device's string
' discription is stored at the location determined by this formula:
    pointer = device id * 2 + $600
' "pointer" is actually the low-byte of the address location. The high
' byte is at pointer+1.
' ----[ Constants ]------
PntrBase
                   CON $600
```

```
' ---- [ EEPROM Data ]-----
' Store strings first so labels can be used in address pointer table
               DATA "Unknown device", 0
Unknown
' shared family codes
               DATA
                       "DS1990 iButton or DS2401",0
FCode01
               DATA
FCode04
                       "DS1994 iButton or DS2404",0
              DATA "DS1920 iButton or DS18S20",
DATA "DS1971 iButton or DS2430",0
DATA "DS1973 iButton or DS2433",0
FCode10
                       "DS1920 iButton or DS18S20",0
FCode14
FCode23
' iButtons
DS1920
              DATA "DS1920 Temperature iButton",0
              DATA "DS1921 Thermochron iButton",0
DS1921
DS1963
              DATA "DS1963 4-kBit Monetary iButton",0
              DATA "DS1971 256-bit EEPROM iButton",0
DS1971
              DATA "DS1973 4-kBit EEPROM iButton",0
DS1973
DS1982
              DATA "DS1982 1-kBit Add-Only iButton", 0
DS1985
              DATA "DS1985 16-kBit Add-Only iButton",0
DS1986
              DATA "DS1986 64-kBit Add-Only iButton", 0
DS1990
              DATA "DS1990 Serial Number iButton",0
DS1991
              DATA "DS1991 MultiKey iButton",0
                       "DS1992 1-kBit Memory iButton",0
DS1992
              DATA
              DATA
DS1993
                       "DS1993 4-kBit Memory iButton",0
               DATA
DS1994
                       "DS1994 4-kBit Plus Time Memory iButton",0
               DATA "DS1995 16-kBit Memory iButton",0
DATA "DS1996 64-kBit Memory iButton",0
DS1995
DS1996
' 1-Wire chips
DS1822
               DATA
                       "DS1822 Econo-MicroLAN Digital Thermometer",0
DS18B20
               DATA
                       "DS18B20 Programmable Resolution Digital
Thermometer", 0
                       "DS18S20 High Precision Digital Thermometer",0
DS18S20
               DATA
DS2401
              DATA
                       "DS2401 Silicon Serial Number",0
                       "DS2404 EconoRAM Time Chip",0
DS2404
              DATA
DS2405
              DATA "DS2405 Addressable Switch",0
              DATA "DS2406 Addressable Switch Plus 1-kBit Memory",0
DS2406
              DATA "DS2417 Time Chip With Interrupt",0
DS2417
DS2430
              DATA "DS2430 256-bit EEPROM",0
              DATA "DS2433 4-kBit EEPROM",0
DS2433
              DATA "DS2450 Quad A/D Converter",0
DATA "DS2505 16-kBit Add-Only Memo:
DATA "DS2506 64-kBit Add-Only Memo:
DATA "DS2890 Digital Pot",0
DS2450
DS2505
                       "DS2505 16-kBit Add-Only Memory",0
                       "DS2506 64-kBit Add-Only Memory",0
DS2506
DS2890
```

Page 416 • The Nuts and Volts of BASIC Stamps (Volume 2)

' string po	inters		
Pointers	DATA	@\$01*2+PntrBase,Word	FCode01
	DATA	@\$04*2+PntrBase,Word	
	DATA	@\$10*2+PntrBase,Word	FCode10
	DATA	@\$14*2+PntrBase,Word	FCode14
	DATA	@\$23*2+PntrBase,Word	FCode23
	DATA	@\$02*2+PntrBase,Word	DS1991
	DATA	@\$06*2+PntrBase,Word	DS1993
	DATA	@\$08*2+PntrBase,Word	DS1992
	DATA	@\$09*2+PntrBase,Word	DS1982
	DATA	@\$0A*2+PntrBase,Word	DS1995
	DATA	@\$0C*2+PntrBase,Word	DS1996
	DATA	@\$1A*2+PntrBase,Word	DS1963
	DATA	@\$21*2+PntrBase,Word	DS1921
	DATA	@\$05*2+PntrBase,Word	DS2405
	DATA	@\$0B*2+PntrBase,Word	DS2505
	DATA	@\$0F*2+PntrBase,Word	DS2506
	DATA	@\$12*2+PntrBase,Word	DS2406
	DATA	@\$20*2+PntrBase,Word	DS2450
	DATA	@\$22*2+PntrBase,Word	DS1822
	DATA	@\$27*2+PntrBase,Word	DS2417
	DATA	@\$28*2+PntrBase,Word	DS18B20
	DATA	@\$2C*2+PntrBase,Word	DS2890