Name: Ahmet Coskuner


TA: Neha Gupta

ECEN 714 Lab 1

1. Full adder simout, symbol, and schematic


```
TOOL:
         ncxlmode
                       15.20-s086: Started on Sep 08, 2022 at 16:08:52 CDT
ncxlmode
    +delay mode path
    +typdelays
    simout.tmp
    /home/grads/a/acoskuner500/ecen714/fulladder run1/testfixture.template
    -f /home/grads/a/acoskuner500/ecen714/fulladder_run1/verilog.inpfiles /opt/coe/ncsu/ncsu-cdk-1.6.0.beta/lib/NCSU_Digital_Parts/nand2/functional/verilog.v
         /opt/coe/ncsu/ncsu-cdk-1.6.0.beta/lib/NCSU_Digital Parts/xor2/functional/verilog.v
         ihnl/cds0/netlist
    +nostdout
    +nocopyright
    +ncvlogargs+" -neverwarn -nostdout -nocopyright "
    +ncelabargs+" -neg_tchk -nonotifier -sdf_NOCheck_celltype -access +r -pulse_e 100
-pulse r 100 -neverwarn -timescale 1ns/1ns -nostdout -nocopyright"
   +ncsimargs+" -neverwarn -nocopyright -qui -input
/home/grads/a/acoskuner500/ecen714/fulladder run1/.simTmpNCCmd "
    +mpssession+virtuoso9914
    +mpshost+zach-127-24.engr.tamu.edu
Relinquished control to SimVision...
ncsim>
ncsim> source /opt/coe/cadence/INCISIVE152/tools/inca/files/ncsimrc
ncsim> database -open shmWave -shm -default -into shm.db
Created default SHM database shmWave
ncsim> probe -create -shm test -all
Created probe 1
ncsim> run
                        0 A=0, B=0, C=0, SUM=0, CARRY=0
                50 A=0, B=0, C=1, SUM=1, CARRY=0
                100 A=0, B=1, C=0, SUM=1, CARRY=0
150 A=0, B=1, C=1, SUM=0, CARRY=1
                200 A=1, B=0, C=0, SUM=1, CARRY=0
                250 A=1, B=0, C=1, SUM=0, CARRY=1
300 A=1, B=1, C=0, SUM=0, CARRY=1
                350 A=1, B=1, C=1, SUM=1, CARRY=1
ncsim>
```






2. 4-bit Adder simout, symbol, and schematic

```
TOOL:
          ncxlmode
                       15.20-s086: Started on Sep 08, 2022 at 17:12:44 CDT
ncxlmode
    +delay_mode_path
    +typdelays
    -1
    simout.tmp
    /home/grads/a/acoskuner500/ecen714/fouradder run1/testfixture.template
    -f /home/grads/a/acoskuner500/ecen714/fouradder_run1/verilog.inpfiles
         /opt/coe/ncsu/ncsu-cdk-1.6.0.beta/lib/NCSU_Digital_Parts/nand2/functional/verilog.v /opt/coe/ncsu/ncsu-cdk-1.6.0.beta/lib/NCSU_Digital_Parts/xor2/functional/verilog.v
         ihnl/cds0/netlist
         ihnl/cds1/netlist
    +nostdout
    +nocopyright
    +ncvlogargs+" -neverwarn -nostdout -nocopyright "
    + ncelabargs + "-neg\_tchk-nonotifier-sdf\_NOCheck\_celltype-access+r-pulse\_e-100
-pulse r 100 -neverwarn -timescale 1ns/lns -nostdout -nocopyright"
    +ncsimargs+" -neverwarn -nocopyright -gui -input
/home/grads/a/acoskuner500/ecen714/fouradder run1/.simTmpNCCmd "
    +mpssession+virtuoso9914
    +mpshost+zach-127-24.engr.tamu.edu
Relinquished control to SimVision...
ncsim> source /opt/coe/cadence/INCISIVE152/tools/inca/files/ncsimrc
ncsim> database -open shmWave -shm -default -into shm.db
Created default SHM database shmWave
ncsim> probe -create -shm test -all
                                           -depth 1
Created probe 1
ncsim> run
                        0 A=0000, B=0000, CIN=0, SUM=0000, COUT=0
                50 A=1111, B=1111, CIN=0, SUM=1110, COUT=1
                100 A=1010, B=1010, CIN=1, SUM=0101, COUT=1
150 A=0101, B=0101, CIN=1, SUM=1011, COUT=0
ncsim>
```





3. 8-bit adder simout, symbol, and schematic

```
TOOL:
          ncxlmode
                       15.20-s086: Started on Sep 08, 2022 at 19:45:29 CDT
ncxlmode
    +delay mode path
    +typdelays
    -1
    simout.tmp
    /home/grads/a/acoskuner500/ecen714/eightadder run1/testfixture.template
    -f /home/grads/a/acoskuner500/ecen714/eightadder run1/verilog.inpfiles
         /opt/coe/ncsu/ncsu-cdk-1.6.0.beta/lib/NCSU_Digital_Parts/inv/functional/verilog.v /opt/coe/ncsu/ncsu-cdk-1.6.0.beta/lib/NCSU_Digital_Parts/nand2/functional/verilog.v
         /opt/coe/ncsu/ncsu-cdk-1.6.0.beta/lib/NCSU_Digital_Parts/xor2/functional/verilog.v
         /opt/coe/ncsu/ncsu-cdk-1.6.0.beta/lib/NCSU_Digital_Parts/Dlatch/behavioral/verilog.v
         ihnl/cds0/netlist
         ihnl/cds1/netlist
         ihnl/cds2/netlist
         ihnl/cds3/netlist
         ihnl/cds4/netlist
    +nost.dout.
    +nocopyright
    +ncvlogargs+" -neverwarn -nostdout -nocopyright "
    +ncelabargs+" -neg_tchk -nonotifier -sdf_NOCheck_celltype -access +r -pulse_e 100
-pulse_r 100 -neverwarn -timescale 1ns/1ns -nostdout -nocopyright"
    +ncsimargs+" -neverwarn -nocopyright -gui -input
/home/grads/a/acoskuner500/ecen714/eightadder run1/.simTmpNCCmd "
    +mpssession+virtuoso9914
    +mpshost+zach-127-24.engr.tamu.edu
Relinquished control to SimVision...
ncsim>
ncsim> source /opt/coe/cadence/INCISIVE152/tools/inca/files/ncsimrc
ncsim> database -open shmWave -shm -default -into shm.db
Created default SHM database shmWave
ncsim> probe -create -shm test -all
                                           -depth 1
Created probe 1
ncsim> run 500ns
                         50 X=011111110, Y=11100111, CIN=0, SUM=00000000, COUT=0
                55 X=011111110, Y=11100111, CIN=0, SUM=01100101, COUT=1
                100 X=11111111, Y=00000000, CIN=1, SUM=01100101, COUT=1 105 X=11111111, Y=00000000, CIN=1, SUM=00000000, COUT=1
                150 X=10101010, Y=01010101, CIN=0, SUM=00000000, COUT=1
                155 X=10101010, Y=01010101, CIN=0, SUM=111111111, COUT=0 200 X=10101010, Y=01010101, CIN=1, SUM=111111111, COUT=0
                205 X=10101010, Y=01010101, CIN=1, SUM=00000000, COUT=1
                250 X=11001100, Y=00110011, CIN=0, SUM=00000000, COUT=1 255 X=11001100, Y=00110011, CIN=0, SUM=111111111, COUT=0 300 X=11001100, Y=00110011, CIN=1, SUM=111111111, COUT=0
                305 X=11001100, Y=00110011, CIN=1, SUM=00000000, COUT=1
Ran until 500 NS + 0
ncsim>
```



(Rotated for better viewing)

