
Description Rev Date Drawn V1.0 2012-11-14 First release pcDuino Document Number Rev V3.0 COVER

4

3

Tuesday, December 24, 2013

, 2013 |Sheet 1 c



Sheet

Tuesday, December 24, 2013

	5		4				3
Function	GPIO List	Pin Name	Direction	Net Name	ACUV	Default	Description
	ERXD2/SPI1_CLK/PA1	E5	0	SPI1_CLK			
SPI1	ERXD1/SPI1_MOSI/PA2 ERXD0/SPI1 MISO/PA3	D 6	0	SPI1_MOSI SPI1_MISO			SPI1_LINK
	SPIOO_CSO/UARTS_TX/EINT22/PI10	C17	0	SPIO_CS			SPIO_LINK/PWM
SPIO	SPIOO_CLK/UARTS_RX/EINT23/PI11	D17	0	SPI0_CLK			SPI01_LINK
	SPIOO_MOSI/UART6_TX/EINT24/PI12 SPIOO_MISO/UART6_RX/EINT25/PI13	C16 D16	0	SPIO_MOSI SPIO_MISO			SPIO_LINK/PWM SPIO_LINK
IICO	TWI0_SCK/PB0	A15	0	PMU-SCK			PMU_HC_LINK
1100	TWI0_SDA/PB1	B15	1/0	PMU-SDA			rino_iic_cinik
IIC1	TWI1_SCK/PB18 TWI1_SDA/PB19	AS BS	1/0	TWI1-SCK TWI1-SDA			IIC_LINK
IIC2	TWI2_SCK/PB20	C8	0	TWI2-SCK			CONN_HC_LINK
1102	TWI2_SDA/PB21	C7	1/0	TWI2-SDA			CONN_IIC_LINK
	I2S_MCLK/AC97_MCLK/PB5 I2S_BCLK/AC97_BCLK/PB6	B13 A12	0	IIS_MICLK IIS_BCLK			
	I2S_LRCK/AC97_SVNC/PB7	B12	0	IIS_LRCLK			
IIS	12S_D00/AC97_D0/PB8	A11	0	IIS_DO0			125_LINK
	I2S_D02/PB10 I2S_D03/PB11	C11 C10	0	IIS_D02 IIS_D03			
	125_DU3/FB11 125_DI/AC97_DI/SPDIF_DI/PB12	C10 C9	0	IIS_DI			
UARTO	UARTO_TX/IR1_TX/PB22	A7	0	UARTO-TX			UARTO_LINK For debug
UMMIU	UARTO_RX/IR1_RX/PB23	87	1	UARTO-RX			
	JTAG_NSO/SPI2_CSO/PB14 JTAG_CKO/SPI2_CLK/PB15	A10 B10	0	JTAG-MS JTAG-CK			
JTAG	JTAG_D00/SPI2_M0SI/PB16	A9	0	JTAG-D0			JJTAG_LINK
	JTAG_DIO/SPI2_MISO/PB17	B9	1	JTAG-DI			
	JTAGSEL NM#	T10 F5	0	JTAG-SEL NMI#			PMU_INT
	SDC0_DI/JATG_MS1/PF0	M20	1/0	SD0-D1			rmv_IIII
	SDC0_D0/JATG_DI1/PF1	M19	1/0	SD0-D0			
SDO	SDC0_CLK/UART0_TX/PF2	L20	0	SD0-CLK	_		SD_CARD
	SDC0_CMD/JTAG_D01/PF3 SDC0 D3/UARTO RX/PF4	L19 K20	0	SD0-CMD SD0-D3			
	SDC0_D2/JATG_CK1/PF5	K19	1/0	SD0-D2			
UART2	EINT30/SPI1_MOSI/UART2_TX/PI18	E15	0	UART2_TX			UART2_LINK/GP10
	EINT30/SPI1_MIS0/UART2_RX/PI19 I2S_D01/PB9	D14 C12	1	UART2_RX USB0-DRV	н	н	PMU_CHANEL_SEL/IIS
USBO	DIM0	N20	1/0	DM0	Ĺ		OTG_USB
OPRO	DPO	N21	1/0	DPO			019_028
USB1	DM1 DP1	P20 P21	1/0	DM1 DP1			USB_WIFI
USB2	DM2	R20	1/0	DM2	L		IICD T A
USDZ	DP2	R21	1/0	DP2			USB_Type_A
	SCL_HDMI SDA_HDMI	R23 R22	1/0	HSCL HSDA			HDMI_DDC
HDBI	HPD_HDMI	P22	1/0	HHPD	Н	L	HDMI_HPD
	CEC_HDMI	P23	1	HCEC	Н	L	HDMI_CEC
PTE	PWM0/PB2 PWM1/PI3	A14 B19	0	PWM1 PWM2			PWM PWM
	XP_TP	Y22	ı	ADC_2			
	XN_TP	AA22	1	ADC_3			
ADC	YP_TP YN_TP	V23 AA23	1	ADC_4 ADC_5			6_CHANEL_ADC
	LRAD CO	AB23	i	ADC_0			
	LRAD C1	AB22	!	ADC_1			CD CAPE DO
	LCD1_D1/ATAA1/UART3_RX/EINT1/CSI1_D1/PH1 LCD4_D1/ATAD0/UART4_TX/EINT4/CSI1_D4/PH4	B6 B5	1	SDO-DET# USBO_ID_DET	L L	H	SD_CARD_DET OTG_USB_DET
DF-	LCDS_D1/ATAD1/UART4_RX/EINTS/CSI1_D5/PH5	CS CS	1/0	PWM3			PWM
PTE	LCD6_D1/ATAD2/UARTS_TX/EINT6/CSI1_D6/PH6	A4	1/0	PWM0			PWM
	VMIC MICINI	AA21 AC20	1	VMIC MICIN1			
	HPOUTR	W19	0	MICIN1 HPR			110 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
Earphone	несом	AA19	1	несом			HP_LINK
	HP COMFB	AA20	1	HPCOMFB	<u> </u>	<u> </u>	
IR	HPOUTL IRO_RX/PB4	V19 A13	0	HPL IR-RX		н	IR
	TSO_CLK/CSIO_PCLK/PE0	E23	i	CS10-PCLK			***
	TSO_ERR/CSIO_MCLK/PE1	E22	!	CS10-MCLK			
	TSO_SYNC/CSIO_HSYNC/PE2 TSO_DVLD/CSIO_VSYNC/PE3	D23	1	CSIO-HSYNC CSIO-VSYNC			
	TSO_D0/CSIO_VSYNC/PE3	C23	1	CSIO-DO			
Camera	TS0_D1/CSI0_D1/PES	C22	1	CS10-D1			CSI_LINK
	TS0_D2/CS10_D2/PE6	B23	1	CS10-D2	-		- 5
	TS0_D3/CSI0_D3/PE7 TS0_D4/CSI0_D4/PE8	B22 A23	+	CS10-D3 CS10-D4			
	TSO_D5/CSIO_D5/PE9	A22	i	CS10-D5			
	TS0_D6/CSI0_D6/PE10	B21	1	CS10-D6			
	TSO_D7/CSIO_D7/PE11 TXP_SATA	A21 T20	0	CS10-D7 SATA_TXP			
e1=-	TXM_SATA	T21	0	SATA_TXN			CATA INV
SATA	RXP_SATA	U21	0	SATA_RXP			SATA_LINK
	RXM_SATA	U20	0	SATA_RXN			
	LCD0_D10/LVDS1_VP0/PD10 LCD0_D11/LVDS1_VN0/PD11	V15 AA15	0	LVDS_TA+ LVDS_TA-	-		
	LCD0_D12/LVDS1_VP1/PD12	Y14	0	LVDS_TB+			ţ
	LCD0_D13/LVDS1_VN1/PD13	AA14	0	LVDS_TB-			LVDS_LINK .
LVDS	LCD0_D14/LVDS1_VP2/PD14 LCD0_D15/LVDS1_VN2/PD15	V13 AA13	0	LVDS_TC+ LVDS_TC-			
	LCD0_D15/LVDS1_VN2/PD15 LCD0_D16/LVDS1_VPC/PD16	712	0	LVDS_TCLK+			
	LCD0_D17/LVDS1_VNC/PD17	AA12	0	LVDS_TCLK-			
	LCD0_D18/LVDS1_VP3/PD18 LCD0 D19/LVDS1 VN3/PD19	Y11 AA11	0	LVDS_TD+ LVDS TD-			
	LCD1_D19/LVDS1_VN3/PD19 LCD1_D0/ATAD0/UART3_TX/EINT0/CS11_D0/PH0	A6	1	PH_DET	н	L	PH_DET
	LCD1_D2/ATAD2/UART3_RTS/EINT2/CSI1_D2/PH2	C6	0	SATA_PWR_EN	Н	L	SATA_PWR_EN
	LCD1_D7/ATAD3/UART5_RX/EINT7/CSI1_D7/PH7 LCD1_D8/ATAD4/EINT8/CSI1_D8/PH8	84 C4	1/0	GP102 GP103			GPIO GPIO
	LCD1_D9/ATAD5/EINT9/CSI1_D9/PH9	D4	1/0	GPI04			GP10
	LCD1_D10/ATAD6/EINT10/CSI1_D10/PH10	A3	1/0	GPI05			GPIO
	LCD1_D11/ATAD7/EINT11/CSI1_D11/PH11 LCD12_D12/ATAD8/EINT12/CSI1_D12/PH12	B3 C3	1/0	GP106 GP107			GPIO GPIO
	LCD12_D12/ATAD8/EINT12/CSI1_D12/PH12 LCD1_D13/ATAD9/EINT13/CSI1_D13/PH13	C3 A2	1/0	GPI07 GPI08			GPIO GPIO
GPTO	LCD14_D14/ATAD10/EINT14/CSI1_D14/PH14	B2	1/0	GP109			GP10
GP10		A1	0	TX_LED	L	Н	TX_LED
GP10	LCD1_D15/ATAD11/EINT15/CSI1_D15/PH15				L	н	RX_LED
GP10	LCD1_D15/ATAD11/EINT15/CSI1_D15/PH15 LCD1_D16/ATAD12/EINT16/CSI1_D16/PH16	B1	0	RX_LED Key Back		μ	Kay David
GP10	LCD1_D15/ATAD11/EINT15/CSI1_D15/PH15	C1	0 I	Key_Back	L L	H	Key_Back Key_Home
GP10	LCD1_D15/ATAD11/BNT15/CS11_D15/PH15 LCD1_D16/ATAD12/BNT16/CS11_D16/PH16 LCD1_D17/ATAD13/BNT17/CS11_D16/PH17 LCD1_D18/ATAD14/ENT18/CS11_D16/PH18 LCD1_D19/ATAD15/ENT19/CS11_D16/PH19	C1 C2 D1	-	Key_Back Key_Home Key_Menu	L	H H	Key_Home Key_Menu
GP10	LCD1_D15/ATAD11/EINT15/CSI1_D15/PH15 LCD1_D16/ATAD12/EINT16/CSI1_D16/PH16 LCD1_D17/ATAD13/EINT17/CSI1_D16/PH17 LCD1_D18/ATAD14/EINT18/CSI1_D16/PH18	C1 C2		Key_Back Key_Home	L	н	Key_Home

