IMAGETEAM™ 3800, 3900, 4600, 4800, 3800r, 3800i Hand Held Linear Imager
USB Programming Bar codes - USB, Laptop, Suffix, Trigger Modes, Factory Default

USB Terminal Interface
Programs the scanner to work as a USB Keyboard Device

Keyboard Emulation
Programs the scanner to work without an external keyboard.

TAB Suffix
Programs the scanner to add a TAB key function after each scan.

Carriage Return Suffix
Programs the scanner to add an Enter key function after each scan.

Clear all Suffixes
Removes all suffixes

Sample Code 39

TEST123

USB PLUS-PS 09/20/06

Auto Trigger
Hands free, Scans continuously at full power.
Note: NOT available in 4600 or 4800

Presentation Mode
Hands free, LED's are off until a bar code is presented.

Reread Delay = Medium
Sets a delay before the scanner can read the same barcode again.
Note: for the 3800 and 3900 Only

Note: For 4600g, 4800i, 3800r, 3800i Only

Manual Trigger
Must press the trigger to activate the scanner

Factory Defaults
Resets your scanner to default settings.