

Advanced Optimiser Tab Manual

Overview

The **Optimiser Tab** determines the best combination of **Spot Size**, **Laser Repetition Rate**, and **Scan Speed** (or Dwell Times) to achieve your analytical goals. It works by “working backwards” from your desired signal quality (SNR) and hardware limits to find the most efficient sampling capability.

User Interface

1. Left Panel: Settings & Configuration

Top Controls

- **Reload Data from iolite:** Refreshes input channels from the main iolite interface.
- **Settings:** Opens the detailed **Hardware Configuration** dialog.

Hardware Configuration Dialog

Accessible via the “Settings” button. This establishes the physical limits of your system.

- **ICP-MS Hardware:**
 - **Manufacturer/Model:** Presets minimum dwell times and switching speeds.
 - **Custom Models:** Choose “Custom Model” (ICP) or “Custom Laser” (Platform) to manually define limits:
 - **ICP Custom Fields:**
 - **Type:** Quadrupole, Sector-Field, Multi-Collector (MC), or TOF.
 - **Allowed Dwell Times:** (MC only) Comma-separated list of valid integration times.
 - **Min Dwell / Precision:** (Quad/TOF) The hardware speed limits.
 - **Laser Custom Fields:**
 - **Mode:** Choose “Maximum Rep-Rate” (continuous) or “Discrete” (specific allowed frequencies).
 - **Max Speed:** Physical limit of the sample stage.
- **Laser Hardware:**
 - **Platform/Source:** Presets maximum repetition rates and frequency precision.
 - **Cell Type:** Defines the maximum stage speed (washout behavior is handled separately).

Input Parameters

Basic setup for your experiment.

- **Initial Spot Size:** The starting point for optimization (often adjusted automatically).
- **Washout:** The time (ms) required for the signal to decay (usually determined via the SPR Tab).
- **Initial Rep-Rate:** A baseline frequency guess (Hz).
- **Mode:**
 - **Spot:** Analysis of a single location.
 - **Number of Shots:** Total laser pulses per spot.
 - **Line:** Continuous scanning along a path.
 - **Line Length:** Total distance (μm).
 - **Imaging:** 2D mapping (raster scan).
 - **Image Width / Height:** Dimensions of the area (μm).

Optimisation Parameters

The “Goals” you want the algorithm to achieve.

- **Pulses per Dwell Time:** The number of laser shots that must occur during a single mass spectrometer integration (dwell) to ensure signal stability.
- **Target SNR (Sigma):** The desired Signal-to-Noise ratio for the limiting isotope.
 - **Calculation Method:** The optimiser calculates SNR in the **Counts Domain** (Total Counts per Dwell) to robustly handle low signals:
 1. **Poisson Variance (Counting Statistics):** Assumed to be equal to the **Mean Background Counts**.
 2. **Flicker Variance (Instrument Noise):** Calculated as the **(Standard Deviation of Background Counts)²**.
 3. **Total Noise:** $\text{Sqrt}(\text{Poisson Variance} + \text{Flicker Variance})$.
 4. **SNR:** $\text{Net Signal Counts} / \text{Total Noise}$.
 - This approach is conservative, effectively summing the theoretical minimum noise (Poisson) with the observed experimental noise (Flicker/Real) to ensure targets are met even under unstable conditions.
- **Min Duty Cycle:** Sets a floor for efficiency ($\text{Time Measuring} / \text{Total Time}$).
 - If the calculated duty cycle is too low (mostly settling time), the optimiser will increase dwell times to improve the ratio.
- **Minimum SNR:** Lower limit for acceptance; channels below this may trigger warnings.
- **Image Dimensions:** (See **Mode** above).
- **Scale Signal with Rep-Rate:**
 - **Checked (Linear Scaling):** Assumes signal intensity (CPS) increases linearly with Frequency (Hz).

- **Why?** Higher Rep-Rate delivers more pulses per second, ablating more material per second, which generates a higher ion signal.
 - **Use Case: Geological Samples** (e.g., blocks/mounts) where there is “infinite” depth. As the laser fires active shots, it drills deeper into fresh material, maintaining the signal increase.
- **Unchecked (Fixed Sensitivity):** Assumes signal intensity is determined by Spot Size alone, regardless of frequency.
 - **Use Case: Thin Sections / Bio-Imaging.** If the laser already fully ablates the entire thickness of the sample (e.g., a 30µm tissue section) with a single shot, firing faster *does not* generate more signal—it simply consumes the sample faster. Checking this box here would dangerously overestimate your SNR.
- **Avoid Gaps:**
 - **Goal:** Prevents “striping” in images by ensuring the stage doesn’t move faster than the laser can fire.
 - **How:** Constraints the calculation so $\text{Speed} \leq \text{Spot Size} * \text{Rep Rate}$.
 - **Pros:** Guarantees full surface coverage.
 - **Cons:** May force a slower stage speed or higher Rep-Rate (potentially increasing washout issues).

Optimised Settings (Results Summary)

The calculated “Ideal” instrument settings.

- **Spot Size:** The recommended beam diameter.
- **Rep-Rate:** The optimal laser frequency (Hz).
- **Speed:** The optimal stage translation speed (µm/s).
- **Acq Time / Budget:** The total integration cycle time calculated to match the laser synchronization.
- **Est. Time:** Total predicted duration of the analysis (HH:MM:SS).

2. Right Panel: Visualisation & Details

Signal Plot (Top)

- Displays real-time signal traces for the selected channels.
- **Regions:**
 - **Background (Blue):** Time range for baseline calculation.
 - **Signal (Red):** Time range for signal intensity calculation.
 - **Auto Select Regions:** Automatically finds the rising/falling edges of the signal.
- **Controls:**
 - **Theme:** Toggle Dark/Light mode.
 - **Normalize:** Scales all traces to 0-1 range for easy comparison.

- **Pan/Zoom Y:** Enables vertical zooming interaction.

Optimised Dwell Time Distribution (Table)

Detailed breakdown per channel.

- **Mode:**
 - **Auto:** Software calculates the optimal dwell.
 - **Exclude:** Channel is ignored.
 - **Set to Min:** Forces the channel to the hardware minimum dwell.
 - **Custom:** Allows manual entry of a specific dwell time.
 - **Optimised Dwell Times:** The calculated integration time for each isotope.
 - **SNR:** Comparison of Initial vs. Resultant Signal-to-Noise Ratios.
-

Workflow Guide

Step 1: Hardware Setup

1. Click **Settings**.
2. Select your **ICP-MS** and **Laser** models.
3. If your specific model isn't listed, choose "Custom" and enter the **Min Dwell Time** (ICP) and **Max Rep Rate** (Laser) manually.

Step 2: Load Data

1. Ensure your iolite session has representative data (e.g., a "Tuning" line).
2. Click **Reload Data from iolite**.
3. **Missing Dwell Times?**
 - If your data lacks embedded dwell time metadata (common with some CSV imports), a dialog will appear.
 - **Set to Global:** Apply a single dwell time (e.g., 10ms) to all channels.
 - **Individual:** Manually enter the dwell time for specific channels if they differ.
4. Verify the plot shows the signal traces.
5. **Check Regions:** Ensure the **Background (Blue)** and **Signal (Red)** regions are correctly identifying the baseline and signal plateau. Use "Auto Select Regions" or adjust the spinboxes manually if needed.

Step 3: Define Goals

1. Set the **Mode** (usually "Imaging" or "Line").
2. Enter your **Washout** time (can be applied from the SPR Tab).
3. Set your target quality metrics (e.g., **Pulses per Dwell Time** = 10, **Target SNR** = 10).

Step 4: Run Optimization

The optimization runs automatically whenever you change a parameter.

1. Watch the **Optimised Settings** panel.
2. The software will display the recommended **Spot Size**, **Rep-Rate**, and **Speed**.
3. Check the **Results Table** at the bottom. Are any important isotopes failing to reach the target SNR?
 - *Orange Highlight*: Cannot reach Target SNR (set to Min).
 - *Blue Highlight*: Hardware limited (cannot go faster).
4. If the Spot Size is too large/small, adjust the **Target SNR** or **Pulses per Dwell** to constrain it.

Step 5: Advanced Logic & Overrides

1. **Min SNR Constraints:**
 - **Quadrupoles**: If a channel cannot meet the Minimum SNR, its dwell time is forced to the *Minimum Dwell* allowed by hardware to save time for other channels.
 - **MC / TOF**: Since all channels are measured simultaneously, the dwell time cannot be reduced individually. Instead, the channel is flagged with an Orange warning in the table.
2. **Min Duty Cycle:**
 - Forces the total integration time to be long enough relative to the magnet settling time (overhead). Useful for ensuring you aren't wasting 50%+ of your analysis time just switching masses.
3. **Manual Overrides:**
 - If you need to force a specific spot size:
 - Change the **Spot Size** spinbox in the "Optimised Settings" panel (it normally says "Auto").
 - This locks the spot size and re-optimizes only the Rep-Rate and Speed.
 - Set it back to 0 (or "Auto") to resume full optimization.
4. If you need to force a specific rep-rate:
 - This is usually derived from the spot size and washout. To influence it, try changing the **Avoid Gaps** setting or **Washout** value.

Tips & Tricks

- **Linking SPR**: Use the SPR Tab first to determine the exact washout time for your cell/tubing, then "Apply" it to the Optimiser.
 - **Duty Cycle**: For Sequential ICP-MS (Quadrupoles), a higher Duty Cycle means more efficient use of time. For TOF/MC, this is always 100%.
 - **Avoid Gaps**: Essential for imaging. It ensures that $\text{Speed} \leq \text{Spot Size} * \text{Rep Rate}$, preventing "striping" artifacts in your map.
-

Status Messages

The Optimiser provides feedback through the status bar and log to explain why certain settings were chosen or constrained. Understanding these messages can help you troubleshoot why a specific result was calculated.

General Optimization Messages

- **“Optimum Spot Size [X] μm - Based on Minimum SNR of [Isotope]”**
 - Indicates that the Spot Size was calculated specifically to satisfy the SNR target for the weakest isotope listed.
- **“Optimum Spot Size [X] μm - Overridden to [Y] μm ”**
 - Appears when you have manually set the Spot Size spinbox to a specific value (Y), overriding the calculated optimum (X).
- **“Calculated Pulses per Dwell Time: [X] (Error: [Y]%)”**
 - Shows the *actual* number of laser pulses that will occur during one mass spectrometer integration. The error percentage shows the deviation from your target “Pulses per Dwell” setting. Small errors (<10%) are usually acceptable.

Hardware Constraints

- **“Constraint: Acq Time increased for Rep Rate Limit”**
 - The Acquisition Time had to be extended because the required Dwell Times + Washout would require a Laser Rep-Rate higher than the laser can physically fire.
- **“Constraint: Acq Time increased for Stage Speed Limit”**
 - The Acquisition Time had to be extended because the stage would need to move faster than the cell’s maximum speed to cover the spot size in the calculated time.
- **“Constraint: Acq Time increased for Duty Cycle ([X]%)”**
 - The total integration time was increased to ensure that the measurement time vs. overhead (settling) time met your “Min Duty Cycle” target.
- **“Constraint: Acq Time increased for Dwell Budget ([X] ms)”**
 - The total time was increased because the sum of the minimum required dwell times for all elected isotopes exceeded the initial budget derived from the Washout Time.

Channel-Specific Warnings

These messages list specific isotopes that are affecting the optimization logic.

- **“The following channels do not meet the minimum SNR target...”**

- **Orange Warning:** These channels have a calculated SNR below your “Minimum SNR” threshold.
- For **MC/TOF** systems, this is just a warning.
- For **Quadrupole** systems, these channels have been forced to the minimum dwell time to save budget.
- **“The following channels cannot be set lower than the hardware minimum ([X] ms)...”**
 - **Blue Warning:** The algorithm wants to reduce the dwell time for these channels (usually high-signal ones) to optimize speed, but is blocked by the hard limit of the instrument (e.g., 1ms or 10ms minimum dwell).
- **“The following channels had zero counts in the background. The background has been assumed to be 1 count over the baseline duration...”**
 - **Gray Warning:** Indicates that the background signal was perfectly zero (common in simulated data or extremely short baselines). To prevent division-by-zero errors in the SNR calculation, a theoretical noise floor of 1 count was assumed.