
# Introduction to Computer Architecture ISE1 & EE2 Autumn 2010 - Dr. Tom Clarke

- EDSAC first stored program computer
- Cambridge 1949
- 650 instructions per second.
- 1024 17-bit words of memory in mercury ultrasonic delay lines.
- 3000 valves, 12 kW power consumption, occupied a room 5m by 4m.
- Early use to solve problems in meteorology, genetics and X-ray crystallography.

#### 60 years ago...



**Electronic Delay Storage Automatic Computer** 

- ◆ ARM7 core up to 130 million instructions per second. 1995-2011.
- ARM7 core in many variations is most successful embedded processor today.
- Picture shows LPC2124
   microcontroller which includes
   ARM7 core + RAM, ROM integrated
   peripherals.
  - The complete microcontroller is the square chip in the middle
  - 128K X 32 bit words flash RAM
  - ❖ 10mW/Mhz clock
- Original ARM design:
  - Steve Furber, Acorn Risc Machines, Cambridge, 1985

#### ... and Now



#### ARM7 CPU – LPC-2124 microcontroller

# Why study this course?

- Computers are the single most significant technological advance of the 20th century
- The course makes a bridge between digital electronics (hardware) & high level languages (software)
- You will learn the basic concepts needed to understand how all computers work

# ISE1 / EE2 Principles of Computers

- Course materials based on two books:
  - "Computer Organization & Design" 2nd edition, Patterson & Hennessy 1998 (around £30 new £15 2<sup>nd</sup> hand via Amazon)
    - Covers most topics on this course
    - → V. Useful for ISE also used in 2<sup>nd</sup> Year.
  - \* "ARM System-on-Chip Architecture", Steve Furber, 2000 (around £25)
    - Best book on ARM processor
- Administration issues:
  - Around 15 lectures on this part of the course
  - Problem sheets for programming labs (EE) / tutorials (ISE)
  - Coursework: will be programming exercises + on-line tests
  - Course website: www2.ee.ic.ac.uk/t.clarke/arch/

## What will you be learning?

#### Part 1 - Introduction

- What is a computer?
- What is Instruction Set Architecture (ISA)
- How is an ISA implemented in hardware? (at an abstract level)
- ❖ MU0 a simple computer
- Instruction formats
- Memory addressing

#### Part 2 – ARM Assembly Language

- \* Assembly language large part of the course
- Details of the ARM ISA
- How to use arithmetic & logical data operations
- How are machine instructions used to implement programs?

#### Part 3 – Hardware Topics


- Computer interfacing with peripherals
  - interrupts & DMA
- ARM Organisation
  - Pipelining
  - Throughput
- Memory hierarchy

# Part 1

#### Introduction to Machine Architecture








300mm wafer, used for production of Intel's "Dothan" Pentium mobile CPUs

#### Levels of representation in computers



```
temp = x;
x = y;
y = temp;
```

```
LDR R0, [PC, #0x0014]


LDR R1, [R0]

LDR R2, [R0,#0x0004]


STR R2, [R0]

STR R1, [R0,#0x0004]
```

# What is "Computer Architecture"?



abstraction



**Application** 

Compiler and Operating System

Instruction Set Architecture

**CPU** hardware


digital logic

Word, Firefox, Mass Effect II

gcc / Linux, Windows 7



ARM / x86 Pentium / ARM7



Core 2 Duo/ AMD Athlon II

NAND/NOR gates, flip-flops

#### What is "Instruction Set Architecture (ISA)"?

- "... the attributes of a [computing] system as seen by the programmer, i.e. the conceptual structure and functional behavior, as distinct from the organization of the data flows and controls, the logic design, and the physical implementation."
  - Amdahl, Blaaw, and Brooks, 1964
- What the computer does, not how it does it!


#### ISA includes:-


- Instruction (or Operation Code) Set
  - Data Types & Data Structures: Encodings & Representations
  - Instruction Formats
- Organization of Programmable Storage (main memory etc)
- Modes of Addressing and Accessing Data Items and Instructions
- Behaviour on Exceptional Conditions (e.g. hardware divide by 0)

## Why is ISA important

- 8086/pentium ISA
  - Allows operating systems and applications to work seamlessly across different computer architectures:
    - Pentium
    - Core 2 duo
    - Athlon
    - 7 Phenom
- ARM ISA
  - Supports highly optimising compiler & operating system software for embedded applications
  - ARM cores can be licensed & sold by different vendors
- Key advantage: different implementations of the same
   ISA can all run identical software

# Factors influencing computer architectures







#### Semiconductor feature size drives technology


- ◆ Transistors/cm² scales as (feature size)-2
  - \* 2005 100nm
  - 2011 32nm
- Speed scales as (feature size)-1/2
  - Other factors limit speed at very small sizes

Note:
Chips get bigger with time
10%/year of transistor increase is
from larger chip size





## Logic & memory relative performance



#### When will Moore's law end?

#### Technology


- Gordon Moore coined Moore's law in 1965
- Number of transistors per chip roughly doubles every 2-3 years
- In 2007 Moore said it could last for another 10-15 years
- The technological limits on making transistors smaller are the size of atoms in 2007 transistor gates were 5 atoms thick!
- Use of high-k Hafnium in gates has pushed capability beyond previous 45nm limits

#### Economics


- Current generation CPUs (2011): 32nm
- Globalfoundries' "Fab 8" in New York, 2012, 28nm, 5 years to build,
- ❖ Intel's "Fab 42" Arizona, 2013, 14nm
- Len Jelinek (chief analyst for at isuppli): 2014, around 20nm, will be end of economic return from new fabs. Moore's Law will stop.
- Semiconductor manufacturers expect continued technological improvement in specific markets, e.g. non-volatile memory to replace hard disks

## Internal Organisation of Computer

Processor aka CPU (Central Processing Unit)




- Major components of Typical Computer System
- Data is mostly stored in the computer memory separate from the Processor, however registers in the processor datapath can also store small amounts of data




# Instructions can move data between CPU registers

- ◆ **READ** A (1234)
- ◆ **READ** B (2000)
  - NB order of reading A,B does not matter
- ◆ WRITE D (3234)



## Inside the memory unit

- Memory contains 8locations named 0-7
- Memory location numbers are called addresses
- A Location's data can be READ or WRITTEN
- Address is a number which specifies location to be READ or WRITTEN with data



# Instructions can move data between memory & registers

Memory location with address 12 is called

mem[12]

A:

1234=>961

B:

**2000** 

<b>Instruction:</b>								
A	:=	<b>mem[6]</b>						
W		R						

READ mem[6] (961) WRITE A (961) Instruction: mem[0] := B

W R

READ B (2000) WRITE mem[0] (2000)

address	data
0	22=>2000
1	0
2	33
3	0
4	0
5	0
6	961
7	100

## Summary

- Speed and density of computers is increasing exponentially with time: speed is near limit, density will reach limit some time. (15 years?).
- All computers consist of five components
  - Processor (CPU): (1) datapath and (2) control
  - (3) Memory
  - (4) Input devices and (5) Output devices
- This course will concentrate on Instruction Set Architectures and their use through assembly language programming
  - Assembly language is a human-readable version of machine code
  - Think of this as being like learning arithmetic calculators are better for big calculations – but you can't understand maths without doing it for yourself as well.
- We will use the ARM processor as our main example

## Lecture 2 A Very Simple Processor

The point of philosophy is to start with something so simple as not to seem worth stating, and to end with something so paradoxical that no one will believe it."

Bertrand Russell

- In this lecture we will show how the control part of a CPU works.
- We describe the operation, in detail, of a very simple processor called MU0.
- Although this is a toy example it illustrates important concepts we use later on:
  - Machine instructions written in assembler, and codes in machine words
  - Sequential execution of instructions

## Data in Computer Memory

#### Memory locations

- Look into memory and you'll see '1's and '0's. Meaning depends on context: could be program, could be numeric data, etc
  - **ADDRESS**
- Data & programs are stored in memory
- Each memory location has fixed width: number of bits (binary digits) of data
- The width of the memory unit is typically 8, 16, 32, 64 bits etc.
- The width of the address a depends on the number of locations N:
  - Thus 8 bits can address up to 256 locations

0	
1	
2	
3	
4	
5	
6	
7	
8	
9	
10	
11	01001101
<b>12</b>	
13	
14	
15	
	MEMORY

## Digital representation of numbers

- We will say more about this in part 2
- ◆ For now, a number stored in a computer will have a fixed number of bits (binary digits) usually 8, 16, or 32.
  - N bits can store whole unsigned numbers in range  $0 \le x \le 2^N 1$
- Each storage location or register in a computer which stores data has a fixed size in bits, and thus can store nonnegative whole numbers up to a given maximum size.

#### **2**<sup>4</sup> = **16** numbers

0000	0
0001	1
0010	2
0011	3
0100	4
0101	5
0110	6
0111	7
1000	8
1001	9
1010	10
1011	11
1100	12
1101	13
1110	14
1111	15

#### How to write numbers

#### 16 bit memory location or register

0	0	0	0	0	0	1	1	0	0	0	1	1	0	1	0	
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	--

What is stored in hardware:

0000001100011010

**Human readable representations:** 

binary number (base 2) 0 or 1 1100011010

decimal number (base 10) 0-9 794

hexadecimal number (base 16) 0-9, A-F 31A

as above, but with leading zeros 031A

Use whichever representation is easiest - the data is the same

#### More on Binary Notation – numbers as 1s and 0s

 Digital computers use a binary number system where the base (or radix) is 2. The radix determines the weight given to each digit:

DIGIT *	2 POSITION#	
---------	-------------	--

Fours	Twos	Ones	Halves	Fourths
22	21	20	2-1	2-2
1	1	0	1	1


- For example, the value of this binary number is as on left:
- NOTATION:

\* 
$$12_{(10)}$$
 12 decimal  
\*  $12_{(8)}$  12 octal =  $10_{(10)}$ 

$$\bullet$$
 1000<sub>(2)</sub> 1000 binary = 8<sub>(16)</sub>

$$\begin{array}{rclrcl}
 1*2^2 & = & 1*4 & = & 4. \\
 1*2^1 & = & 1*2 & = & 2. \\
 0*2^0 & = & 0*1 & = & 0. \\
 1*2^{-1} & = & 1*.5 & = & 0.5 \\
 1*2^{-2} & = & 1*.25 & = & + 0.25 \\
 \hline
 6.75
 \end{array}$$

# Octal and hexadecimal number systems: easy to translate to/from binary



#### Extra hex digits

1	0	1	0	10	Α
1	0	1	1	11	В
1	1	0	0	12	C
1	1	0	1	13	D
1	1	1	0	14	Е
1	1	1	1	15	F

What is this number in decimal?

# Hexadecimal examples

You should remember these:

$$• 10_{(16)} = 16, F_{(16)} = 15$$


$$• 100_{(16)} = 256, FF_{(16)} = 255$$

$$•$$
 1000<sub>(16)</sub> = 4096, FFF<sub>(16)</sub> = 4095


$$•$$
 10000<sub>(16)</sub> = 65536, FFFF<sub>(16)</sub> = 65535

- For convenience 1024 = 1K, so 4096=4K, 65536=64K etc.
- What is 2013<sub>(16)</sub>?
  - In binary?
  - In decimal?
- ♦ Can you work out  $(1000_{(16)} 8)$  in hexadecimal (borrow is 16, not 10)?
  - ❖ FF8<sub>(16)</sub>

#### MU0 - A Very Simple Processor



## Logical (programmer's) view of MU0



Memory location with address 0 is storing data 551

**Registers:** 

Each can store one 16 bit number

A: Accumulator

**PC: Program Counter** 

Memory
Locations:
Each can store
one 16 bit
number

(NB IR is not visible to programmer)

#### MU0 Design

- Let us design a simple processor MU0 with 16-bit instruction and data bus and minimal hardware:-
  - Program Counter (PC) holds address of the next instruction to execute (a register)
  - One register: accumulator (A) holds data being processed
  - Instruction Register (IR) holds current instruction code being executed
  - Arithmetic Logic Unit (ALU) performs operations on data
- We will only design 8 instructions, but to leave room for expansion, we will allow capacity for 16 instructions
  - so we need 4 bits to identify an instruction: the *opcode*

# MU0 Design (2)

- Let us further assume that the memory is word-addressable (forget bytes)
  - \* each 16-bit word has its own location: word 0, word 1, etc.
    - Mu0 can't address individual bytes!

address	data
0	0123 <sub>(16)</sub>
1	7777 <sub>(16)</sub>

The 16-bit instruction code (machine code) has a format:

4 bits	12 bits
opcode	S

- Note top 4 bits define the operation code (opcode) and the bottom 12 bits define the memory address of the data (the operand)
- ◆ This machine can address up to 2<sup>12</sup> = 4k words = 8k bytes of data

#### **MU0 Instruction Set**

- mem[S] contents of memory location with address S
- [Think of memory locations as being an array here S is the array index]
- ❖ A is the single 16 bit CPU register
- ❖ S is a number from instruction in range 0-4095 (000<sub>(16)</sub>-FFF<sub>(16)</sub>)

	Instruction	Opcode (hex)	Effect
LoaD A	LDA S	0000 (0)	A := mem[S]
Store A	STA S	0001 (1)	mem[S] := A
ADD to A	ADD S	0010 (2)	A := A + mem[S]
SUBtract from A	SUB S	0011 (3)	A := A - mem[S]
JuMP	JMP S	0100 (4)	PC := S
Jump if Gt Equal	JGE S	0101 (5)	if A ≥ 0, PC := S
Jump if Not Equal	JNE S	0110 (6)	if A ≠ 0, PC := S
SToP	STP	0111 (7)	stop

## Our First Program

- The simplest use of our microprocessor: add two numbers
  - Let's assume these numbers are stored at **two consecutive locations** in memory, with addresses 2E and 2F
  - Let's assume we wish to store the result back to memory location [with address] 30
- We need to load the accumulator with one value, add the other, and then store the result back into memory

Instructions execute in sequence

LDA 02E 002E

ADD 02F 202F

STA 030 1030

STP 7???

Note – we follow tradition and use Hex notation for addresses and data


Human readable (mnemonic) assembly code

Machine Code

#### Walkthrough of MU0 execution

- Common technique used to debug computer programs
- Write down state of all internal registers, memory, etc.
- Trace through instructions making the necessary changes at each step
- In machine code the PC register determines which instruction will next be executed.
  - Normally PC is incremented at end of each instruction to get to the next instruction in the sequence
- Each machine instruction is implemented in hardware during one or more clock cycles in which things happen. We will trace through each cycle
  - This technique is invaluable when debugging or learning initially!

#### Caught in the Act!




 Initially, we assume PC = 0, data and instructions are loaded in memory as shown, other CPU registers are undefined.


#### Instruction 1: LDA 02E

NB - data shown is after each cycle has completed - so PC is one more than PC used to fetch instruction

Cycle 1 (fetch instr and increment PC)


Cycle 2 (execute instruction)






	machine code			
000	<b>0</b> 02E			
001	<b>2</b> 02F			
002	<b>1</b> 030			
003	<b>7</b> 000			
004				
005				
006				
:				
02E	0AA0			
02F	0110			
030				


#### Instruction 2: ADD 02F






tjwc - 28-Oct-11

#### Instruction 3: STA 030





#### Instruction 4: STP


Cycle 1

ALU

PC
4

OBBO
7000

data bus



## Key Points: instructions

- Microprocessors perform operations depending on instruction codes stored in memory
- Instructions usually have two parts:
  - Opcode determines what is to be done with the data
  - Operand specifies where/what is the data
- Program Counter (PC) address of current instruction
- PC incremented automatically each time it is used
  - Therefore instructions are normally executed sequentially
- The number of clock cycles taken by a MU0 instruction is the same as the number of memory accesses it makes.
  - LDA, STA, ADD, SUB therefore take 2 clock cycles each: one to READ from memory (fetch) the instruction, a second to fetch (and operate on) the data
  - ❖ JMP, JGE, JNE, STP only need one memory read (the instruction itself) and therefore can be executed in one clock cycle.

## Key Points: hardware

- Memory contains both programs and data
- Program area and data area in memory are usually well separated. Reading program instructions as data is possible but not useful
- ALU is responsible for arithmetic and logic functions
- There are usually one or more general purpose registers for storing results or memory addresses. MU0 only has one: A
  - more registers => more powerful. See ARM later
- Fetching data from inside the CPU is much faster than from memory unit
  - Assume number of memory operations determines number of cycles needed to execute instruction
- Assume MU0 will always reset to start execution from address 000<sub>16</sub>.

#### Lecture 3 – Memory Fundamentals

"A good scientist is a person with original ideas. A good engineer is a person who makes a design that works with as few original ideas as possible. There are no prima donnas in engineering." Freeman Dyson

- This will introduce some of the general features needed to understand other ISAs such as the much more complex ARM ISA which we study in detail in Part 2
  - CPU instruction format
  - Memory architecture

#### Instruction format classification


- 3-operand instruction format (used by ARM processor)
  - dest := op1 op op2

f bits	n bits	n bits	n bits
function	op 1 addr.	op 2 addr.	dest. addr.

- 2-operand instruction format (used by the AVR 8 bit microcontrollers)
  - dest := dest op op1

f bits	n bits	n bits
function	op 1 addr.	dest. addr.

- 1-operand instruction format (used in MU0 and some 8-bit microcontrollers such as MC6811)
  - acc := acc op op1



## a := b+c Memory or Registers?

#### 2 & 3 operand ISAa have multiple registers Assume 8 registers called R0-R7

a,b,c stored in memory

**LDA** mem[100]

**ADD** mem[101]

**STA mem[102]** 

1 operand (MU0)

a: mem[102]

b: mem[101]

c: mem[100]

a,b,c stored in registers

ADD RO,R1

**MOV, R2, R0** 

**ADD R2, R1, R0** 

2 operand (AVR)

a: R2

b: R1

:: R0

ADD R0,R1 ;R0:=R0+R1

MOV R2,R0 ;R2 := R0

3 operand (ARM)

a: R2

b: R1

: R0

ADD R2,R1,R0 ;R2:=R1+R0

#### Modern CPU Design

#### 1. Load / Store architecture

- registers are faster than memory so use them whenever possible
- Lots of registers only go to main memory when really necessary.
- Separate register/ALU instructions (fast) from memory READ & WRITE.
  - Memory READ is called LOAD, Memory WRITE is called STORE

#### 2. Concurrent execution of instructions for greater speed


- multiple function units (ALUs, etc) superscalar or VLIW (EPIC) examples: Pentium & Athlon
- "production line" arrangement overlaps instructions in a pipeline: all modern CPU.
  - See later

#### 3. On-chip caches for greater speed

- Incorpoate some memory (cache) on same chip as CPU
  - See later


## Main memory organisation

- Main memory is used to store programs, data, intermediate results
- Two main organisations: Harvard & von Neumann
- Harvard architecture.
  - ❖ In A Harvard architecture CPU programs are stored in a separate memory (possibly with a different width) from the data memory. This has the added benefit that instructions can be fetched at the same time as data, simplifying & speeding up the hardware.
  - In practice, the convenience of being able to read and write programs just like normal data makes this less usual
    - → still popular for fixed program microcontrollers.



## Von Neumann memory architecture

- Von Neumann architecture (like MU0).
  - Programs and data occupy a single memory.
- Think of main memory as being an array of words, the array index being the memory address. Each word (array location) has data which can be separately written or read.
- Usually instructions are one word in length but can be either more or less




## Memory review

- Memory locations store instructions or data and each have unique numeric addresses
  - Usually addresses range from 0 up to some maximum value.
- Memory space is the unique range of possible memory addresses in a computer system
- We talk about "the address of a memory location".
- Each memory location stores a fixed number of bits of data, normally 8, 16, 32 or 64
- We write mem<sub>8</sub>[100], mem<sub>16</sub>[100] to indicate the value of the 8 or 16 bits with memory address 100 etc. & indicates hex number.
  - $mem_{16}[\&02E] = \&0AA0$

	machine		
	<u>code</u>		
000	<b>0</b> 02E		
001	<b>2</b> 02F		
002	<b>1</b> 030		
003	<b>7</b> 000		
004			
005			
006			
:			
02E	0AA0		
02F	0110		
030	0BB0		

#### Nibbles, Bytes, Words


- Internal datapaths inside computers could be different width for example 4-bit, 8-bit, 16-bit or 32-bit.
- For example: ARM processor uses 32-bit internal datapath
- WORD = 32-bit for ARM, 16-bit for MU0, 64 bit for latest x86 processors
- BYTE (8 bits) and NIBBLE (4 bits) are architecture independent



## Byte and Word addressing


- Many programs, for example those manipulating characters each of which takes up one byte – need to access memory as an array of bytes, not words.
- For example in a 16 bit system there are 2 bytes for every word.
  This means that byte addresses must increase twice as fast as
  word addresses. There are two different ways to number bytes
  within a word as below.

#### NB. Numbers in locations are byte address, not data



## Byte addresses for words

- Most computer systems now use little-endian byte addressing, in which the least-significant byte has the lower address.
- It is inconvenient to have completely separate byte and word addresses, so word addressing usually follows byte addressing.
  - The word address of a word is the byte address of its lowest numbered byte. This means that consecutive words have addresses separated by 2 (16 bit words) or 4 (32 bit words) etc.




#### What is an "address"?

- Conceptually, a memory location address is just a name, like
   A,B,C,D. The location value (stored data) changes, not the address.
- Practically, because addresses are numbers, we can use this fact to advantage
- MU0 executes sequential programs by adding one to PC each instruction. PC is the address of the next instruction to be executed
- Later we will see that numeric addresses allow sequential data access
- Words & bytes both need addresses so they can be READ & WRITTEN
- The best solution is to make word addresses follow bytes
  - **❖** 16 bit memory: 0,2,4,6,...
  - **❖** 32 bit memory: 0,4,8,12,...

# Different views of memory access: byte or word

NB 0x alternate notation for hex (&)


- Different instructions to allow either byte or word access to memory.
  - Word read or write operates on a whole word Mem<sub>16</sub> in memory
  - The memory address is the word address (even number)
  - Byte read or write is similar except that a single byte (half a word here) is read or written Mem<sub>8</sub>.




$$Mem_{16}[800] = 0x0203_{(16)} = 515$$
  
 $Mem_{16}[802] = 10_{(16)} = 16$   
 $Mem_{8}[800] = 3$   
 $Mem_{8}[801] = 2$   
 $Mem_{8}[802] = 10_{(16)} = 16$   
 $Mem_{8}[803] = 0$ 

## **CPU Registers & Memory**

- CPU registers (e.g. A, R0) are normally same length as memory word
- Word READ (easy):
  - ❖ A := Mem<sub>16</sub>[addr]
- Word WRITE (easy):
  - ❖ Mem<sub>16</sub>[addr] := A
- ◆ Byte READ: 8 →16?
  - **❖** A:
  - ❖ A := 00000000 Mem<sub>8</sub>[addr]
- ◆ Byte WRITE: 16 → 8?
  - $Arr Mem_8[addr] := A(7:0)$  (bottom 8 bits of A)




8 bits 8 bits
Memory



16 bits

## What are memory locations used for?

- Read-write memory (RAM) is used for data and programs. It loses its contents on power-down.
- Read-only memory (ROM) typically used to hold programs that do not change
  - \* Flash ROM allows data to be changed by programming (but not by memory write).
- Memory-mapped I/O. Some locations (addresses) in memory allow communication with peripheral devices.
  - For example, a memory write to the data register of a serial communication controller might output a byte on a serial port of a PC.
  - In practice, all I/O in modern systems is memory-mapped




## Memory addressing modes


#### Direct addressing

- ❖ A := mem[N] (N in instruction word)
- Limited memory space (by number of bits available)
- Does not allow array access (where location is selcted by number in register)
- Indirect addressing (not often used now)
  - ❖ A := mem[mem[N]]

#### Register addressing:

- ❖ A := mem[X]✓ where X is the name of a register in CPU
- Register offset addressing
  - ❖ A := mem[X + N]
  - Register indirect is special case where offset = 0





## Example of register offset addressing

- Using register indirect addressing set A equal to sum of values in memory locations from S to S+99, then stop.
- Assume X is a register. Assume register addressing added to ISA

A := 0; each value will be added to A

X := S; X points to next memory loc

#### LOOP:

A := A + mem[X]; add next value to A


X := X + 1; move down one location

if X < S+100 JMP LOOP; goto LOOP if

**STP** ; not finished

This uses register addressing. How to change to register offset addressing?

A		
X	/	/



# Advantages of register offset addressing mode over direct addressing

- Memory address size limited by register size not by bits in instruction word
  - $32 \text{ bits} = 2^{32} = 4294967296 \text{ memory addresses}$
- Array memory access is possible (memory location read or written depends on value of a variable etc)
- If register is set to constant value can use just like direct addressing
  - OK if CPU has large number of register so can set one register permanently
- Allows programs to run using data anywhere in memory
  - Set register to base of program data area
- Register used like this is often called base register

#### Lecture 4 - Introduction to ARM programming

"Steve is one of the brightest guys I've ever worked with - brilliant - but when we decided to do a microprocessor on our own, I made two great decisions - I gave them two things which National, Intel and Motorola had never given their design teams: the first was no money; the second was no people. The only way they could do it was to keep it really simple." - Hermann Hauser talking about Steve Furber and the ARM design

#### Why learn ARM?

- Currently dominant architecture for embedded systems
- ❖ 32 bits => powerful & fast
- Efficient: very low power/MIPS
- Regular instruction set with many advanced features

#### Beyond MU0 - A first look at ARM

- Complete instruction set.
   Wide variety of arithmetic,
   logical, shift & conditional
   branch instructions
- Larger address space 12bit address gives 4k byte of memory. So use a 32-bit or address bus.
  - Typical physical memory size 1Mbyte (uses 20 bits) but can be anything up to 2<sup>32</sup> bytes
- Subroutine call mechanism

   this allows writing modular programs.
- Additional internal registers

   this reduces the need for accessing external memory & speeds up calculations

- Interrupts, direct memory access (DMA), and cache memory.
  - interrupts: allow external devices (e.g. mouse, keyboard) to interrupt the current program execution
  - DMA: allows external highthroughput devices (e.g. display card) to access memory directly rather than through processor
  - Cache: a small amount of fast memory on the processor chip

#### The ARM Instruction Set

- Load-Store architecture
- Fixed-length (32-bit) instructions
- 3-operand instruction format (2 source operand regs, 1 result operand reg): ALU operations very powerful (can include shifts)
- Conditional execution of ALL instructions (v. clever idea!)
- Load-Store multiple registers in one instruction
- A single-cycle n-bit shift with ALU operation
- "Combines the best of RISC with the best of CISC"

## ARM Programmer's Model

- 16 X 32 bit registers: names r0 r15
- r15 (R15) is equal to the PC
  - Its value is the current PC value
  - Writing to it causes a branch!
- r0-r14 (R0-R14) are general purpose
  - r13, r14 have additional functions, described later
- Current Processor Status Register (CPSR)
  - Holds condition codes AKA status bits

31	29	CPSR	7	6	5	4 0	
NZ	CV	unused		F	Τ	mode	

PC:	<b>─</b>
1 0	

32 bits
r0
r1
r2
r3
r4
r5
r6
r7
r8
r9
r10
r11
r12
r13 (stack pointer)
r14 (link register)
r15

## ARM Programmer's Model (con't)

- CPSR is a special register, it cannot be read or written like other registers
  - The result of any data processing instruction can modify status bits (flags)
  - These flags are read to determine branch conditions etc
- Main status bits (AKA condition codes):
  - N (result was negative)
  - Z (result was zero)
  - C (result involved a carry-out (unsigned overflow)
  - V (result overflowed as signed number)
- Other fields described later



## ARM's memory organization

- Byte addressed memory
- Maximum 2<sup>32</sup> bytes of memory
- A word = 32-bits, half-word = 16 bits
- Words aligned on 4-byte boundaries

**-** bit 31 bit 0 20 20 16 19 16 word16 **12** half-word14 half-word12 11 10 8 8 word8 4 half-word4 byte6 0 byte3 byte2 byte1 byte0 NB - Lowest byte address = LSB of word

"Little-endian"

Word addresses follow LSB byte address

byte address

## ARM Assembly Quick Introduction

		·
MOV ra, rb	ra := rb	◆n decimal in range -128 to 127
MOV ra, #n	ra := n	
ADD ra, rb, rc	ra := rb + rc	◆SUB => - instead of +
ADD ra, rb, #n	ra := rb + n	
CMP ra, rb	set status bits on ra-rb	◆CMP is like SUB but has no destination
CMP ra, #n	set status bits on ra-n	register and sets condition codes NZCV
B label	branch to label	BL label is branch & link to subroutine
BEQ label BNE label BMI label BPL label	branch to label if zero branch if not zero branch if negative branch if zero or plus	Branch conditions apply to the result of the last instruction to set <b>status bits</b> (ADDS/SUBS/MOVS/CMP etc).
LDR ra, label STR ra, label ADR ra, label LDR ra, [rb] STR ra, [rb]	ra := mem[label] mem[label] := ra ra :=address of label ra := mem[rb] mem[rb] := ra	<pre> LDRB/STRB =&gt; byte transfer  Other address modes (see later):  [rb,#n] =&gt; mem[rb+n]  [rb,#n]! =&gt; mem[rb+n], rb := rb+n  [rb],#n =&gt; mem[rb], rb:=rb+n  [rb+ri] =&gt; mem[rb+ri] </pre>

#### Assembly Language Labels

- Programs need to reference memory addresses:
  - Memory LOAD & STORE (address of memory location)
  - Branch to a different instruction (address of destination instruction)
- In machine code addresses are just numbers
  - In assembler this is inconvenient, we want a symbolic equivalent!
- Labels are used to represent numbers in assembler


address	label	instruction	comment
00F8	START	MOV R10, #0	;R10 := 0
00FC		MOV R0, #4	;R0 := 4
0100	LOOP	ADD R10, R10, R11	;R10 := R10+R11
0104		SUB R0,R0,#1	;R0 := R0 -1
0108		CMP R0, #0	;Compare R0 with 0
010C		BEQ LOOP	;branch if R0 = 0
0110	FINISH		; finished

Symbol table				
START	&00F8			
LOOP	&0100			
FINISH	&0110			

#### MU0 to ARM translation

Operation	MU0	ARM
A := mem[S] R0 := mem[S]	LDA S	LDR RO, S
mem[S] := A mem[S] := Rn	STA S	STR RO, S
A := A + mem[S]	ADD S	LDR R1, S
R0 := R0 + mem[S]		ADD R0, R0, R1
R0 := S	n/a	MOV RO, #S
R0 := R1 + R2	n/a	ADD R0, R1, R2
PC := S	JMP S	B S





## Introduction to ARM data processing

$$a := b + c - d$$

## ARM has 16 registers R0-R15 If a,b,c,d are in registers:

a: R0

b: R1

c: R2

d: R3

#### **Machine Instructions:**

ADD Rx,Ry,Rz ; Rx := Ry + Rz

SUB Rx,Ry,Rz ;Rx := Ry - Rz

**ADD R0, R1, R2** 

**SUB R0, R0, R3** 

LOAD data to reg from memory

STORE result to memory from reg

LDR R1, LB

LDR R2, LC

LDR R3, LD

**ADD R0, R1, R2** 

**SUB R0, R0, R3** 

STR RO, LA

#### memory

LA,LB,LC,LD are labels for the addresses of 4 word memory locations

LA	а
LB	b
LC	С
LD	d

## Negative numbers: two's complement

- Real programming need to add, signed numbers which can be positive or negative
- Memory locations & registers don't do this!
- SOLUTION use two's complement signed representation
- Basic idea, use MSB to determine is number positive or negative
- The same bits now have two different meanings

Stored bits	Unsigned	2's comp signed
0011	3	3
0000	0	0
1011	11	-5

## Two's Complement in 4 bit binary word

#### bits in register or memory location

$$\begin{array}{|c|c|c|c|c|c|} \hline b_3 & b_2 & b_1 & b_0 \\ \hline \end{array}$$

#### unsigned binary

$$8b_3 + 4b_2 + 2b_1 + b_0 = u(b_i)$$

$$0 \le u \le 15$$

#### two's complement signed binary

$$-8b_3 + 4b_2 + 2b_1 + b_0 = z(b_i)$$
  $-8 \le z \le 7$ 


Computer data  $b_i$  has unsigned value  $u(b_i)$  and signed value  $z(b_i)$ 

NB definition of **z()** depends on number of bits since MSB has negative weight

b <sub>i</sub>	u(b <sub>i</sub> )	z(b <sub>i</sub> )
0000	0	0
0001	1	1
0010	2	2
0011	3	3
0100	4	4
0101	5	5
0110	6	6
0111	7	7
1000	8	-8
1001	9	-7
1010	10	-6
1011	11	-5
1100	12	-4
1101	13	-3
1110	14	-2
1111	15	-1

## Two's complement facts (1)

- Two's complement is very surprising!
- Suppose we have unsigned 4 bit addition:
- u(ci) = u(bi) + u(ai)
  - The result can be >15 so there is a carry or overflow bit c4
  - ❖ In a CPU the destination register can never hold this, because it is same width as source, so the result is always truncated (c<sub>3</sub>c<sub>2</sub>c<sub>1</sub>c<sub>0</sub>).
- z(bi)+z(ai) = u(bi)+u(ai) 16(a3+b3)
- Truncated result (c<sub>3</sub>c<sub>2</sub>c<sub>1</sub>c<sub>0</sub>) of two's complement & unsigned addition is identical
  - Use one hardware adder don't care whether numbers are signed or unsigned



Two's complement signed numbers are universally used in computers because they can be added, subtracted with the same hardware as unsigned numbers

## Two's complement facts (2)

- Assume registers are N bits wide
- Two's complement bit pattern for positive number  $(b_{N-1} = 0)$  is same as unsigned
- ♦ How do we find two's complement bit pattern b<sub>i</sub> for negative number -S?
- $b_{N-1} = 1$  (because number is negative)

-S = z(bi) = u(bi) -2<sup>N</sup>b<sub>N</sub> = u(b<sub>i</sub>) - 2<sup>N</sup>  

$$\Rightarrow$$
 u(b<sub>i</sub>) = 2<sup>N</sup> - S = 1 + [(2<sup>N-1</sup> - 1) - S]

 This makes an easy way to calculate two's complement negation of S.

1 1 1 1 
$$2^{N}-1$$
  
0 1 0 1 -  $S=5$   
1 0 1 0 +1  $(2^{N}-1)-S$   
1 0 1 1  $2^{N}-S$ 

invert bits and add 1

2's complement for -5

## Two's complement facts (3)

## Overflow $\Rightarrow$ N bit result is not the correct sum of the N bit operands

addition	overflow condition	Note
unsigned	u(a) + u(b) > 2 <sup>N</sup> - 1	Overflow is same as Nth bit of sum (carry bit) = 1
Two's complement signed	$z(a) + z(b) < -2^{N-1}$ or $z(a) + z(b) > 2^{N-1} -1$	The correct result must lie within two's complement number range

## CMP instruction & condition codes

**CMP R0, #n** 

CMP compares two numbers by calculating the difference x = R0 - n

#### \*x is truncated to 32 bits

- Sets condition codes
- Use conditional branch

after CMP				
Branch	condition CMP R0, #n		after CMP a , b	
BEQ	R0 = n	Z=1	a = b	
BNE	R0 <> n	Z=0	a ≠ b	
BMI	u(R0) < u(n)	C=0	u(a) < u(b)	
BPL	u(R0) ≥ u(n)	C=1	u(a) ≥ u(b)	

condition code	condition for 1	function
N	z(x) < 0	negative
Z	x = 0	zero
С	u(R0) ≥ n	unsigned overflow
V	$z(x) \neq z(R0) - z(n)$	signed overflow

z(x) two complement interpretation u(x) unsigned interpretation

## Carry bit (C) - hardware

◆Suppose q<sub>i</sub> is the N bit sum of a binary adder inputs a<sub>i</sub> & b<sub>i</sub>


#### Overflow $\Rightarrow$ N bit sum is wrong:

Unsigned

$$u(a_i) + u(b_i) = u(q_i) + 2^n c_n$$

- Cn = 1 is condition for unsigned overflow
- ◆In ARM architecture C<sub>n</sub> is stored in C condition code

c<sub>n</sub> is lost change from 2<sup>n</sup> to 0



MS two bits of n bit addition

## Signed overflow (V) & bit - hardware


#### Signed

$$z(a_i) + z(b_i) = z(qi) - 2^n c_n + 2^{n-1} z^* c_{n-1}$$

**Therefore signed overflow if 2^{n}(c\_{n-1} - c\_n) \neq 0** 

$$\mathbf{v} = \mathbf{c_n} \times \mathbf{c_{n-1}}$$

MS two bits of n bit addition



## Overflow (how you calculate)

- Compute: z = z(a) + z(b)
  - This is what the answer should be
- If x lies within range of two's complement there is no signed overflow
  - ❖  $2^{n-1} \le x \le 2^{n-1}$  1 ⇒ no overflow
- Note that the same is true for unsigned overflow
- Compute u = u(a) + u(b)
  - $\bullet$  0  $\leq$  u  $\leq$  2<sup>n</sup> 1  $\Rightarrow$  no overflow
- Addition does not care about signedness. Both C & V are computed. Programmer decides which is important.

## What is subtraction in binary?

- In a microprocessor
  - Subtract generates correct two's complement answer for two's complement operands.
  - ❖ Subtract = negate followed by add: a b = a + (-b)
  - ❖ Example: 4 1

two's comp negate is invert bits & add 1:

0001 => 1110 => 1111

**NB** +1 for negation is done by setting adder carry in to 1, so only one adder is needed

No overflow because 3 is correct signed result Note that carry out can be 1 (as here) or 0 when there is no signed overflow

0100

0001