






Audio




MCU



Power





Display



Actual number of LEDs is configurable by:
* shorting JP1 to JP4 to skip each of the first four pairs
* shorting JP5 to JP7 to define the total number of LEDs with a minimum of 10 and enabling the next 2, 4, or 8 pairs, respectively.

For example:
* Shorting JP1, JP2, and JP6 will skip LEDs D1..D4 and activate 14 total LEDs (D5..D18)
* Not shorting any jumpers will only activate the first 10 LEDs (D1..D10)



Sheet: /		
File: rainbow-music-pegasus.kicad_sch		
Title:		
Size: A3	Date:	Rev:
KiCad E.D.A. 10.0.3		Id: 1/1