

04

AUDIO/VIDEO DEPARTMENT

- General
- Lighting
- Stage Furniture
- Power Supply
- Audio/Video Desk
- Theme Monitors
- Program Monitors
- Sound Distribution
- System Startup
- System Shutdown
- FM Broadcast
- Communication Headsets
- System Layout
- Microphones
- Wireless Microphones
- Emergencies
- Audio/Video Desk Setup
- Auxiliary Auditorium
- Troubleshooting
- Checklists

General

Lighting

Stage Furniture
Power Supply
Audio/Video Desk
Theme Monitors
Program Monitors
Sound Distribution
System Startup
System Shutdown
FM Broadcast
Communication Headsets
System Layout
Microphones
Wireless Microphones
Emergencies
Audio/Video Desk Setup
Auxiliary Auditorium
Troubleshooting
Checklists

GENERAL

The Audio/Video Department is located at the rear of the main auditorium. Brothers who operate the audio mixer, computers, cameras, and video equipment should receive adequate training and clearly understand their role.

Monitors are provided in most departments to allow volunteers to view the program while caring for an assignment.

There are lines on the floor of the stage to show where demonstrations and interviewees may stand.

No modifications (including colour coding or labelling) should be made to the audio system without prior approval from the Assembly Hall Overseer.

Any observations as to improvement are welcomed, and these may be conveyed to the Assembly Hall Representative (AHR) who can report to the Assembly Hall Overseer (AHO). The Local Design/Construction Department (LDC) makes any final decisions in this regard.

LIGHTING

The stage lights are activated from a cabinet in the backstage area on the stage left side. This will be typically turned on by the AHR at the beginning of the day.

The locked cabinet does not need to be opened as the stage lighting is pre-set.

At the end of the day turn the large isolator switch from ON to OFF located outside the cabinet.



General

Lighting

Stage Furniture

Power Supply

Audio/Video Desk

Theme Monitors

Program Monitors

Sound Distribution

System Startup

System Shutdown

FM Broadcast

Communication Headsets

System Layout

Microphones

Wireless Microphones

Emergencies

Audio/Video Desk Setup

Auxiliary Auditorium

Troubleshooting

Checklists

STAGE FURNITURE

Adequate furniture is on hand for each event.

The event chairman would usually advise the Assembly Hall Overseer before the event if additional equipment is needed.

POWER SUPPLY

The power supply is controlled by a single switch, located at the right side of the A/V Desk. Individual pieces of equipment at the desk should not be turned on and off at their “standby power” switches.

AUDIO/VIDEO DESK

To avoid distracting the operators, only trained brothers assigned to operate the equipment should be admitted to the Audio/Video Department area.

To protect the equipment, no food or drink should be taken into this area and no foreign components, systems, leads or cords should be introduced.

THEME MONITORS

The Assembly / Convention theme is displayed on a monitor in each auditorium operated by the Assembly Hall Representative (AHR). The main auditorium’s theme monitor is wall-mounted next to the platform on the stage right side. In the auxiliary auditorium, the monitor is also mounted on the wall in the corner on the left side of the auditorium.

- General
- Lighting
- Stage Furniture
- Power Supply
- Audio/Video Desk
- Theme Monitors
- Program Monitors**
- Sound Distribution**
- System Startup
- System Shutdown
- FM Broadcast
- Communication Headsets
- System Layout
- Microphones
- Wireless Microphones
- Emergencies
- Audio/Video Desk Setup
- Auxiliary Auditorium
- Troubleshooting
- Checklists

PROGRAM MONITORS

Monitors that provide a live view of the program are available in the areas listed below. Event Oversight may determine which of these monitors are used. The monitors remain on the appropriate input at all times and may be switched on by using the remote controls, located on the A/V Desk and in the backstage A/V Cabinet. Please return remotes to these locations.

Locations of Monitors		
Backstage Waiting Areas (x3)	Baptism Waiting Area	Foyer
Chairman’s Office (Backstage)	Dining Room (x2)	First Aid
Auxiliary Auditorium (x2)	Auxiliary Chairman’s Office	Parents Room
Convention Committee Office	Audit Office	Parking Kiosk

SOUND DISTRIBUTION

Sound to Foyer

Program sound is provided via fixed speakers in the foyer, with volume levels adjustable at the Sound Console. This zone is labelled “foyer” on the mixer.

Sound to Offices & Backstage

Program sound is provided via fixed speakers backstage and in the offices throughout the AH, with volume levels adjustable at the Sound Console. This zone is labelled “All Other Areas” on the mixer. In addition to fadeable sound levels at the Sound Console, volume can individually be controlled from dials in each of the offices.

Sound to Dining Area

Program sound is available and provided via fixed speakers in the Dining Room, with volume levels adjustable at the Sound Console. This zone is labelled “Cafe” on the mixer. Event Oversight may determine whether the program should be transmitted here.

General
 Lighting
 Stage Furniture
 Power Supply
 Audio/Video Desk
 Theme Monitors
 Program Monitors
 Sound Distribution
System Startup
 System Shutdown
 FM Broadcast
 Communication Headsets
 System Layout
 Microphones
 Wireless Microphones
 Emergencies
 Audio/Video Desk Setup
 Auxiliary Auditorium
 Troubleshooting
 Checklists

SYSTEM STARTUP

Please note the following procedure to start the A/V System each day:

- Remove dust covers from all equipment
- Switch A/V Desk Main Power from 0 to 1 - see picture 1
- Power up Desktop computers
- Switch A/V Desk Main Power from 1 to 2
- Proceed to Backstage A/V cabinet
- Power up Video Processors by turning on the labelled switch - see picture 2
- Wait 30 seconds
- Power up LED screens by turning the labelled isolator switches to ON - see picture 2

Important Note: Wait 60 seconds for LED screens to fully display. If a screen is displaying improperly after 60 seconds or more, power cycle the problematic screen by switching it off at the isolator, waiting 30 seconds, and switching it back on.



General

Lighting

Stage Furniture

Power Supply

Audio/Video Desk

Theme Monitors

Program Monitors

Sound Distribution

System Startup

System Shutdown

FM Broadcast

Communication Headsets

System Layout

Microphones

Wireless Microphones

Emergencies

Audio/Video Desk Setup

Auxiliary Auditorium

Troubleshooting

Checklists

SYSTEM SHUTDOWN

Please note the following procedure to shutdown the A/V System each day:

- Power down LED screens by turning the isolator switches to OFF
- Power down Video Processors by turning off the labelled switch
- Switch A/V Desk Main Power from 2 to 1
- Shutdown HP Desktop computers
- Switch A/V Desk Main Power from 1 to 0
- Replace dust covers on all equipment

Important Note: Please do not turn power switches off on individual pieces of equipment.

FM BROADCAST

A radio broadcasting device is located in the WiFi and Radio cabinet, located in the fire/alarm panel office. This device is set up to transmit the program via FM frequency 107.7.

Typically, the AHR will operate this equipment.

COMMUNICATION HEADSETS

Six (6) “David Clark” wireless headsets are available for use by the A/V and Platform Teams.

These headsets are stored in the Backstage A/V cabinet. Battery charging stations are set up at the right side of the A/V Desk.

Please ensure batteries are placed on charge at the end of each day, and headsets are properly stored in their cases and returned to the Backstage A/V cabinet at the end of the event.

General
Lighting
Stage Furniture
Power Supply
Audio/Video Desk
Theme Monitors
Program Monitors
Sound Distribution
System Startup
System Shutdown
FM Broadcast
Communication Headsets
System Layout
Microphones
Wireless Microphones
Emergencies
Audio/Video Desk Setup
Auxiliary Auditorium
Troubleshooting
Checklists

SYSTEM LAYOUT

Six (6) microphone sockets are available on the platform. Sockets are labelled on the input box (located at front/centre of stage) and these reflect the inputs at the Sound Console. Microphone leads are permanently connected on the platform.

MICROPHONES

Five (5) wired microphones are available for use. These are stored in the Backstage A/V cabinet.

While microphone leads should remain neatly coiled up on the platform and booms in position, please return the microphones to their cases and store in the cabinet at the end of the event.

Any microphone failure or other sound problems must be referred to the overseer of the department, who will inform the AHR.

WIRELESS MICROPHONES

Four (4) wireless (or roving) microphones are available for use. They are stored, along with their respective charging docks, at each side of stage access. These microphones are identified by a coloured band around each unit which relates to a label on the Sound Console. The receivers for these microphones are located at the A/V Desk and will power on with the rest of the system.


Please return these microphones to their charging docks after use.

EMERGENCIES

If an emergency requires evacuation of the building, the Chairman may authorize the Audio/Video Department to keep the sound system alive for evacuation announcements and instructions

General
 Lighting
 Stage Furniture
 Power Supply
 Audio/Video Desk
 Theme Monitors
 Program Monitors
 Sound Distribution
 System Startup
 System Shutdown
 FM Broadcast
 Communication Headsets
 System Layout
 Microphones
 Wireless Microphones
 Emergencies
Audio/Video Desk Setup
Auxiliary Auditorium
 Troubleshooting
 Checklists

AUDIO/VIDEO DESK SETUP



AUXILIARY AUDITORIUM


The Auxiliary Auditorium includes a theme monitor and two (2) program monitors, and can be configured to be an extension of the program in the main auditorium or be used for an independent program.

Remotes for the theme monitor and two (2) program monitors are stored in the auxiliary AV Desk.

Extension of Main Auditorium

To extend the program from the main auditorium:

- Turn on power isolation switches to both “MIXER” and “MONITORS” (see picture 1)
- Select input 2 on the video input switcher (see picture 2)
- Adjust the slider labelled “Main Hall” on the mixer as desired - this will allow sound from the main auditorium to be transmitted into the Auxiliary Auditorium



General
Lighting
Stage Furniture
Power Supply
Audio/Video Desk
Theme Monitors
Program Monitors
Sound Distribution
System Startup
System Shutdown
FM Broadcast
Communication Headsets
System Layout
Microphones
Wireless Microphones
Emergencies
Audio/Video Desk Setup
Auxiliary Auditorium
Troubleshooting
Checklists

AUXILIARY AUDITORIUM


Independent Program

For an independent program in the auxiliary auditorium:

- Turn on power isolation switches to both “MIXER” and “MONITORS” (see picture 1)
- Select input 1 on the video input switcher (see picture 2)
- Use the computer connected to the auxiliary AV Desk for media playback.
- Use the auxiliary AV Desk mixer and associated sound equipment to control and adjust sound and microphone output.

Important Note: Please do not turn off individual pieces of equipment, such as the mixer or amplifier.

Use the isolation switch in picture 1 to power off the equipment. The laptop may be shutdown normally.



TROUBLESHOOTING

If the system or part of the system does not appear to be functioning or a repair is required, please contact the Assembly Hall Representative (AHR). Adjustments to the amplifiers are not permitted.

04

AUDIO/VIDEO DEPARTMENT

Please complete the tasks list below

START OF THE EVENT (AUDIO)

- ☐ Remove dust covers on desk equipment
- ☐ Power up AV Desk as per “System Startup”
- ☐ Power up big screens as per “System Startup”
- ☐ Turn on monitors throughout AH as directed by Event Oversight
- ☐ Test sound and video equipment

FINAL CHECKLIST

- ☐ Audio/video desk is left neat and tidy
- ☐ Replace dust covers on desk equipment
- ☐ Make sure all other audio equipment and TVs are switched off
- ☐ Ensure the AV systems have been turned off in auxiliary auditorium
- ☐ Power down AV Desk as per “Shutdown Procedure”
- ☐ Power down big screens as per “Shutdown Procedure”
- ☐ Remove all schedules, outlines etc
- ☐ Remove batteries from headsets, place on charge, and return headsets to cases
- ☐ Store headsets in Backstage AV cabinet
- ☐ All personal belongings removed
- ☐ Note any potential problems that may need attention prior to the next event and advise Event Oversight. Please specify the exact location and nature of the problem eg which headset, screen or other equipment needs attention.
- ☐ Return this checklist to Event Oversight

04

AUDIO/VIDEO DEPARTMENT

Please complete the tasks list below

START OF THE EVENT (AUDIO)

- ☐ Remove dust covers on desk equipment
- ☐ Power up AV Desk as per “System Startup”
- ☐ Power up big screens as per “System Startup”
- ☐ Turn on monitors throughout AH as directed by Event Oversight
- ☐ Test sound and video equipment

FINAL CHECKLIST

- ☐ Audio/video desk is left neat and tidy
- ☐ Replace dust covers on desk equipment
- ☐ Make sure all other audio equipment and TVs are switched off
- ☐ Ensure the AV systems have been turned off in auxiliary auditorium
- ☐ Power down AV Desk as per “Shutdown Procedure”
- ☐ Power down big screens as per “Shutdown Procedure”
- ☐ Remove all schedules, outlines etc
- ☐ Remove batteries from headsets, place on charge, and return headsets to cases
- ☐ Store headsets in Backstage AV cabinet
- ☐ All personal belongings removed
- ☐ Note any potential problems that may need attention prior to the next event and advise Event Oversight. Please specify the exact location and nature of the problem eg which headset, screen or other equipment needs attention.
- ☐ Return this checklist to Event Oversight

04

PLATFORM DEPARTMENT

Please complete the tasks list below

START OF THE EVENT (PLATFORM)

- ☐ Arrange stage furniture as required for the event
- ☐ Connect microphones to booms (Chairman and Speaker)

FINAL CHECKLIST

- ☐ Tidy stage and backstage areas
- ☐ Neatly coil leads and leave them plugged in on the platform
- ☐ Return microphones to protective cases and store in Backstage AV cabinet
- ☐ Return wireless microphones to charging stations
- ☐ Return stage furniture to original locations, with speaker's lectern in centre stage
- ☐ Interview tables and chairs to be left tidy backstage
- ☐ Remove all redundant paperwork – including from the noticeboard
- ☐ Ensure that the backstage waiting areas are tidy and well presented
- ☐ All personal belongings removed
- ☐ Ensure that all platform and backstage lighting is turned off
- ☐ Make sure all other audio equipment and TVs are switched off
- ☐ Return this checklist to event oversight