


Stare Podłączenie



Zasilacz

GND	5V	5V
SCL	SDA	3V3

DRV8833



STM32L476RG






Jetson Nano


Zasilacz



DRV8833



2 Prawy Sil/Enk



1 lewy Sil/Enk

STM32L476RG

Jetson Nano

3.3V	1	5.0V
I2C1_SDA	3	5.0V
I2C1_SCL	5	GND
GPIO09	7	UART1_TXD
GND	9	UART1_RXD
UART1_RTS*	11	I2S0_SCLK
SP1_SCK	13	GND
GPIO12	15	SP1_CS1*
3.3V	17	SP1_CS0*
SP10_MOSI	19	GND
SP10_MISO	21	SP1_MISO
SP10_SCK	23	SP10_CS0*
GND	25	SP10_CS1*
I2C0_SDA	27	I2C0_SCL
GPIO01	29	GND
GPIO11	31	GPIO07
GPIO13	33	GND
I2S0_FS	35	UART1_CTS*
SP11_MOSI	37	I2S0_DIN
GND	39	I2S0_DOUT