



ADLM STUDIO · USER GUIDE

ADLM Cloud: valuations and contract administration user guide

Value the work done, issue interim payment certificates, and run variations and the contract lock.

Version 2026.09

Runs on Web, any browser (adlmstudio.net)

Updated 1 October 2026

adlmstudio.net/guides

Contents

Valuations and the contract

Valuation

Contract administration

Troubleshooting

I forgot the contract PIN

Frequently asked questions

What happens when I lock the contract?

Where do I get help?

ADLM Cloud: valuations and contract administration

Value the work done, issue interim payment certificates, and run variations and the contract lock.

This is one part of the [ADLM Cloud guide](#). It covers the workspace as it is on the live site at the start of October 2026.

Valuations and the contract

Valuation

The Valuation view is where you value work done and run the contract.

Recording progress. Progress is recorded on the Bill of Quantity:

1. Tick a line's box to mark it fully done (**Mark as completed**), or type a percentage in its **Done** box. Partial values are paid pro rata.
2. Click **Save changes**. Each save is logged against that day in the daily valuation log.

Valuation workspace. At the top of the Valuation view:

- **Valuation basis:** choose **By Bill of Quantity** (each line valued by its own % complete) or **By Budget (Material & Labour)** (each line valued from its material and labour lines marked on the Budget).
- **Show daily valuation log** and **Show valuation settings** turn those sections on and off.

Valuation settings. These are saved per project:

Setting	Default	What it does
Client / Employer	blank	The client's name on the valuation and exported bill
Retention %	5	Held back from the gross value
VAT %	7.5	Added to the subtotal
Withholding tax %	2.5	Deducted from the subtotal

Set these once, when the contract is agreed, so every later valuation is worked out the same way.

The daily valuation log.

1. Choose a day in **Valuation date**.
2. Read down the figures: **Gross value of works to date**, **Net valuation to date** (after retention), **Less previous payments** ("Not applicable for first valuation" on the first one), **Subtotal before taxes**, and **Total amount due for payment**.
3. Click **Print valuation** for the formal Interim Payment Application, or **Export Excel** for an editable workbook.

Contract administration

Below the valuation is **Contract administration**, with four views: **Certificates**, **Variations**, **Final account** and **BIM models**.

Locking the contract. Locking freezes the priced bill as the contract sum. After that, new items become variations and re-measured quantities are recorded as actuals, so the contract figure never moves.

1. Open the **Bill of Quantity** and click the **Contract** tab on the ribbon.
2. Click **Lock contract**.
3. Choose a 4-digit PIN and type it twice. If your account uses email verification for sensitive actions, you enter the code sent to your email instead.

IMPORTANT

Keep the PIN safe. You need the same 4 digits to unlock the contract, and a lost PIN cannot be recovered without asking ADLM support.

To unlock, click **Unlock** on the same tab and enter the PIN (or the emailed code).

Interim certificates.

1. Open **Certificates**.
2. Click **Issue certificate**. It certifies the current value to date as the next IPC.
3. Set each certificate's status as it moves along: **Draft**, **Approved**, **Paid**.
4. Download any certificate as an Excel workbook.

Each certificate row shows **Cumulative**, **Less prev.**, **This cert**, **Retention**, VAT, withholding tax and **Net payable**. Only the latest certificate can be deleted, which keeps the sequence honest.

TIP

Lock the contract before the first certificate, so every certificate is measured against the same baseline.

Variations.

1. Open **Variations** and click **Add variation**.
2. Fill in **What changed**, the **Instruction reference**, the **Type** (**Addition** or **Omission**) and the **Value (N)**.
3. A new variation waits for approval and is not counted yet. Open it and click **Approve** or **Reject**.

Only approved variations move the project total. The tiles show **Approved**, **net**, **Additions**, **Omissions** and **Waiting for approval**. Lines added to a locked contract from the plugin are raised as variations for you.

Final account. This shows the closing settlement: **Measured work**, **Preliminaries**, **Provisional and PC sums**, contingency and **Approved variations**, set against the **Contract sum**, with **Certified so far**. The movement reads as an over-run, **Under-run (savings)** or **On budget**.

1. When the job is finished, click **Close the final account**. The contract must be locked first.
2. Confirm. Items, variations and certificates are frozen.
3. Click **Download** for the final account workbook.

To make an adjustment later, click **Reopen**. No new certificate can be issued while the final account is closed.

BIM models (QUIV, Revit MEP and CIVIQ projects). When you save from QUIV, the model is exported to IFC and attached to the project automatically, one slot each for **Architectural**, **Structural** and MEP. Each slot shows whether it is **Attached** and whether its element IDs match the bill. If the model does not cover the bill, the missing element IDs are listed.

If the plugin was not used, click **Advanced: manual upload** and then **Upload manually** (or **Replace manually**) to attach an IFC file yourself. Files can be up to 100 MB.

Troubleshooting

I forgot the contract PIN

The PIN cannot be recovered on the website. Contact ADLM support from **Support** (</manage/support>) to have it reset.

Frequently asked questions

What happens when I lock the contract?

The priced bill becomes the contract sum and stops moving. New items become variations, re-measured quantities are recorded as actuals, and certificates are measured against the locked figure. HERON shows the lock too and saves your edits as actuals.

Where do I get help?

Ask Ada, chat with us on WhatsApp, or raise a ticket from **Support** (</manage/support>).



Read the latest version of this guide at adlmstudio.net/guides.

Need help? adlmstudio.net/support

ADLM Studio Ltd · RC 7440343