


## Operation Instruction for PowerGPS




If the problem shown in the figure occurs when using Power GPS tool, you need to set the decimal separator of your PC.




Please follow the steps as below:

1. Check your Region and Language from Control Panel.





2. Click additional settings.



3. Check the default setting of decimal symbol, if it is not ".", please change it to ".", then you can run the tool smoothly.

