

```
int potPin = A0;

int greenLED = 9;
int yellowLED = 10;
int redLED = 11;

void setup()
{
    pinMode(greenLED, OUTPUT);
    pinMode(yellowLED, OUTPUT);
    pinMode(redLED, OUTPUT);
    Serial.begin(9600);
}

void loop()
{
    int potValue = analogRead(potPin);
    if (potValue <= 340)
    {
        int brightness = map(potValue, 0, 340, 0, 255);

        analogWrite(greenLED, brightness);
        analogWrite(yellowLED, 0);
        analogWrite(redLED, 0);

        Serial.print("Potentiometer: ");
        Serial.print(potValue);
        Serial.println(" Green ON");
    }
}
```

```
else if (potValue <= 680) {

    int brightness = map(potValue, 341, 680, 0, 255);

    analogWrite(greenLED, 0);
    analogWrite(yellowLED, brightness);
    analogWrite(redLED, 0);

    Serial.print("Potentiometer: ");
    Serial.print(potValue);
    Serial.println(" Yellow ON");

}

else {

    int brightness = map(potValue, 681, 1023, 0, 255);

    analogWrite(greenLED, 0);
    analogWrite(yellowLED, 0);
    analogWrite(redLED, brightness);

    Serial.print("Potentiometer: ");
    Serial.print(potValue);
    Serial.println(" Red ON");
}

delay(1000);
}
```

Brilliant KrunK-Bigery

Circuits Schematic Components

Simulator time: 00:00:44

Code Stop Simulation Send To

1 (Arduino Uno R3)

```
34 analogWrite(yellowLED, brightness);
35 analogWrite(redLED, 0);
36
37 Serial.print("Potentiometer: ");
38 Serial.print(potValue);
39 Serial.println(" Yellow ON");
40
41 }
42
43 else {
44
45   int brightness = map(potValue, 681, 1023, 0, 255);
46   analogWrite(greenLED, 0);
47   analogWrite(yellowLED, 0);
48   analogWrite(redLED, brightness);
49
50   Serial.print("Potentiometer: ");
51   Serial.print(potValue);
52   Serial.println(" Red ON");
53 }
54
55 delay(1000);
56
57 }
```

Serial Monitor

Potentiometer: 266 Green ON
Potentiometer: 266 Green ON
Potentiometer: 266 Green ON
Potentiometer: 266 Green ON
Potentiometer: 266 Green ON
Potentiometer: 266 Green ON