

Module 1: Work Order Management

Tab 4: Municipal Permits (Balady) (v2.0)

Version: 2.0

Date: November 26, 2025

1. Purpose

This tab is the central hub for managing all municipal excavation permits required for a Work Order, which are processed through the official Balady platform (<https://ssoapp.balady.gov.sa>). It is designed to streamline the permit application process by leveraging existing data from other tabs, track the lifecycle of each permit, and provide critical alerts to prevent costly penalties.

Since a single Work Order can require multiple permits, this tab will be structured to manage a list of permits, each with its own detailed information and status.

2. Main View: Permit List

When the user clicks on the "Municipal Permits" tab, the main view will be a table listing all permits associated with the current Work Order.

- **Add New Permit Button:** A button at the top of the table to create a new permit entry.
- **Table Structure:** Each row represents a single permit.

Column Header	Data Source	Notes
Permit Number	<u>permits.permit_number</u>	The official number from the Balady platform.
Permit Type	<u>permits.permit_type</u>	e.g., Emergency Excavation, Individual Building.
Status	<u>permits.status</u>	Color-coded: Draft, Submitted, Approved, Paid, Active, Expired, Closed.
Work Start Date	<u>permits.start_date</u>	The date the permit becomes active.
Work End Date	<u>permits.end_date</u>	The date the permit expires.

Column Header	Data Source	Notes
Days Remaining	Calculated Field	A countdown of days until the end date. Shows a warning icon if expired. The background color of this cell will change based on urgency (Green > 7 days, Yellow 1-7 days, Red <= 0 days).

- **Actions:** Clicking on a row will open the detailed view for that specific permit.

3. Detail View: Permit Information

This view contains all the information for a single permit, organized into logical sections.

3.1. Section 1: General Information

This section contains a mix of pre-populated data from other tabs and new information entered during the permit application process.

Pre-populated Fields (Read-Only):

Field Name (English)	Data Source	Field Name (Arabic)
Contract Number	<u>work_orders.work_order_number</u>	رقم العقد
Project Name	<u>work_orders.project_name</u>	اسم المشروع
Main Contractor	<u>work_orders.main_contractor</u>	المقاول الرئيسي
Project Manager	<u>work_orders.project_manager</u>	مدير المشروع
Main Consultant	<u>work_orders.consultant</u>	الاستشاري الرئيسي
Consultant Project Manager	<u>work_orders.consultant_pm</u>	مدير المشروع (الاستشاري)
Governorate / Region	<u>work_orders.governorate</u>	المحافظة / المنطقة
Municipality	<u>work_orders.municipality</u>	البلدية
Sub-municipality	<u>work_orders.sub_municipality</u>	البلدية الفرعية

Field Name (English)	Data Source	Field Name (Arabic)
Districts	<u>work_orders.districts</u>	الأحياء

New Permit Fields (Input):

Field Name (English)	Data Type	Notes	Field Name (Arabic)
Permit Number	Text	The official number from Balady.	رقم التصريح
Initial Approval Number	Text	If applicable.	رقم الموافقة المبدئية
Version Number	Text		رقم النسخة
Issue Date	Date		تاريخ الإصدار
Work Start Date	DateTime		تاريخ بدء العمل
Work End Date	DateTime	Crucial for alerts.	تاريخ انتهاء العمل
Equipment Entry Date	DateTime		تاريخ إدخال المعدات
Nature of Work	Text		طبيعة العمل
Service Type	Text		نوع الخدمة
Excavation Method	Text		طريقة الحفر
SADAD Number	Text	Crucial for payment.	رقم سداد

3.2. Section 2: Excavation Details (Read-Only)

This section displays the excavation path details autopopulated from the **Site Survey** tab to aid in filling out the Balady application.

Column Header	Data Source	Field Name (Arabic)
Line	<u>site_survey.excavation_details.line</u>	المسار
Length (m)	<u>site_survey.excavation_details.length</u>	الطول
Width (m)	<u>site_survey.excavation_details.width</u>	العرض
Depth (m)	<u>site_survey.excavation_details.depth</u>	العمق
Road Type	<u>site_survey.excavation_details.road_type</u>	نوع المسار

3.3. Section 3: Status and Alerts

This section provides a clear, visual representation of the permit's status and critical deadlines.

- **Permit Status:** A dropdown field to manually set the permit's current status (Draft, Submitted, Approved, Paid, Active, Expired, Closed).
- **Expiration Alert:** A prominent visual indicator (e.g., a banner or a large countdown timer) that clearly shows the number of days remaining until the Work End Date. The color should change as the date gets closer:
 - **Green:** > 7 days remaining
 - **Yellow:** 1-7 days remaining
 - **Red:** Expired (0 or fewer days remaining)
- **Extend Permit Button:** A button that, when clicked, could trigger a notification or workflow to remind the responsible person to apply for an extension on the Balady platform.

3.4. Section 4: Documents

- **Upload Permit PDF Button:** Allows the user to upload the final, official permit PDF downloaded from the Balady platform.
- **Document Viewer:** An embedded PDF viewer to display the uploaded permit.

4. Workflow and Integration

- 1 **Data Flow:** When a user creates a new permit in this tab, the system automatically populates the read-only fields from the Work Order Information and Site Survey tabs.
- 2 **SADAD Payment:** Once the SADAD Number is entered, the system should trigger a notification or task for the finance department, providing them with the Work Order Number and the SADAD Number for payment.

- 3 **Dashboard Status:** The status of the permits in this tab directly drives the **Permit Start** and **Permit Close** columns on the main Work Order Dashboard.
- **Permit Start:** This column on the dashboard turns **Green** if at least one permit for the Work Order has a status of Active.
 - **Permit Close:** This column on the dashboard turns **Green** only when **all** permits for the Work Order have a status of Closed.

End of Document