Lecture notes: Robot Interaction with the Environment

Jie Fu

Department of Electrical and Computer Engineering Robotics Engineering Program Worcester Polytechnic Institute

RBE502, 2018



Part of the lecture notes are from Prof. Alessandro De Luca's lecture in force control. http://www.diag.uniromal.it/~deluca/rob2_en/15_ImpedanceControl.pdf

- imposes a desired dynamic behavior, specified through a generalized dynamic impedance, namely a complete set of mass-spring-damper equations.
- a model describing how reaction forces are generated is not explicitly required.
- suited for tasks in which contact forces should be "small" and no need to modulate the force.
- the choice of a specific stiffness in the impedance model along a Cartesian direction results in a trade-off between contact forces and position accuracy in that direction.

Cartesian dynamics

When system is in contact, the environment introduces a **generalized** Cartesian force F.

$$M(q)\ddot{q}+C(q,\dot{q})\dot{q}+N(q)=\tau+J^{T}(q)F.$$

where J(q) is the geometric jacobian of the robot manipulator.

The force
$$F = \begin{bmatrix} \gamma \\ \mu \end{bmatrix}$$
 performs work on $v = \begin{bmatrix} \dot{p} \\ \omega \end{bmatrix} = \underline{J(q)\dot{q}}$.

$$\dot{x} = J_a(q)\dot{q}$$

$$J_{a}(1)\hat{i} \Rightarrow J_{a}(b)\vec{J} =$$



Dynamic model in Cartesian coordinates

$$M(9)\ddot{9} + C\dot{9} + N = T + J_{\alpha}^{T} J_{\alpha}^{T} F = T + J_{\alpha}^{T} F_{\alpha}$$

For generalized force performing work on \dot{z}
 $\dot{x} = J_{\alpha}\dot{9}$
 $\ddot{x} = J_{\alpha}\dot{9} + J_{\alpha}\dot{9} \Rightarrow \ddot{9} = J_{\alpha}^{T}(9)(\ddot{x} - J_{\alpha}\dot{9})$
 $= J_{\alpha}^{T}(9)(\ddot{x} - J_{\alpha}J_{\alpha}^{T}\dot{x})$

$$M_{x}(9) \ddot{x} + C_{x}(9,9) \dot{x} + N_{x}(1) = J_{a}^{-7} \tau + F_{a}$$

$$M_{x}(9) = J_{a}^{-7}(9) M(9) J_{a}^{-7}(9)$$

$$C_{x} = J_{a}^{-7}(9) C J_{a}^{-7} - M_{x}(1) J_{a}^{-7} J_{a}^{-7}$$

$$N_{x} = J_{a}^{-7}(9) N(9)$$

Properties of the dynamic model in Cartesian coordinates

- $M_X(q) > 0$
- $\dot{M}_X(q) 2C_X(q,\dot{q})$ is skew symmetric.
- The Cartesian dynamic model of the robot is linearly parameterized in terms of a set of dynamic coefficients.

Impedence control design

Mx
$$\ddot{X}$$
 + G \ddot{X} + D X = D T + D introduce D T end back linearization: \ddot{X} = D D T = D D T = D =

Impose a desired dynamic impedance model:

| Kd | Fa | Md, Kd, Bd & 6x6 matrices. |
| Bd | inertia soffnes damping. × 6 R 6 $Md(\ddot{x}-\ddot{x}_d) + Bd(\dot{x}-\dot{x}_d) + Kd(x-x_d) = Fa$

ax

To satisfy the desired impedance.

To satisty the degired impedance.
$$T = \int_{a}^{T} (\hat{x}) \left[M_{X} \left(M_{d}^{T} \left[F_{a} - B_{d} \left(\dot{x} - \dot{X}_{d} \right) - K_{d} \left(x - X_{d} \right) \right] + \ddot{X}_{d} \right) + C_{X} \dot{x} + N_{X} - F_{a} \right]$$

X=Na [Fa- Bux- xd) - Ka(x xd)] + Xd = ax

Examples

 x_d is often **slightly inside the environment** to maintain contact.



 x_d is often the rest position in a human-robot interaction task.

https://youtu.be/3lqVuNXHdkk

Control law in joint coordinates

$$\tau = M(q)J_a^{-1}(q)\{\ddot{x}_d - \dot{J}_a(q)\dot{q} + M_d^{-1}[B_d(\dot{x}_d - \dot{x}) + K_d(x_d - x)] + C(q, \dot{q})\dot{q} + N(q) + J_a^T[M_x(q)M_d^{-1} - I]F_a\}$$
(1)

while the principle of control design is based on dynamic analysis and desired (impedance) behavior as described in the **Cartesian space**, the final control implementation is always made at **robot joint level**.

When to use impedence control

- there is uncertainty in geometric characteristics (position, orientation) of the environment
- adapt/match to the dynamic characteristics (in particular, stiffness) of the environment, in a complementary way.
- mimic the behavior of human arm. fast and stiff in the free motion direction, and compliant and slow in "safe guard" motion.
- Require force feedback in the general form.

parameter selection:


- large $M_{d,i}$ and small $K_{d,i}$ in Cartesian directions where contact is foreseen (low contact forces).
- large $K_{d,i}$ and small $M_{d,i}$ in Cartesian directions where motion is free to keep tracking performance good.
- the damping coefficients $B_{d,i}$ are used to shape transient behaviors.



Mimic human arm



Human arm behavior



in selected directions:

the stiffer is the environment, the softer is the chosen model stiffness $\mathbf{K}_{\text{m,i}}$

Simplication -1

When choose the apparent inertia M_d equal to the natural Cartesian inertia of the robot M_x . note that $M_d = M_x = J_a^{-T} M J_a^{-1}$

$$\tau = M(q)J_a^{-1}(q)\{\ddot{x}_d - \dot{J}_a(q)\dot{q} + M_d^{-1}[B_d(\dot{x}_d - \dot{x}) + K_d(x_d - x)]\} + C(q, \dot{q})\dot{q} + N(q) + J_a^T[M_x(q)M_d^{-1} - I]F_a \quad (2)$$

becomes

$$T = M J_a^{-1} \left[\ddot{X}_d - \dot{J}_a \dot{q} \right] + J_a^{-1} \left[B_d \left(\dot{X}_d - \dot{X}_d \right) + K_d \left(\dot{X}_d - \dot{X}_d \right) \right] + C \dot{q} + N$$

No need for force sensor.

Simplication -2

if the impedance model (now, nonlinear) is still supposed to represent a real mechanical system, then in correspondence to a desired non-constant inertia (((q)) there should be Coriolis and centrifugal terms.

$$M_d = N_x(Q)
M_d(\ddot{x} - \ddot{x}_d) + (C_x(q, \dot{q}) + B_d)(\dot{x} - \dot{x}_d) + K_d(x - x_d) = F_a$$

the new controller becomes

$$T = M \int_{a}^{+} \ddot{x}_{d} + \int_{a}^{+} C_{x} \dot{x}_{d} + N(2) + \int_{a}^{+} \left[B_{d} (\dot{x}_{d} \dot{x}) + k_{d} (x_{d} - x) \right]$$

$$\text{for set point tracking:} \quad x_{d} = const. \quad \ddot{x}_{d} = \dot{x}_{d} = 0$$

$$T = N(2) + \int_{a}^{+} \left[B_{d} (-\dot{x}) - k_{d} (x_{d} - x) \right]$$


Cartesian regulation control

When x_d is constant and $F_a = 0$ (no contact) the controller is A.5. for set point tracking.

PD + Gravity componentian.

Cartesian stiffness control

Assume:
$$Fa = Ke(xe-x)$$



When x_d is constant and $F_a \neq 0$: Convergence to x_d is not guaranteed. closed-loop system behavior

$$V = \frac{1}{2} \dot{X}^{T} M_{x} \dot{X} + \frac{1}{2} (X_{d} - X)^{T} k_{d} (X_{d} - X) + \frac{1}{2} (X_{e} + X)^{T} k_{e} (X_{e} + X)$$

$$\dot{V} = \dot{X}^{T} M_{x} \ddot{X} + \frac{1}{2} \dot{X}^{T} \dot{M}_{x} \dot{X} - \dot{X}^{T} k_{d} (X_{d} - X) - \dot{X}^{T} k_{e} (X_{e} - X)$$

$$M_{x} \ddot{X} + (C_{x} + B_{d}) \dot{X} + k_{d} (X - X_{d}) = F_{a} \qquad (\ddot{X}_{d} - \dot{X}_{d} - 0)$$

$$\dot{V} = -\dot{X}^{T} B_{d} \dot{X} \leq 0$$

$$\dot{X} = 0 = \ddot{X} \qquad \text{invariant}.$$

$$\sqrt{\frac{1}{2}(X_d-X)^T} kd(X_d-X)$$

Substitute into impedance model:

$$\underbrace{M\overset{\dot{}}{x}}_{x}^{\dot{}} + \underbrace{(C_{x} + b_{d})\overset{\dot{}}{x} + k_{d}(x - x_{d})}_{XE} = \underbrace{ke(x_{e} - x)}_{XE}$$

$$X_{\overline{k}} = (K_d + K_e)^{-1} (K_d \times d + K_e \times e)$$