



User Guide

Table of Contents


Get to Know Your Yealink Cordless Phone	2
Calling Options	2
Dial Phone Numbers or Extensions	2
Answer Calls	
Hold Calls	2
Transfer Calls	2
Transfer Call to an Extension or Other Number	2
Transfer Call Directly to Voicemail	2
Conference Calling	3
To Conduct a Conference Call	3
Muting a Call	3
Do Not Disturb	3

Changing Volume	3
Directory	3
Group Call Park	3
Unpark	
Quick Dial Guide	3
Easy Dialing Options	
Voice Messaging Main Menu	4
"Play Message" options	4
Voicemail	4
Accessing Voicemail	4

User Guide



Get to Know Your Yealink Cordless Phone



Signal strength

ا Voicemail

Battery status

Call features

✓ Missed call

Settings

Do not disturb

Call history

Call forward

Power hold on/off

i Status

Calling Options

Dial Phone Numbers or Extensions

Enter the desired number when the handset is idle.

- Local and Long distance dial the 10-digit phone number (area code + local number)
- International dial 011 + country code + city code + number
- · Internal extension dial the extension

Answer Calls

- To answer a call, press the *Accept* soft key or press 🕝
- Other options are to press Speakerphone button
 or press (ox)
- To answer a new call while on an active call, press down arrow ▼ to navigate to new call and then press the Accept soft key (the current call will be held)

Hold Calls

- Place a call on hold by pressing the Options soft key, and then select Hold. The held party will hear music/ message while holding
- To resume a held call, press the Resume soft key

Transfer Calls

Transfer Call to an Extension or Other Number

- During a live call, press Options, then Transfer and dial the ext/number
- When you hear the ring back sound, or after you have talked with the other party, press *Transfer* and hang up



If you press *Transfer* or hang up directly after hearing the ring back sound, the call will automatically transfer without having to announce the caller.

Transfer Call Directly to Voicemail

- During a live call, press Options, then Transfer and dial *55 followed by the ext/number
- 2. Press Transfer again



User Guide

Conference Calling

To Conduct a Conference Call

- Call the first party. After party answers, press Options, then Conference
- Dial the extension or phone for the second party and press Conf. When party answers, press Conf again; all three parties are joined together in conference

Muting a Call

- To mute an active call, press №. The call is muted and the № icon is displayed on the LCD screen.

Do Not Disturb

- To enable do not disturb, press . Select Call Features > Do Not Disturb > (**) > Enabled > Save.
 The icon on the status bar indicates that DND mode is activated and any incoming calls will be directed to voicemail
- To disable do not disturb, press (ox). Select Call Features > Do Not Disturb > (ox) > Disabled > Save.

Changing Volume

- To change the ringer volume, press

 or

 when the phone is idle or ringing

Directory

To access the directory, press (a) and then navigate to the directory icon. Select Network Directory > All Contacts > (a). Navigate to and highlight the desired contact. Press the dial button and (a) to call the highlighted contact

Group Call Park

 While on an active call, press Options and then navigate down ▼ to Group Call Park. Press (x). Listen to the message which identifies the extension the call is parked on

Unpark

 To unpark a call, dial *88 followed by the park extension and then press the Call button or #

Quick Dial Guide

Easy Dialing Options		
	On	Off
Call forward		
All calls	*72	*73
All calls to voicemail	* 21	# 21
When no answer to voicemail	* 41	# 41
Not reachable (For business continuity plan. Requires set-up)	* 94	* 95
Check not reachable status	* 63 *	
Call return (last inbound number)	* 69	
Call waiting	*73	# 41
Cancel call waiting for a single call		*70
Access voicemail	* 86	
Music on hold deactivation (Per-call deactivation)	* 60	(Music returns next call
Clear message waiting indicator	* 99	
Change number of rings before voicemail picks up	* 610	

Yealink-W76P-220525-UG



User Guide

Voicemail

Accessing Voicemail

- 1. Press and hold the 1 button or dial *86
- 2. Follow prompts to play messages, record greetings, etc.

Voice Messaging Main Menu

1	Listen to Messages
2	Busy Greeting Menu
3	No Answer Greeting Menu
4	Extended Away Greeting Menu
5	Compose Message Menu
7	Delete All Messages
8	Message Deposit Settings Menu
*	Voice Portal Main Menu
#	Repeat Menu

While listening to message		Betv	ween messages
1	Skip Back	#	Save
2	Pause/Resume	7	Delete
3	Skip Forward	2	Repeat
4	Jump to Beginning	5	Envelope Info
6	Jump to End	6	Play Next Message
Any time		8	Callback Caller
*	Return to Previous Menu	9	Additional Options 1 Reply to Message 2 Forward Message * Return to Previous Menu # Repeat