

MUS370

Sound Recording Practice

Contents

1 Literature				1	
2	Sound Recording theory and practice 2.1 Early Recording			3	
3	Sound Recording Practice 5				
	3.1	Cable		5	
		3.1.1	•	5	
		3.1.2	Balanced cable	5	
	3.2	_	phones	5	
		3.2.1	Dynamic (moving coil) Mics	5	
		3.2.2	Condenser (capacitor) Mics	6	
		3.2.3	Ribbon	6	
		$3.2.4 \\ 3.2.5$	Frequency Response	7	
		3.2.6	Polar Patterns	7 9	
	3.3		ring a spatial image	_	
	0.0	3.3.1	Spatial encoding		
		3.3.2	Stereo capture techniques		
		3.3.3	Ambisonics		
		3.3.4	The Shotgun Microphone		
		3.3.5	Pressure Gradient Mics		
	2 /	Surrou	and Sound	1/	

iv CONTENTS

Chapter 1

Literature

- (Rumsey, 2006)
- (Bartlett, 2013)
- \bullet (Borwick, 1996)
- (Ballora, 2002)
- (Bartlett and Bartlett, 1999)
- (Bartlett, 1991)
- (Howard and Angus, 2009)
- (Huber, 2009)
- $\bullet~({\rm Katz~and~Katz},\,2007)$
- (Ballou, 2013)

Chapter 2

Sound Recording theory and practice

2.1 Early Recording

For examples of early recording see the BBC archives

- 2.2 Multi-channel
- 2.3 Analog versus Digital

Chapter 3

Sound Recording Practice

3.1 Cable

3.1.1 Unbalanced cable

An unbalanced audio cdable has two conductors. One carries the audio signal and the other is the shield/ground.

3.1.2 Balanced cable

Balanced audio requires XLR or TRS connectors with three cables (hot pin 2, cold pin3 and earth 1) As microphones operate at low voltage levels, it is possible to induce noise in the cable. Balancing a cable gets rid of this noise. A typical balanced cable contains two identical wires, which are twisted together and then wrapped with a third conductor that acts as a shield. One wire is in phase with respect to the source signal, the other wire is reversed in polarity, which is also referred to as being 180 out of phase at all frequencies. The in-phase wire is called non-inverting, positive or "hot" while the out-of-phase wire is called inverting, phase-inverted, anti-phase, negative or "cold". You have one signal in phase and one out of phase. Since the amplifier at the far end measures the difference in voltage between the two signal lines, noise induced (the same on both signals) is rejected.

Therefore your signal voltage is doubled. (Because each wire essentially acts as the reference voltage for the other, with this 'equal and opposite' signal format the differential input stage sees a signal which is twice the size of either signal individually: and this gives rise to the often talked about 6dB level hike it produces when compared to connecting the balanced output to an unbalanced destination.)

The theory is based on the Wheatstone Bridge.

3.2 Microphones

Microphones convert sound energy to a changing electric current (a signal). Main classes of microphones:

3.2.1 Dynamic (moving coil) Mics

- Low sensitivity because a lot of sound energy is required to move the heavy coil.
- Usually a very uneven frequency response.
- Durable suited to live sound re-enforcement or recording of very loud instruments.
- Cheap




Figure 3.1: Moving coil microphone

3.2.2 Condenser (capacitor) Mics

- High sensitivity
- Usually a flatter frequency response
- Delicate and expensive damaged very easily so often avoided for live sound re-enforcement.
- Back Electret cheaper and usually lower quality then condenser




Figure 3.2: Condenser microphone

In a typical condenser mic the diaphragm is a very thin circular plate of metal that is free to move. Directly behind the moving plate is a second plate that is fixed. As the moving plate moves due to changes in sound pressure the distance between the plates changes. The two plates form a capacitor (an electronic component that stores charge) and some electronics in the mic turn changing capacitance into changing current (a signal). The electronics needed by the mic require a small amount of power. This is usually provided by phantom power from the preamp (+48v) but can sometimes be a battery in the mic.

3.2.3 Ribbon

- High sensitivity
- Usually a flatter frequency response
- Very expensive and vintage technology.
- very delicate

3.2. MICROPHONES 7




Figure 3.3: Ribbon microphone

Ribbon mics are very expensive and not that commonly seen but they are usually used when you need a very sensitive pickup. Acoustic instruments etc.

3.2.4 Frequency Response

Microphones and speakers respond differently to specific frequencies. This response can be shown in a graph of level over frequency. Sometimes we are interested in a 'flat' frequency response. (the unit responds equally to as many frequencies as possible) Studio loudspeakers almost always aim for the flattest frequency response. Generally this is desirable in a mic as well. Sometimes we are interested in a characteristic frequency response. (the unit colours the sound by emphasizing or filtering certain frequencies) Dynamic mics often colour the sound, certain vocal mics aim to produce 'warmer' tones. These mics offer creative possibilities.

3.2.5 Polar Patterns

Microphones have an associated polar pickup pattern. In reality this is frequency dependent (see below) but it is usually generalized into the following:

Omni-directional (equal response in all directions)




Figure 3.4: Omnidirectional pattern

Cardioid (weighted response from one direction)




Figure 3.5: Cardioid pattern

Hyper-Cardioid (more extreme directional variations) (no picture)

Figure eight (bidirectional pickup response, used in M/S pair see below)




Figure 3.6: Figure 8 pattern

In reality these pickup patterns extend in 3 dimensions. The following picture highlights this.

3.2. MICROPHONES 9




Figure 3.7: 3d cardioid pattern

3.2.6 Polar representation of frequency response

Microphones and loudspeakers have directional characteristics. (They respond differently in different directions) Most microphone manufacturers provide polar response charts. Good interactive one at: Neumann Website Learning to read these charts is useful. the following is the frequency response of the D112 kick drum mic.




Figure 3.8: Frequency response curve

3.3 Capturing a spatial image

In a recording we will want to recreate the sense of space that was present in the source. We also need to present the recordings through a medium that can reproduce the sense of space. Typically the process is generalised into the term spatial encoding/decoding. We would say that a recording is spatially encoded in stereo, M/S or b-format.

3.3.1 Spatial encoding

Some examples of spatial encoding formats.

- mono (1 channel)
- stereo (2 channel, X/Y pair)
- stereo (2 channel, A/B pair)
- stereo (2 channel, M/S pair)
- 4 channel (quad)
- 4 channel (b-format encoded)
- 5.1 (5 full range channels and a low frequency effects channel LFE)
- $\bullet\,$ 7.1 (7 full range channels and a low frequency effects channel LFE)
- 10.2 (2 * 5.1 rigs at differing altitude)
- 8 channel (cubic array)
- 8 channel (circle array)

On this course we mainly work in stereo.

3.3.2 Stereo capture techniques

Spaced pair (A/B pair) mics are spaced apart across the sound field Coincident pair (X/Y pair)




Figure 3.9: XY pair

Using figure 8 microphones (therefore capturing more of the room) with conincident spacing (side by side, or one on top of the other) is called a Blumlein pair.




Figure 3.10: Blumlein pair

Spaced techniques include:

- ORTF pair (French Radio), mics spaced 17cm apart at 110 degrees
- NOS pair (Dutch Radio), mics spaced 30cm apart at 90 degrees
- RAI pair (Italian Radio), 21cm apart, 100 degrees.




Figure 3.11: ORTF pair

Middle and Side M/S pair M/S pairs are suited to broadcast because they can be converted to mono without phase cancellations. With this format the spatial information is encoded and must be decoded with the mixer (see diagram) or with a dedicated M/S decoder.




Figure 3.12: Mid-side pair




Figure 3.13: Mid-side pair pic2

Baffled stereo normally uses two omni-directional microphones with an acoustic baffle between them. Microphones are pointed directly at the ensemble and are spaced approximately 35cm apart.

Binaural stereo simulates the human head an usually comprises two omni-directional microphones placed inside a dummy head (and sometimes torso).

Spread stereo techniques can make use of omni or cardioid microphones as required.

3.3.3 Ambisonics

Ambisonics is a method of capturing the sound in such a way as to preserve as much of the spatial image as possible. The sound is recorded with a special microphone (a sound field mic) and encoded to a 'B-format' stream. The B-format consists of 4 channels: named W, X, Y, and Z. B-format streams can be decoded with some fairly complex mathematics into any arbitrary playback array. So if you have a stereo speaker set it can be decoded to stereo. If you have a home cinema system it can be decoded into 5.1.

Ambisonics encodes sounds from all directions in terms of pressure and velocity components, and decodes these signals to a number of loudspeakers, with psychoacoustically optimised shelf filtering above 700Hz to correct for the shadowing effects of the head. Ambisonics might be considered as the theoretical successor to coincident stereo on two loudspeakers. A good starter reference is Rumsey (Rumsey, 2006, pp402-407)

USSS has a TetraMic by Core Sound This records A-Format signals (mic pickup) A,B,C and D. The A format consists of the four signals with four sub-cardioid capsules mounted on the four faces of a tetrahedron. So left-front (LF), right-front (RF), left-back (LB) and right-back (RB) (despite them pointing up and down).

B-format is made up from three figure-eight components (X,Y and Z) and an omni component (W). X is forward facing fig8. Y is sideways fig8. The X, Y and Z components have frontal, sideways and upwards gain of +3dB or root2 with relation to the W signal (0 dB).

Deriving a B format signal from A format

```
X = 0.5((lf-lb)+(rf-rb))
Y = 0.5((lf-rb)-(rf-lb))
Z = 0.5((lf-lb)+(rb))
W = 0.5(lf+lb+rf+rb)
```

To decode into stereo:

```
R = 0.7071 * W + 0.5 * Y

L = 0.7071 * W + -0.5 * Y
```

To decode into quad:

```
 \begin{array}{l} R = 0.3536 * W + 0.3536 * X + 0.3536 * Y \\ L = 0.3536 * W + 0.3536 * X + -0.3536 * Y \\ RL = 0.3536 * W + -0.3536 * X + 0.3536 * Y \\ RR = 0.3536 * W + -0.3536 * X + -0.3536 * Y \\ \end{array}
```

The full details of this process are here http://www.blueripplesound.com/decoding

Ambisonics is used mainly in research, particularly the research of spatial sound. The following shows a closeup view of the Soundfield mic capsule and a polar plot of the pickup response of a B-Format stream.



Figure 3.14: Soundfield microhpone

3.3.4 The Shotgun Microphone

3.3.5 Pressure Gradient Mics

3.4 Surround Sound

Surround sound in the studio. http://www.soundonsound.com/sos/aug01/articles/surroundsound1.asp Disney (Fantasia) saw the first real trials of surround sound. Dolby Surround. Much quad was multiplexed into stereo then decoded. The requirement to have mono and stereo compatibility from a 4:2:4 matrix technique. Dolby MP (motion picture) was a kind of 3.1 with three front and a surround which went back up the cinema. Dolby Pro-Logic is the consumer version of this technique. Dolby Matrix encoding (LCRS)

Bibliography

Ballora, M. (2002). Essentials of Music Technology. Prentice Hall.

Ballou, G. (2013). Handbook for sound engineers. Focal Press.

Bartlett, B. (1991). Stereo microphone techniques. Focal Press.

Bartlett, B. (2013). Practical Recording Techniques: The step-by-step approach to professional audio recording. Focal Press.

Bartlett, B. and Bartlett, J. (1999). On-location recording techniques. Taylor & Francis US.

Borwick, J. (1996). Sound recording practice 4/e.

Howard, D. and Angus, J. (2009). Acoustics and psychoacoustics. Taylor & Francis US.

Huber, D. M. (2009). Modern recording techniques. Taylor & Francis US.

Katz, B. and Katz, R. A. (2007). Mastering audio: the art and the science. Taylor & Francis US.

Rumsey, F. (2006). Sound and recording: an introduction. Taylor & Francis US.

16 BIBLIOGRAPHY