



Data Sheet

SCL3300-D01 3-axis inclinometer with angle output and digital SPI interface

Features

- 3-axis (XYZ) inclinometer
- User selectable measurement modes: 3000 LSB/g with 70 Hz LPF 6000 LSB/g with 40 Hz LPF 12000 LSB/g with 10 Hz LPF
- Angle output resolution 0.0055°/LSB
- -40°C...+125°C operating range
- 3.0V...3.6V supply voltage
- SPI digital interface
- Ultra-low 0.001 °/√Hz noise density
- Excellent offset stability
- Size 8.6 x 7.6 x 3.3 mm (l × w × h)
- Proven capacitive 3D-MEMS technology

Applications

SCL3300-D01 is targeted at applications demanding high stability and accuracy with tough environmental requirements.

Typical applications include:

- Leveling
- Tilt sensing
- Machine control
- Structural health monitoring
- Inertial measurement units (IMUs)
- Robotics
- Positioning and guidance systems

Overview

The SCL3300-D01 is a high performance inclinometer sensor component. It is a three-axis inclinometer sensor with angle output based on Murata's proven capacitive 3D-MEMS technology. Signal processing is done in a mixed signal ASIC with flexible SPI digital interface. Sensor element and ASIC are packaged into 12 pin pre-molded plastic housing that guarantees reliable operation over product's lifetime.

The SCL3300-D01 is designed, manufactured and tested for high stability, reliability and quality requirements. The component has extremely stable output over wide range of temperature and vibration. The component has several advanced self-diagnostics features, is suitable for SMD mounting and is compatible with RoHS and ELV directives.






TABLE OF CONTENTS Introduction......4 Specifications4 2.1 Abbreviations 4 2.2 General Specifications......4 2.3 2.4 2.5 2.6 Absolute Maximum Ratings.......7 2.7 Pin Description8 2.8 Performance characteristics 9 2.9 2.9.1 2.9.2 2.10 2.11 2.11.1 General Product Description14 3.1 Component Operation, Reset and Power Up15 4.1 4.2 Component Interfacing17 5.1.1 General 17 5.1.2 Protocol 17 5.1.3 SPI frame 19 5.1.4 Operations 20 5.1.5 5.2 6.1 Sensor Data Block 24 6.1.1 6.1.2



	6.1	.3 Example of Angle Data Conversion	. 27
	6.2	STO	
	6.2	.1 Example of Self-Test Analysis	
	6.3	STATUS	30
	6.4	Error Flag Block	31
	6.4.1	ERR_FLAG1	31
	6.4.2	ERR_FLAG2	32
	6.5	CMD	33
	6.6	ANG_CTRL	. 34
	6.7	WHOAMI	. 34
	6.8	Serial Block	. 35
	6.8	.1 Example of Resolving Serial Number	. 35
	6.9	SELBANK	. 37
7	App	plication information	. 37
	7.1	Application Circuitry and External Component Characteristics	. 37
	7.2	Assembly Instructions	. 39
3	Fre	equently Asked Questions	. 39
9	Orc	der Information	. 40

1 Introduction

This document contains essential technical information about the SCL3300-D01 sensor including specifications, SPI interface descriptions, user accessible register details, electrical properties and application information. This document should be used as a reference when designing in SCL3300-D01 component.

2 Specifications

2.1 Abbreviations

ASIC	Application Specific Integrated Circuit
SPI	Serial Peripheral Interface
RT	Room Temperature, +23 °C
FS	Full Scale
CSB	Chip Select
SCK	Serial Clock
MOSI	Master Out Slave In
MISO	Master In Slave Out
MCU	Microcontroller
STO	Self-test Output

2.2 General Specifications

General specifications for SCL3300-D01 component are presented in Table 1. All analog voltages are related to the potential at AVSS and all digital voltages are related to the potential at DVSS.

Table 1 General specifications

Parameter	Condition		Тур	Max	Units
Supply voltage: VDD, DVIO		3.0	3.3	3.6	V
Current consumption: I_VDD	Temperature range -40 +125 °C Standard operation Mode 4		1.2 2.1		mA
Current consumption: I_VDD in power down mode Temperature range -40 +125 °C Power down mode (PD) Typical value is at room temperature (+23 °C)			3	10	μА



2.3 Performance Specifications for Inclinometer

Table 2 Inclinometer performance specifications. Supply voltage VDD = 3.3 V and room temperature (RT) +23 $^{\circ}$ C unless otherwise specified. Definition of gravitational acceleration: $g = 9.819 \text{ m/s}^2$.

Parameter	Condition	Min	Nom	Max	Unit
Measurement range	Mode 1 Mode 2 Mode 3, Mode 4 ^{(A}		1.8 3.6 -		g
weasurement range	Mode 1 Mode 2 Mode 3, Mode 4 ^{(A}		±90 ±90 ±10		۰
Offset error (B	-40°C +125°C	-20 -1.15		20 1.15	mg °
Offset temperature drift (C	-40°C +125°C X, Y	-10 -0.57		10 0.57	mg °
Onset temperature unit	-40°C +125°C Z	-15 -0.86		15 0.86	mg °
	Mode 1 Mode 2 Mode 3, Mode 4		6000 3000 12000		LSB/g
Sensitivity (acceleration output)	Mode 1 Mode 2 Mode 3, Mode 4		105 52 209		LSB/°
	valid only between 01° (D				
Sensitivity (inclination output)	All modes		182		LSB/°
Sensitivity error (B	-40°C +125°C Mode 1	-0.7		0.7	%
Sensitivity temperature drift (C	-40°C +25°C Mode 1	-0.3		0.3	%
Linearity error (E	-1g +1g range		TBD		mg
Integrated noise (RMS, accelerometer)	Mode 3, X, Y, Z channels Mode 4, X, Z channels Mode 4, Y channel		0.13 0.08 0.06		mg _{RMS}
Noise density (F	Mode 3, X, Y, Z channels Mode 4, X, Z channels Mode 4, Y channel		32 20 15		µg/√Hz
Noise defisity	Mode 3, X, Y, Z channels Mode 4, X, Z channels Mode 4, Y channel		0.0018 0.0012 0.0009		°/√Hz
Cross axis sensitivity (G	per axis	-1		1	%
Amplitudo rooposes	Mode 1		40		Hz
Amplitude response, -3dB frequency	Mode 2		70		Hz
, ,	Mode 3, Mode 4		10		Hz
Power on start-up time				15 ^{(H}	ms
ODR			2000		Hz

Min/Max values are ±3 sigma variation limits from test population at the minimum. Min/Max values are not guaranteed.

A) Inclination mode. Dynamic range is dependent on orientation in gravity.

B) Includes calibration error, temperature, supply voltage and drift over lifetime.



- C) Deviation from value at room temperature (RT).
- D) Angle calculated using 1g * SIN(θ), where θ is the inclination angle relative to the 0g position. Due to characteristics of sine function sensitivity is inversely proportional to inclination angle. Reported values are valid only between 0° to ±1°.
- E) Straight line through specified measurement range end points.
- F) SPI communication may affect the noise level. Used SPI clock should be carefully validated. Recommended SPI clock is 2 MHz 4 MHz to achieve the best performance; see section 2.9.2 SPI AC Characteristics for details.
- G) Cross axis sensitivity is the maximum sensitivity in the plane perpendicular to the measuring direction. X-axis output cross axis sensitivity (cross axis for Y and Z-axis outputs are defined correspondingly):
 - Cross axis for Y axis = Sensitivity Y / Sensitivity X
 - Cross axis for Z axis = Sensitivity Z / Sensitivity X
- H) Power on start-up time is specified according to recommended start-up sequence; see section 4.2 Start-up sequence for details.



2.4 Performance Specification for Temperature Sensor

Table 3 Temperature sensor performance specifications.

Parameter	Condition	Min.	Тур	Max.	Unit
Temperature signal range		-50		+150	°C
Temperature signal sensitivity	Direct 16-bit word		18.9		LSB/°C
Temperature signal offset	°C output	-10		10	°C

Temperature is converted to °C with following equation:

Temperature [°C] =
$$-273 + (TEMP / 18.9)$$
,

where TEMP is temperature sensor output register content in decimal format.

2.5 Specification for Angle Outputs

Angles are converted to degrees with following equation:

Angle [°] = ANG_% /
$$2^14 * 90$$
,

where ANG_% is angle output register (ANG_X, ANG_Y, ANG_Z) content in decimal format.

2.6 Absolute Maximum Ratings

Within the maximum ratings (Table 4), no damage to the component shall occur. Parametric values may deviate from specification, yet no functional failure shall occur.

Table 4. Absolute maximum ratings.

Symbol	Description	Min.	Тур	Max.	Unit
VDD	D Supply voltage analog circuitry			4.3	V
DIN/DOUT	IN/DOUT Maximum voltage at digital input and output pins			DVIO+0.3	V
Topr	Operating temperature range	-40		+125	Ô
Tstg	Storage temperature range	-40		+150	°C
ESD_HBM	ESD according Human Body Model (HBM) Q100-002	-2000		2000	V
ESD_CDM	ESD according Charged Device Model (CDM) Q100-011	-1000		1000	٧
US Ultrasonic agitation (cleaning, welding, etc.)		•	Prohibited		



2.7 Pin Description

The pinout for SCL3300-D01 is presented in Figure 1.





Figure 1 Pinout for SCL3300-D01.

Table 5 SCL3300-D01 pin descriptions.

Pin#	Name	Туре	Description
1	AVSS	GND	Analog reference ground, connect externally to GND
2	A_EXTC	AOUT	External capacitor connection for analog core
3	RESERVED	-	Factory use only, connect externally to GND
4	VDD	SUPPLY	Analog Supply voltage
5	CSB	DIN	Chip Select of SPI Interface, 3.3V logic compatible Schmitt-trigger input
6	MISO	DOUT	Data Out of SPI Interface
7	MOSI	DIN	Data In of SPI Interface, 3.3V logic compatible Schmitt-trigger input
8	SCK	DIN	CLK signal of SPI Interface
9	DVIO	SUPPLY	SPI interface Supply Voltage
10	D_EXTC	AOUT	External capacitor connection for digital core
11	11 11//22 1 (2011) 1		Digital reference ground, connect externally to GND. Must never be left floating when component is powered.
12	EMC_GND	EMC GND	EMC ground pin, connect externally to GND



2.8 Performance characteristics






Figure 2 Example noise spectrum of X-channel in mode 4

Figure 3 Example noise spectrum of Y-channel in mode 4



2.9 Digital I/O Specification

2.9.1 SPI DC Characteristics

Table 6 describes the DC characteristics of SCL3300-D01 sensor SPI I/O pins. Supply voltage is 3.3 V unless otherwise specified. Current flowing into the circuit has a positive value.

Table 6 SPI DC Characteristics

Symbol	Remark		Min.	Тур	Max.	Unit
	•				•	
Serial Clock	k SCK (Pull Down)					
I _{PD}	Pull-down current	Vin = 3.0 - 3.6 V	7.5	16.5	36	uA
V _{IH}	Input voltage '1'	0.67*DVIO		DVIO	V	
V _{IL}	Input voltage '0'	0		0.33*DVIO	V	
					•	
Chip Select	CSB (Pull Up), low active)				
I _{PU}	Pull-up current	Vin = 0	7.5	16.5	36	uA
V _{IH}	Input voltage '1'	•	0.67*DVIO		DVIO	V
V _{IL}	Input voltage '0'		0		0.33*DVIO	V
Serial Data	Input MOSI (Pull Down)					
I_{PD}	Pull-down current	Vin = 3.0 - 3.6 V	7.5	16.5	36	uA
V _{IH}	Input voltage '1'		0.67*DVIO		DVIO	V
V _{IL}	Input voltage '0'		0		0.33*DVIO	V
Serial Data	Output MISO (Tri State)					
V _{OH}	Output high voltage	I > -1 mA	DVIO-0.5V			V
V _{OL}	Output low voltage	I < 1 mA			0.5	V
I _{LEAK}	Tri-state leakage	0 < VMISO < 3.3 V	-1	0	1	uA
	Maximum Capacitive	load			50	pF

2.9.2 SPI AC Characteristics

The AC characteristics of SCL3300-D01 are defined in Figure 4 and Table 7.




Figure 4 Timing diagram of SPI communication.

Table 7 SPI AC electrical characteristics.

Symbol	Description	Min.	Тур	Max.	Unit
T _{LS1}	Time from CSB (10%) to SCK (90%)	T _{per} /2			ns
T _{LS2}	Time from SCK (10%) to CSB (90%)	T _{per} /2			ns
T _{CL}	SCK low time	T _{per} /2			ns
T _{CH}	SCK high time	T _{per} /2			ns
$f_{SCK} = 1/T_{per}$	SCK Frequency *	0.1	2	8	MHz
T _{SET}	Time from changing MOSI (10%, 90%) to SCK (90%). Data setup time	T _{per} /4			ns
T _{HOL}	Time from SCK (90%) to changing MOSI (10%, 90%). Data hold time	T _{per} /4			ns
T _{VAL1}	Time from CSB (10%) to stable MISO (10%, 90%)		120		ns
T _{LZ}	Time from CSB (90%) to high impedance state of MISO		110		ns
T _{VAL2}	Time from SCK (10%) to stable MISO (10%, 90%)		110		ns
T _{LH}	Time between SPI cycles, CSB at high level (90%)	10	· · · · · · · · · · · · · · · · · · ·	<u> </u>	us

^{*} SPI communication may affect the noise level. Used SPI clock should be carefully validated. Recommended SPI clock is 2 MHz - 4 MHz to achieve the best performance.

2.10 Measurement Axis and Directions





Figure 5 SCL3300-D01 measurement directions.

Table 8 SCL3300-D01 accelerometer measurement directions.



2.11 Package Characteristics

2.11.1 Package Outline Drawing




Figure 6 Package outline. The tolerances are according to ISO2768-f (see Table 9).

Table 9 Limits for linear measures (ISO2768-f).

Talanana alaa	Limits in mm for nominal size in mm					
Tolerance class	0.5 to 3	Above 3 to 6	Above 6 to 30			
f (fine)	±0.05	±0.05	±0.1			



2.12 PCB Footprint




Figure 7 Recommended PWB pad layout for SCL3300-D01. All dimensions are in mm. The tolerances are according to ISO2768-f (see Table 9).

3 General Product Description

The SCL3300-D01 sensor includes acceleration sensing element and Application-Specific Integrated Circuit (ASIC). Figure 8 contains an upper level block diagram of the component.




Figure 8. SCL3300-D01 component block diagram.



The sensing elements are manufactured using Murata proprietary High Aspect Ratio (HAR) 3D-MEMS process, which enables making robust, extremely stable and low noise capacitive sensors.

The acceleration sensing element consists of four acceleration sensitive masses. Acceleration causes capacitance change that is converted into a voltage change in the signal conditioning ASIC.

3.1 Factory Calibration

SCL3300-D01 sensors are factory calibrated. No separate calibration is required in the application. Calibration parameters are stored to non-volatile memory during manufacturing. The parameters are read automatically from the internal non-volatile memory during the start-up.

Assembly can cause offset/bias errors to the sensor output. If best possible accuracy is required, system level offset/bias calibration (zeroing) after assembly is recommended. Offset calibration is recommended to be performed not earlier than 12 hours after reflow. It should be noted that accuracy can be improved with longer stabilization time.

4 Component Operation, Reset and Power Up

4.1 Component Operation

Sensor ODR in normal operation mode is 2000 Hz. Registers are updated in every 0.5 ms and if all data is not read the full noise performance of sensor is not met.

In order to achieve optimal performance, it is recommended that during normal operation acceleration outputs ACCX, ACCY, ACCZ are read in every cycle using sensor ODR. It is necessary to read STATUS register only if return status (RS) indicates error.

4.2 Start-up sequence

Table 10 Start-Up Sequence

Step	Procedure	RS*	Function	Note	
1	Set VDD 3.0 - 3.6 V DVIO 3.0 - 3.6 V		Startup the device	VDD and DVIO don't need to rise at the same time	
2	Wait 10 ms		Memory reading Settling of signal path		
				Mode 1 (default)	1.8g full-scale 40 Hz 1st order low pass filter
	Set Measurement '1			Mode 2	3.6g full-scale 70 Hz 1st order low pass filter
3		'11'	' Select operation mode	Mode 3	Inclination mode 10 Hz 1st order low pass filter
				Mode 4	Inclination mode 10 Hz 1st order low pass filter Low noise mode
4	Wait 5 ms		Settling of signal path		
5	Read STATUS	'11'	Clear status summary	Reset status su	ımmary
6	Read STATUS	'11'	Read status summary	SPI response to step 5 Read status summary. Due to SPI off- frame protocol response is before STATUS has been cleared.	
7	Read STATUS (or any other valid SPI command)	'01'	Ensure successful start-up	SPI response to step 6. First response where STATUS has been cleared. RS bits should be '01' to indicate proper start-up. Otherwise start-up has not been done correctly. See 6.3 STATUS for more information.	
8	Write ANG_CTRL	'01'	Enable angle outputs	See section 6.6	for more information.

^{*} RS bits in returned SPI response during normal start-up. See 5.1.5 Return Status for more information.
** if not set, mode1 is used.



4.3 Operation modes

SCL3300-D01 provides four user selectable operation modes.

Table 11 Operation mode description

Mode		Acceleration outp	Inclination output	Acceleration and Inclination output	
Mode	Full-scale	Sensitivity LSB/g	Sensitivity °/g *	Sensitivity °/g	1 st order low pass filter
1	± 1.8 g	6000	105	182	40 Hz
2	± 3.6 g	3000	<mark>52</mark>	182	70 Hz
3	Inclination mode**	12000	209	182	10 Hz
4	Inclination mode**	12000	209	182	10 Hz

^{*} Angle calculated using 1g * SIN(θ), where θ is the inclination angle relative to the 0g position. Due to characteristics of sine function sensitivity is inversely proportional to inclination angle. Reported values are valid only between 0° to $\pm 1^{\circ}$.

5 Component Interfacing

5.1.1 General

SPI communication transfers data between the SPI master and registers of the SCL3300-D01 ASIC. The SCL3300-D01 always operates as a slave device in master-slave operation mode. 3-wire SPI connection is not supported.

Table 12 SPI interface pins

Pin	Pin Name	Communication		
CSB	Chip Select (active low)	MCU	\rightarrow	SCL3300
SCK	Serial Clock	MCU	\rightarrow	SCL3300
MOSI	Master Out Slave In	MCU	\rightarrow	SCL3300
MISO	Master In Slave Out	SCL3300	\rightarrow	MCU

5.1.2 Protocol

The SPI is a 32-bit 4-wire slave configured bus. Off-frame protocol is used so each transfer consists of two phases. A response to the request is sent within next request frame. The response concurrent to the request contains the data requested by the previous command. The first bit in a sequence is an MSB.

The SPI transmission is always started with the falling edge of chip select, CSB. The data bits are sampled at the rising edge of the SCK signal. The data is captured on the rising edge (MOSI line) of the SCK and it is propagated on the falling edge (MISO line) of the SCK. This equals to SPI Mode 0 (CPOL = 0 and CPHA = 0).

^{**} Inclination mode. Dynamic range is dependent on orientation in gravity.



NOTE: For sensor operation, time between consecutive SPI requests (i.e. CSB high) must be at least 10 μ s. If less than 10 μ s is used, output data will be corrupted.




Figure 9 SPI Protocol



5.1.3 SPI frame

The SPI Frame is divided into four parts:

- 1. Operation Code (OP), consisting of Read/Write (RW) and Address (ADDR)
- 2. Return Status (RS, in MISO)
- 3. Data (D)
- 4. Checksum (CRC)

See Figure 10 and Table 13 Table 13 SPI Frame Specification for more details. For allowed SPI operating commands see Table 14.




Figure 10 SPI Frame

Table 13 SPI Frame Specification

Name	Bits	Description	MISO / MOSI		
OP	[31:26]	Operation code RW + ADDR	OP [5] = RW OP [4:0] = ADDR	Read = 0 / V Register add	
RS	[25:24]	Return status	MISO '00' - Startup in progress '01' - Normal operation, r '10' - Self-test running '11' - Error		MOSI '00' – Always
D	[23:8]	Data	Returned data / data to v	vrite	
CRC	[7:0]	Checksum	See section 5.2		

Return Status (RS) shows error (i.e. '11') when an error flag (or flags) is active in, or if previous MOSI-command had incorrect CRC.



5.1.4 Operations

Allowed operation commands are shown in Table 14. No other commands are allowed.

Table 14 Operations and their equivalent SPI frames

rable 14 Operations and the				arrico						ODLE
Operation	Bank									SPI Frame Hex
Read ACC_X	0 1	0000	0100	0000	0000	0000	0000	1111	0111	040000F7h
Read ACC_Y	0 1	0000	1000	0000	0000	0000	0000	1111	1101	080000FDh
Read ACC_Z	0 1	0000	1100	0000	0000	0000	0000	1111	1011	0C0000FBh
Read STO (self-test output)	0 1	0001	0000	0000	0000	0000	0000	1110	1001	100000E9h
Enable ANGLE outputs	0	1011	0000	0000	0000	0001	1111	0110	1111	B0001F6Fh
Read ANG_X	0	0010	0100	0000	0000	0000	0000	1100	0111	240000C7h
Read ANG_Y	0	0010	1000	0000	0000	0000	0000	1100	1101	280000CDh
Read ANG_Z	0	0010	1100	0000	0000	0000	0000	1100	1011	2C0000CBh
Read Temperature	0 1	0001	0100	0000	0000	0000	0000	1110	1111	140000EFh
Read Status Summary	0 1	0001	1000	0000	0000	0000	0000	1110	0101	180000E5h
Read ERR_FLAG1	0	0001	1100	0000	0000	0000	0000	1110	0011	1C0000E3
Read ERR_FLAG2	0	0010	0000	0000	0000	0000	0000	1100	0001	200000C1h
Read CMD	0	0011	0100	0000	0000	0000	0000	1101	1111	340000DFh
Change to mode 1	0	1011	0100	0000	0000	0000	0000	0001	1111	B400001Fh
Change to mode 2	0	1011	0100	0000	0000	0000	0001	0000	0010	B4000102h
Change to mode 3	0	1011	0100	0000	0000	0000	0010	0010	0101	B4000225h
Change to mode 4	0	1011	0100	0000	0000	0000	0011	0011	1000	B4000338h
Set power down mode	0	1011	0100	0000	0000	0000	0100	0110	1011	B400046Bh
Wake up from power down mode	0	1011	0100	0000	0000	0000	0000	0001	1111	B400001Fh
SW Reset	0	1011	0100	0000	0000	0010	0000	1001	1000	B4002098h
Read WHOAMI	0	0100	0000	0000	0000	0000	0000	1001	0001	40000091h
Read SERIAL1	1	0110	0100	0000	0000	0000	0000	1010	0111	640000A7h
Read SERIAL2	1	0110	1000	0000	0000	0000	0000	1010	1101	680000ADh
Read current bank	0 1	0111	1100	0000	0000	0000	0000	1011	0011	7C0000B3h
Switch to bank #0	0 1	1111	1100	0000	0000	0000	0000	0111	0011	FC000073h
Switch to bank #1	0 1	1111	1100	0000	0000	0000	0001	0110	1110	FC00016Eh

5.1.5 Return Status

SPI frame Return Status bits (RS bits) indicate the functional status of the sensor. See Table 15 for RS definitions.

Table 15 Return Status definitions

RS [1]	RS [0]	Description			
0	0	Startup in progress			
0	1	Normal operation, no flags			
1	0	Reserved			
1	1	Error			

The priority of the return status states is from high to low: $00 \rightarrow 11 \rightarrow 01$

Return Status (RS) shows error (i.e. '11') when an error flag (or flags) is active in Status Summary register, or if previous MOSI-command had incorrect frame CRC. See Table 26 for description of the Status Summary register.

5.2 Checksum (CRC)

For SPI transmission error detection a Cyclic Redundancy Check (CRC) is implemented, for details see Table 16.

Table 16 SPI CRC definition

Parameter	Value
Name	CRC-8
Width	8 bit
Poly	1Dh (generator polynom: X8+X4+X3+X2+1)
Init	FFh (initialization value)
XOR out	FFh (inversion of CRC result)

The CRC value used in system level software has to be initialized with FFh to ensure a CRC failure in case of stuck-at-0 and stuck-at-1 error on the SPI bus. C-programming language example for CRC calculation is presented in Figure 11. It can be used as is in an appropriate programming context.

```
// Calculate CRC for 24 MSB's of the 32 bit dword
// (8 LSB's are the CRC field and are not included in CRC calculation)
uint8_t CalculateCRC(uint32_t Data)
  uint8_t BitIndex;
  uint8_t BitValue;
  uint8_t CRC;
  CRC = 0xFF;
  for (BitIndex = 31; BitIndex > 7; BitIndex--)
    BitValue = (uint8_t)((Data >> BitIndex) & 0x01);
    CRC = CRC8(BitValue, CRC);
  CRC = (uint8_t)~CRC;
  return CRC;
static uint8_t CRC8(uint8_t BitValue, uint8_t CRC)
  uint8_t Temp;
  Temp = (uint8 t)(CRC & 0x80);
  if (BitValue == 0x01)
    Temp ^= 0x80;
  }
  CRC <<= 1;
  if (Temp > 0)
    CRC ^= 0x1D;
  }
  return CRC;
```

Figure 11 C-programming language example for CRC calculation

In case of wrong CRC in MOSI write/read, RS bits "11" are set in the next SPI response, STATUS register is not changed, and write command is discarded. If CRC in MISO SPI response is incorrect, communication failure occurred.

CRC calculation example:

```
Read ACC_X register (04h)

SPI [31:8] = 040000h → CRC = F7h

SPI [7:0] = F7h

SPI frame = 040000F7h
```

6 Register Definition

SCL3300-D01 contains two user switchable register banks. Default register bank is #0. One should have register bank #0 always active, unless data from bank #1 is required. After reading data from bank #1 is finished, one should switch back to bank #0 to ensure no accidental read / writes in unwanted registers. See 6.9 SELBANK for more information for selecting active register bank. Table 17 shows overview of register banks and register addresses.



Table 17 Register address space overview

Addr	Read/	Registe	er Bank	Description
(hex)	Write	#0	#1	Description
01h	R	ACC_X	ACC_X	X-axis acceleration output in 2's complement format
02h	R	ACC_Y	ACC_Y	Y-axis acceleration output in 2's complement format
03h	R	ACC_Z	ACC_Z	Z-axis acceleration output in 2's complement format
04h	R	STO	STO	Self-test output in 2's complement format
05h	R	TEMPERATURE	TEMPERATURE	Temperature sensor output in 2's complement format
06h	R	STATUS	STATUS	Status Summary combining ERR_FLAG1 and ERR_FLAG2
07h	R	ERR_FLAG1	reserved	Error flags group1
08h	R	ERR_FLAG2	reserved	Error flags group2
09h	-	ANG_X	reserved	X-axis angle output in 2's complement format
0Ah	-	ANG_Y	reserved	Y-axis angle output in 2's complement format
0Bh	-	ANG_Z	reserved	Z-axis angle output in 2's complement format
0Ch	-	ANG_CTRL	reserved	Enable angle outputs
0Dh	R/W	MODE	reserved	Sets operation mode, SW Reset and Power down mode
0Eh	-	reserved	reserved	-
0Fh	-	reserved	reserved	-
10h	R	WHOAMI	reserved	8-bit register for component identification
11h	-	reserved	reserved	-
12h	-	reserved	reserved	-
13h	-	reserved	reserved	-
14h	-	reserved	reserved	-
15h	-	reserved	reserved	-
16h	-	reserved	reserved	-
17h	-	reserved	reserved	-
18h	-	reserved	reserved	-
19h	R	reserved	SERIAL1	Component serial part 1
1Ah	R	reserved	SERIAL2	Component serial part 2
1Bh	-	reserved	Factory Use	-
1Ch	-	reserved	Factory Use	-
1Dh	-	reserved	Factory Use	-
1Eh	-	reserved	reserved	-
1Fh	R/W	SELBANK	SELBANK	Switch between active register banks

User should not access Reserved nor Factory Use registers. Power-cycle, reset and power down mode will reset all written settings.



6.1 Sensor Data Block

Table 18 Sensor data block description

Bank	Addr	Name	No. of bits	Read / Write	Description
0 1	01h	ACC_X	16	R	X-axis acceleration output in 2's complement format
0 1	02h	ACC_Y	16	R	Y-axis acceleration output in 2's complement format
0 1	03h	ACC_Z	16	R	Z-axis acceleration output in 2's complement format
0 1	05h	TEMPERATURE	16	R	Temperature sensor output in 2's complement format. See section 2.4 for conversion equation.
0	09h	ANG_X	16	R	X-axis angle output in 2's complement format See section 0 for conversion equation.
0	0Ah	ANG_Y	16	R	Y-axis angle output in 2's complement format See section 0 for conversion equation.
0	0Bh	ANG_Z	16	R	Z-axis angle output in 2's complement format See section 0 for conversion equation

Table 19 Sensor data block operations

Table 10 Censor data block operations							
Operation	SPI Frame	SPI Frame Hex					
Read ACC_X	0000 0100 0000 0000 0000 0000 1111 0111	040000F7h					
Read ACC_Y	0000 1000 0000 0000 0000 0000 1111 1101	080000FDh					
Read ACC_Z	0000 1100 0000 0000 0000 0000 1111 1011	0C0000FBh					
Read Temperature	0001 0100 0000 0000 0000 0000 1110 1111	140000EFh					
Read ANG_X	0010 0100 0000 0000 0000 0000 1100 0111	240000C7h					
Read ANG_Y	0010 1000 0000 0000 0000 0000 1100 1101	280000CDh					
Read ANG_Z	0010 1100 0000 0000 0000 0000 1100 1011	2C0000CBh					



6.1.1 Example of Acceleration Data Conversion

For example, if ACC_X register read results: ACC_X = 0500DC1Ch, the register content is converted to acceleration rate as follows:

OP[31 RS[25	+		Data[23:8]		CRC[7:0]
0	5	0	0	D	C	1	С

```
OP + RS
      05h = 0000 \ 0101b
            0000 01b
                                = OP code = Read ACC_X
            01b
                                = return status (RS bits) = no error
Data = ACC_X register content
      00DCh
            00DCh → 220d
                                = in 2's complement format
            Acceleration:
            = 220 LSB / sensitivity(mode1)
            = 220 LSB / 2700 LSB/g
            = 0.081 g
CRC
      1Ch
          CRC of 0500DCh, see section 5.2
```



6.1.2 Example of Temperature Data Conversion

For example, if TEMPERATURE register read results: TEMPERATURE = 15161E0Ah, the register content is converted to temperature as follows:

	OP[31 RS[25	+ -		Data[23:8]		CRC[7:0]
Ī	1	5	1	6	1	E	0	Α

OP + RS

```
Data = TEMPERATURE register content

161Eh

161Eh → 5662d = in 2's complement format

Temperature:

= -273 + (5662 / 18.9)

= +26.6°C
```

CRC

0Ah

CRC of 15161Eh, see section 5.2



6.1.3 Example of Angle Data Conversion

Angle outputs must be enabled before angles can be read from registers. See section 6.6 for details.

For example, if ANG_X register read results: ANG_X = 15161E0Ah, the register content is converted to angle (degrees) as follows:

OP[31 RS[25	+ -		Data[23:8]		CRC[7:0]
2	5	0	F	8	8	2	5

```
OP + RS

25h = 0010 0101b
0010 01b = OP code = Read ANG_X
01b = return status (RS bits) = no error

Data = ANG_X register content
0F88h
0F88h → 3976d
Angle in degrees:
= 3976/2^14*90
= 21.84°

CRC
25h
```

CRC of 250F88h, see section 5.2

6.2 STO

Table 20 STO (self-test output) description


Bank	Addr	Name	No. of bits	Read / Write	Description
0 1	04h	STO	16	R	Self-test output in 2's complement format

Table 21 STO operation

Operation	SPI Frame	SPI Frame Hex		
Read STO (self-test output)	0001 0000 0000 0000 0000 0000 1110 1001	100000E9h		

If self-test option is desired in application, following guidelines should be taken into account. STO is used to monitor if accelerometer is functioning correctly. It provides information on signal saturation during vibration and shock events. STO should be read continuously in the normal operation sequence after XYZ acceleration readings.

STO threshold monitoring should be implemented on application software. Failure thresholds and failure tolerant time of the system are application specific and should be carefully validated. Monitoring can be implemented by counting the subsequent "STO signal exceeding threshold" —events. Examples for STO thresholds are shown in Table 22.



Failure-tolerant time, e.g. event counter how many times threshold is exceeded

Component failure can be suspected if the STO signal exceeds the threshold level continuously after performing component hard reset in static (no vibration) condition.

Table 22 Examples for STO Thresholds

Mode	Full-scale	Examples for STO thresholds
1	TBD	
2	TBD	
3	TBD	
4	TBD	



6.2.1 Example of Self-Test Analysis

For example, if STO register read results: STO = 1100017Bh, the register value can be converted as follows:

OP[31 RS[25	+ -		Data[CRC[7:0]		
1	1	0	0	0	1	7	В

```
OP + RS

11h = 0001 0001b
0001 00b = OP code = Read STO
01b = return status (RS bits) = no error

Data = STO register content
0001h
0001h → 1d = in 2's complement format
Self-test reading:
= 1
See Table 11 for recommended STO threshold values

CRC
7Bh
CRC of 110001h, see section 5.2
```

6.3 STATUS

Table 23 STATUS description

Bank	Addr	Name	No. of bits	Read / Write	Description
0 1	06h	STATUS	16	R	Status Summary combining ERR_FLAG1 and ERR_FLAG2

Table 24 STATUS operation

Operation	SPI Frame	SPI Frame Hex		
Read Status Summary	0001 1000 0000 0000 0000 0000 1110 0101	180000E5h		

Table 25 STATUS register

D45	D44	D40	D40	l.	D40	D0	Б0		D0	D.	D 4	Б0	Б0	D4	D0	D:1
D15	D14	D13	D12	D11	D10	D9	D8	D7	D6	D5	D4	D3	D2	D1	D0	Bit
		Resei	rved			DIGI1	DIGI2	CLK	SAT	TEMP_SAT	PWR	MEM	PD	MODE_CHANGE	PIN_CONTINUITY	Read

Table 26 STATUS register bit description

Bit	Name	Description	Required action/explanation			
9	DIGI1	Digital block error type 1	SW or HW reset needed			
8	DIGI2	Digital block error type 2	SW or HW reset needed			
7	CLK	Clock error	SW or HW reset needed			
6	SAT	Signal saturated in signal path	Acceleration too high and acceleration reading not usable. Component failure possible. All acceleration and STO output data is invalid.			
5	TEMP_SAT	Temperature signal path saturated	External temperature too high or low. Component failure possible			
4	PWR	Voltage level failure	External voltages too high or low. Component failure possible. SW or HW reset needed.			
3	MEM	Error in non-volatile memory	Memory check failed. Possible component failure SW or HW reset needed.			
2	PD	Device in power down mode	If power down is not requested. SW or HW reset needed			
1	MODE_CHANGE	Operation mode changed	If mode change is not requested. SW or HW reset needed			
0	PIN_CONTINUITY	Component internal connection error	Possible component failure			

Rev. 1

Software (SW) reset is done with SPI operation (see 5.1.4). Hardware (HW) reset is done by power cycling the sensor. If these do not reset the error, then possible component error has occurred and system needs to be shut down and part returned to supplier.

6.4 Error Flag Block

Table 27 Error flag block description

Bank	Addr	Register Name	No. of bits	Read / Write	Description
0	07h	ERR_FLAG1	16	R	Error flags
0	08h	ERR_FLAG2	16	R	Error flags

Table 28 Error flag block operations

Operation	SPI Frame	SPI Frame Hex		
Read ERR_FLAG1	0001 1100 0000 0000 0000 0000 1110 0011	1C0000E3		
Read ERR_FLAG2	0010 0000 0000 0000 0000 0000 1100 0001	200000C1h		

STATUS register contains combination of the information in the ERR_FLAG1 and ERR_FLAG2 registers; if there is an error, it is reflected in STATUS. ERR_FLAG registers can be used to further assess reason for error. Note that reading ERR_FLAG registers does not reset error flags in STATUS register nor reset RS bits.

6.4.1 ERR_FLAG1

Table 29 ERR_FLAG1 register

				- 5												
D15	D14	D13	D12	D11	D10	D9	D8	D7	D6	D5	D4	D3	D2	D1	D0	Bit
	Rese	rved		ADC_SAT					AFE_	_SAT					MEM	Read

Table 30 ERR_FLAG1 register bit description

Bit	Name	Description
15:12	Reserved	Reserved
11	ADC_SAT	Signal saturated at A2D
10:1	AFE_SAT	Signal saturated at C2V
0	MEM	Error in non-volatile memory

6.4.2 ERR_FLAG2

Table 31 ERR_FLAG2 register

		_		_												
D15	D14	D13	D12	D11	D10	D9	D8	D7	D6	D5	D4	D3	D2	D1	D0	Bit
Reserved	D_EXTC	A_AEXT_C	AGND	VDD	Reserved	MODE_CHANGE	PD	MEMORY_CRC	Reserved	APWR	DPWR	REFV	APWR_2	TEMP_SAT	CLK	Read

Table 32 ERR FLAG2 register bit description

1 4510 02	ERR_FLAGZ register bit descript) I					
Bit	Name	Description					
15	Reserved	Reserved					
14	D_EXT_C	External capacitor connection error					
13	A_EXT_C	External capacitor connection error					
12	AGND	Analog ground connection error					
11	VDD	Supply voltage error					
10	Reserved	Reserved					
9	MODE_CHANGE	Operation mode changed by user					
8	PD	Device in power down mode					
7	MEMORY_CRC	Memory CRC check failed					
6	Reserved	Reserved					
5	APWR	Analog power error					
4	DPWR	Digital power error					
3	VREF	Reference voltage error					
2	APWR_2	Analog power error					
1	TEMP_SAT	Temperature signal path saturated					
0	CLK	Clock error					

6.5 CMD

Table 33 CMD description

Bank	Addr	Register Name	No. of bits	Read / Write	Description
0	0Dh	CMD	16	R/W	Sets operation mode, SW Reset and Power down mode

Table 34 CMD operations

Command	SPI Frame	SPI Frame hex
Read CMD	0011 0100 0000 0000 0000 0000 1101 1111	340000DFh
Change to mode1	1011 0100 0000 0000 0000 0000 0001 1111	B400001Fh
Change to mode2	1011 0100 0000 0000 0000 0001 0000 0010	B4000102h
Change to mode3	1011 0100 0000 0000 0000 0010 0010 0101	B4000225h
Change to mode4	1011 0100 0000 0000 0000 0011 0011 1000	B4000338h
Set power down mode	1011 0100 0000 0000 0000 0100 0110 1011	B400046Bh
Wake up from power down mode	1011 0100 0000 0000 0000 0000 0001 1111	B400001Fh
SW Reset	1011 0100 0000 0000 0010 0000 1001 1000	B4002098h

Table 35 CMD register

D15	D14	D13	D12	D11	D10	D9	D8	D7	D6	D5	D4	D3	D2	D1	D0	Bit
			Reserved					Factory use	Factory use	SW_RST	Factory use	Factory use	PD	NOUT	2	Read

Table 36 CMD register bit description

Bit	Name	Description
15:8	Reserved	Reserved
7	Factory use	Factory use
6	Factory use	Factory use
5	SW_RST	Software (SW) Reset
4	Factory use	Factory use
3	Factory use	Factory use
2	PD	Power Down
1:0	MODE	Operation Mode

Sets operation mode of the SCL3300-D01. After power-off, reset (SW or HW), power down mode or unintentional power-off, normal start-up sequence must be followed. Note: mode will be set to default mode1.

Operation modes are described in section 4.3.

Changing mode will set Status Summary bit 1 to high, setting / waking up from power down mode will set Status Summary bit 2 to high (see 6.3.) Thus RS bits will show '11' (see 5.1.5.)

Note: User must not configure other than given valid commands, otherwise power-off, reset or power down is required.

6.6 ANG_CTRL

Table 37 ANG CTRL description

В	ank	Addr	Register Name	No. of bits	Read / Write	Description
	0	0Ch	ANG_CTRL	16	W	Enable angle outputs.

Table 38 ANG CTRL operations

Command	SPI Frame	SPI Frame hex
Enable Angle Outputs	1011 0000 0000 0000 0001 1111 0110 1111	B0001F6Fh

Table 39 ANG_CTRL register

			_		•												
ĺ	D15	D14	D13	D12	D11	D10	D9	D8	D7	D6	D5	D4	D3	D2	D1	D0	Bit
		•	•	-	Not L	lsed [1	5:5]	-				Enab		le Out _l '11111		:0] =	Write

ANG_CTRL is a 5-bit registers to control angle outputs. Default value for register is 00h. Angle outputs are enabled by writing 1Fh to ANG_CTRL.

6.7 WHOAMI

Table 40 WHOAMI description

Ban	k Addr	Register Name	No. of bits	Read / Write	Description
0	10h	WHOAMI	8	R	8-bit register for component identification

Table 41 WHOAMI operations

Operation	SPI Frame	SPI Frame Hex
Read WHOAMI	0100 0000 0000 0000 0000 0000 1001 0001	40000091h

Table 42 WHOAMI register

			_													
D15	D14	D13	D12	D11	D10	D9	D8	D7	D6	D5	D4	D3	D2	D1	D0	Bit
								-	-	-	-	-	-	-	-	Write
	Not Used [15:8]									ompo	nent II	7:0]	= C1h		•	Read

WHOAMI is a 8-bit register for component identification. Returned value is C1h.

Note: as returned value is fixed, this can be used to ensure SPI communication is working correctly.



6.8 Serial Block

Table 43 Serial block description

			•			
	Bank	Addr	Register Name	No. of bits	Read / Write	Description
	1	19h	SERIAL1	16	R	Component serial part 1
Ī	1	1Ah	SERIAL2	16	R	Component serial part 2

Table 44 Serial block operations

Operation	SPI Frame	SPI Frame Hex	
Read SERIAL1	0110 0100 0000 0000 0000 0000 1010 0111	640000A7h	
Read SERIAL2	0110 1000 0000 0000 0000 0000 1010 1101	680000ADh	

Serial Block contains sensor serial number in two 16 bit registers in register bank #1, see 6.5 CMD for information how to switch register banks. The same serial number is also written on top of the sensor.

The following procedure is recommended when reading serial number:

- 1. Change active register bank to #1
- 2. Read registers 19h and 1Ah
- 3. Change active register back to bank #0
- 4. Resolve serial number:
 - 1. Combine result data from 1Ah[16:31] and 19h[0:15]
 - 2. Convert HEX to DEC
 - 3. Add letters "B33" to end

6.8.1 Example of Resolving Serial Number

1 Change active register bank to #1

SPI Request SWITCH_TO_BANK_1

Request: FC00016E

Response: XXXXXXXX, response to previous command

2. Read registers 19h and 1Ah

SPI Request READ_SERIAL1:

Request: 640000A7

Response: FD0001E1, response to switch command

SPI Request READ_SERIAL2:

Request: 680000AD

Response: 65F7DA19, response to serial1, data: F7DA



3. Change active register back to bank #0

SPI Request SWITCH_TO_BANK_0

Request: FC000073

Response: 693CE54F, response to serial2, data: 3CE5

4. Resolve serial number

1. Combined Serial number: 3CE5F7DA

HEX to DEC: 1021704154
 Add "B33": 1021704154B33

→ Full Serial number: 1021704154B33



6.9 SELBANK

Table 45 SELBANK description

Bank	Addr	Register Name	No. of bits	Read / Write	Description
0 1	1Fh	SELBANK	16	R	Switch between active register banks

Table 46 SELBANK operations

Command	SPI Frame	SPI Frame hex
Read current bank	0111 1100 0000 0000 0000 0000 1011 0011	7C0000B3h
Switch to bank #0	1111 1100 0000 0000 0000 0000 0111 0011	FC000073h
Switch to bank #1	1111 1100 0000 0000 0000 0001 0110 1110	FC00016Eh

SELBANK is used to switch between memory banks #0 and #1. It's recommended to keep memory bank #0 selected unless register from bank #1 is required, for example, reading serial number of sensor. After using bank #1 user should switch back to bank #0.

7 Application information

7.1 Application Circuitry and External Component Characteristics

See Figure 12 and Table 47 for specification of the external components. The PCB layout example is shown in Figure 13.




Figure 12 Application schematic.



Table 47 External component description for SCL3300-D01.

Symbol	Description		Min.	Nom.	Max.	Unit
C1	Decoupling capacitor between VDD and GND Recommended component: Murata GCM155R71C104KA55, 0402, 16V, X7R Please confirm capacitor availability from www.murata.com	ESR	70	100	130 100	nF mΩ
C2	Decoupling capacitor between A_EXTC and GND Recommended component: Murata GCM155R71C104KA55, 0402, 16V, X7R Please confirm capacitor availability from www.murata.com	ESR	70	100	130 100	nF mΩ
C3	Decoupling capacitor between D_EXTC and GND Recommended component: Murata GCM155R71C104KA55, 0402, 16V, X7R Please confirm capacitor availability from www.murata.com	ESR	70	100	130 100	nF mΩ
C4	Decoupling capacitor between DVIO and GND Recommended component: Murata GCM155R71C104KA55, 0402, 16V, X7R Please confirm capacitor availability from www.murata.com	ESR	70	100	130 100	nF mΩ




Figure 13. Application PCB layout.

General circuit diagram and PCB layout recommendations for SCL3300-D01:

- 1. Connect decoupling SMD capacitors (C1 C4) right next to respective component pins.
- 2. Place ground plate under component.
- 3. Do not route signals or power supplies under the component on top layer.
- 4. Ensure good ground connection of DVSS, AVSS and EMC_GND pins



7.2 Assembly Instructions

The Moisture Sensitivity Level of the component is Level 3 according to the IPC/JEDEC JSTD-020C. The part is delivered in a dry pack. The manufacturing floor time (out of bag) at the customer's end is 168 hours.

Usage of PCB coating materials may penetrate component lid and affect component performance. PCB coating is not allowed.

Sensor components shall not be exposed to chemicals which are known to react with silicones, such as solvents. Sensor components shall not be exposed to chemicals with high impurity levels, such as CI-, Na+, NO3-, SO4-, NH4+ in excess of >10 ppm. Flame retardants such as Br or P containing materials shall be avoided in close vicinity of sensor component. Materials with high amount of volatile content should also be avoided.

If heat stabilized polymers are used in application, user should check that no iodine, or other halogen, containing additives are used.

For additional assembly related details please refer to technical note Assembly instructions of Dual Flat Lead Package (DFL).

APP 2702 Rev.2 Assembly_Instructions_for_DFL_Package

8 Frequently Asked Questions

- How can I be sure SPI communication is working?
 - Read register WHOAMI (10h), the response should be C1h.
- Why do I get wrong results when I read data?
 - SCL3300-D01 uses off-frame protocol (see 5.1.2 Protocol), make sure to utilize this correctly.
 - o Confirm time between SPI requests (CSB high) is at least 10 μs.
 - Ensure SCL3300-D01 is correctly started (see 4.2 Start-up sequence).
 - Read RS bits (see 5.1.5 Return Status), if error is shown read Status Summary (see 6.3 STATUS) for further information.
 - Confirm correct sensitivity is used for current operation mode (see 4.3 Operation modes)
- Why all angle outputs read only zeroes?
 - Ensure that angle outputs are enabled after startup (see 4.2 Start-up sequence and 6.6 ANG_CTRL)



9 Order Information

Order Code	Description	Packing	Qty
SCL3300-D01-004	3-axis inclinometer with digital SPI interface	Bulk	4pcs
SCL3300-D01-1	3-axis inclinometer with digital SPI interface	T&R	100pcs
SCL3300-D01-10	3-axis inclinometer with digital SPI interface	T&R	1000pcs



Document Change Control

Authors
Antti Miettinen
Department/Role
Product Division / Product Manager

Rev.	Date	Change Description	Author	Reviewed by	ECN
1	13.11.2018	Initial Release	APM	ANFI, SRA	
			i e		