Pages	SubPages	Description	Parameters Required
Sign Up Page		To Create a Login for the user to login	1.Username 2.Password 3. Name 4. Email 5. Company
Login Page		To Provide the Login Authentication	1.Username 2.Password
Home Page		Summary of the Web Portal is displayed as the dashboard . It will be the landing page	<ul><li>1.Weather Parameters</li><li>2. Summary of Online/offline Robots</li><li>3. Alerts and Notifications</li><li>4. Graphical view of KPI Indicators</li></ul>
Live Data		Displays the realtime data about the individual Robots along with the timestamp and provision for download the table details as Csv,XLSX,PDF	1.Timestamp 2. Robot Id 3. Robot Control 4.Robot status feedback 5.Communication Status 6.RFID Data 7.Battery Percentage 8.Current Running Length 9.Total Running Length 10.Robot Stuck Count 11.Cleaning Cycle 12.Current Panels Cleaned 13.Total Panels Cleaned 14.Battery Cycles 15.Device ID 16.Lat,Long 17.TempA 18.Temp1,2,3,4(approx) 19. rain strom alert
Reports		This Page provides provision to download Day/monthly/yearly reports with custom parameters of individual robots	1. Robot Travelling Distance- Daywise(In meters) 2. Robot Travelling Distance -Total(In meters) 3. Solar Panels Cleaned -Daywise 4. Solar Panels Cleaned -Total 5. Total Battery Discharge Cycles

Scheduler		This page provides the provision for scheduling the robots operation according to the setted time based on whether day wise or week wise schedule	1.Cleaning Frequency     2.Last cleaning Time     3. Next Scheduled Time
Alerts		This page provides the alerts list and its status	1.Timestamp 2. Alert name 3.Robot Id 4. Type 5. Action Required
		In this Page the users can be configured with the credentials.	
Settings	Users	Once configured then only they can access the website with the credentials provided	
	Client	In this page the clients/customers can be configured	
	Plant/Site	This page provides the provision to add/configure the details about the sites of the corresponding clients	
	Blocks	To set the blocks/grouped areas under the site where the robots are added	
	Robots	To add or assign robots for the assigned blocks	
	Webportal Settings	In this page we can set the settings for the site customization	
	External Integrations	Provision for the external Integrations /Rule engine should be added to provide easy configuration settings	
Help/Support		This page provides the provision to raise tickets for support	