Bode plot of an Integrator

We start with finding the Bode plot asymptotes for a simple system characterized by

$$G(s) = \frac{1}{s} \implies G(j\omega) = \frac{1}{j\omega} = |G(j\omega)| \angle G(j\omega) = \frac{1}{|\omega|} \angle - 90^{\circ}$$


Examining the amplitude in dB scale, i.e.,

$$20 \cdot \log_{10} \left| G(j\omega) \right| = 20 \cdot \log_{10} \frac{1}{|\omega|} = -20 \cdot \log_{10} \left| \omega \right| dB$$

$$\omega = 1 \implies 20 \cdot \log_{10} |G(j1)| = -20 \cdot \log_{10} 1 = 0 \text{ dB}$$

 $\omega = 10 \implies 20 \cdot \log_{10} |G(j10)| = -20 \cdot \log_{10} 10 = -20 \text{ dB}$





Thus, the above expressions clearly indicate that the magnitude is reduced by -20dB when the frequency is increased by 10 times. It is equivalent to say that the magnitude is rolling off 20dB per decade

The phase response of an integrator is -90 degrees, a constant.

Bode plot of a Diffrentiator

We start with finding the Bode plot asymptotes for a simple system characterized by


$$G(s) = s \Rightarrow G(j\omega) = j\omega = |G(j\omega)| \angle G(j\omega) = |\omega| \angle 90^{\circ}$$

Examining the amplitude in dB scale, i.e.,

$$|20\log_{10}|G(j\omega)| = 20.\log_{10}|\omega| = 20\log_{10}|\omega|dB$$

 $\omega = 1 \Rightarrow 20 \log_{10} |G(j1)| = 20 \log_{10} 1 = 0 dB$ $\omega = 10 \Rightarrow 20 \log_{10} |G(j10)| = 20 \log_{10} 10 = 20 dB$






Thus, the above expressions clearly indicate that the magnitude is increased by 20dB when the frequency is increased by 10 times. It is equivalent to say that the magnitude is rolling up 20dB per decade

The phase response of an integrator is 90 degrees, a constant.

Example : k



1

0.1


Magnitude:

$$|k|_{dB} = 20\log|k|(dB)$$

Phase:

$$\angle k = \begin{cases} 0^o & , k > 0 \end{cases}$$

$$180^o & , k < 0 \end{cases}$$



10

Example:

$$G(s) = \frac{a}{(s+a)}$$

Magnitude:

$$\left| (1+j\frac{\omega}{a})^{-1} \right|_{dB} = -20\log\sqrt{1+(\frac{\omega}{a})^2}$$
$$= -10\log[1+(\frac{\omega}{a})^2]$$

$$\omega \prec \prec a \Rightarrow \frac{\omega}{a} \approx 0 \Rightarrow dB = -10 \log 1 = 0$$

$$\omega \succ \Rightarrow 1 + j\frac{\omega}{a} \approx \frac{\omega}{a} \Rightarrow dB \approx -20\log\frac{\omega}{a}$$

 $dB = -[20\log\omega - 20\log a]$

$$\omega = a \Rightarrow 1 + j1 \Rightarrow dB = -10 \log 2 = -3.01$$

Phase:


$$\angle (1+j\frac{\omega}{a}) = 0^0 - \tan^{-1}\frac{\omega}{a}$$

$$\omega \prec \prec a \Rightarrow \frac{\omega}{a} \approx 0 \Rightarrow \angle GH \approx \tan^{-1} 0 = 0^{\circ}$$

$$\omega \succ \Rightarrow \frac{\omega}{a} \approx \infty \Rightarrow \angle GH \approx -\tan^{-1} \infty = -90^{\circ}$$

a=1

Break Frequency or corner frequency



Example:
$$G(s) = \frac{10}{(s+10)}$$

Magnitude:
$$\left| (1 + j\frac{\omega}{10})^{-1} \right|_{dB} = -20 \log \sqrt{1 + (\frac{\omega}{10})^2}$$

= $-10 \log[1 + (\frac{\omega}{10})^2]$

Magnitude:
$$|a| \frac{(s)}{(s+10)}| = -20 \log \sqrt{1 + (\frac{\omega}{10})^2}$$

$$= -10 \log[1 + (\frac{\omega}{10})^2]$$

$$= -10 \log[1 + (\frac{\omega}{10})^2]$$

$$\omega \prec \prec 10 \Rightarrow \frac{\omega}{10} \approx 0 \Rightarrow dB = -10 \log 1 = 0$$

$$\omega \succ \succ 10 \Rightarrow 1 + j \frac{\omega}{10} \approx \frac{\omega}{10} \Rightarrow dB \approx -20 \log \frac{\omega}{10}$$


$$dB = -[20 \log \omega - 20 \log 10]$$

 $\omega = 10 \Rightarrow 1 + i1 \Rightarrow dB = -10 \log 2 = -3.01$

$$\angle (1+j\frac{\omega}{10}) = 0^0 - \tan^{-1}\frac{\omega}{10}$$

$$\angle (1+j\frac{\omega}{10}) = 0^0 - \tan^{-1}\frac{\omega}{10} \qquad \omega \prec \prec 10 \Rightarrow \frac{\omega}{10} \approx 0 \Rightarrow \angle GH \approx \tan^{-1}0 = 0^0$$

$$\omega \succ 10 \Rightarrow \frac{\omega}{10} \approx \infty \Rightarrow \angle GH \approx -\tan^{-1} \infty = -90^{\circ}$$



Bode Plot- A General First Order Unstable System

$$G(s) = \frac{\omega_1}{s - \omega_1}$$

$$G(s) = \frac{\omega_{l}}{s - \omega_{l}} = \frac{-1}{1 - \frac{s}{\omega_{l}}} \implies G(j\omega) = \frac{-1}{1 - j\left(\frac{\omega}{\omega_{l}}\right)} = \frac{1}{\sqrt{1 + \left(\frac{\omega}{\omega_{l}}\right)^{2}}} \angle -180^{\circ} + \tan^{-1}\left(\frac{\omega}{\omega_{l}}\right)$$

Let us examine the following situations.


$$\omega = \omega_{\rm i} \quad \Rightarrow \quad G(j\omega_{\rm i}) = \frac{1}{\sqrt{1 + \left(\frac{\omega_{\rm i}}{\omega_{\rm i}}\right)^2}} \angle \tan^{-1}\left(\frac{\omega_{\rm i}}{\omega_{\rm i}}\right) = 0.707 \angle -135^{\circ} \quad (0.707 = -3 \text{ dB})$$

$$\omega \ll \omega_1 \implies G(j\omega) = \frac{1}{\sqrt{1 + \left(\frac{\omega}{\omega_1}\right)^2}} \angle -180^\circ + \tan^{-1}\left(\frac{\omega}{\omega_1}\right) \approx 1 \angle -180^\circ$$


$$\omega >> \omega_1 \implies G(j\omega) = \frac{1}{\sqrt{1 + \left(\frac{\omega}{\omega_1}\right)^2}} \angle -180^\circ + \tan^{-1}\left(\frac{\omega}{\omega_1}\right) \approx \frac{\omega_1}{\omega} \angle -90^\circ$$

Example: Consider the following system where $\omega_1=10$ rad/s is the corner frequency


$$G(s) = \frac{-1}{1 - s/10}$$



The Bode plot of $G(s) = 1 + s/\omega_1$ can be done similarly....



The Bode plot of $G(s) = 1 - s/\omega_1$ can be done similarly....



Bode plot- Putting all together

Assume a given system has only simple poles and zeros

$$G(s) = \frac{b_m s^m + b_{m-1} s^{m-1} + \dots + b_1 s + b_0}{s^n + a_{n-1} s^{n-1} + \dots + a_1 s + a_0} = \frac{b_m (s + z_1) \dots (s + z_m)}{(s + p_1) \dots (s + p_m)}$$

or

$$G(s) = \frac{b_m(s+z_1)\cdots(s+z_m)}{(s+p_1)\cdots(s+p_m)} = \frac{k(1+\frac{s}{z_1})\cdots(1+\frac{s}{p_{m_1}})}{s^q(1+\frac{s}{p_1})\cdots(1+\frac{s}{p_{n_1}})}$$

In dB scale, we have

$$\left|G(j\omega)\right| \mathrm{dB} = \left|k\right| \mathrm{in} \ \mathrm{dB} + \left|1 + \frac{j\omega}{z_1}\right| \mathrm{in} \ \mathrm{dB} + \dots + \left|1 + \frac{j\omega}{z_{m_1}}\right| \mathrm{in} \ \mathrm{dB} - \left|\omega\right| \mathrm{in} \ \mathrm{dB} \times q - \left|1 + \frac{j\omega}{p_1}\right| \mathrm{in} \ \mathrm{dB} - \dots - \left|1 + \frac{j\omega}{p_{n_1}}\right| \mathrm{in} \ \mathrm{dB}$$

Similarly,

$$\angle G(j\omega) = \angle k + \angle \left(1 + \frac{j\omega}{z_1}\right) + \dots + \angle \left(1 + \frac{j\omega}{z_{m_1}}\right) - 90^\circ \times q - \angle \left(1 + \frac{j\omega}{p_1}\right) - \dots - \angle \left(1 + \frac{j\omega}{p_{n_1}}\right)$$


Thus, the Bode plot of a complex system can be broken down to the additions and subtractions of some simple systems...

Example


sketch bode plot of

$$G(s) = \frac{10^4 (1+s)}{(10+s)(100+s)^2}$$
$$= \frac{0.1(1+s)}{(1+s/10)(1+s/100)^2}$$

Corner frequency at 1,10,100



$$G(s) = \frac{20s}{(1+s/5)(1+s/500)}$$



Example

 $G(s) = \frac{(s+3)}{s(s+1)(s+2)}$


 $=\frac{(3/2)(1+s/3)}{s(1+s)(1+s/2)}$

sketch bode plot of

Corner frequency at 1,2,3


Slope at each break frequency for magnitude plot

| Frequency | small | 1 | 2 | 3 |
|-------------|-------|-----|-----|-----|
| S | -20 | -20 | -20 | -20 |
| 1/(s+1) | 0 | -20 | -20 | -20 |
| 1/(s+2) | 0 | 0 | -20 | -20 |
| (s+3) | 0 | 0 | 0 | 20 |
| Total Slope | -20 | -40 | -60 | -40 |



Bode Plots to Transfer Function

- 1. We can also take the bode plot and extact the transfer fucntion from it.
- 2. First, determine the constant gain factor, k
- 3. Next, move from lowest to highest frequency noting the appearance and order of the poles and zeros.



$$|20\log|G(jw)| = 32dB \text{ at } w = 1r/s$$

 $|20\log|G(jw)| = -8dB \text{ at } w = 10r/s$

The slope can be defined as

$$\frac{-8 - 32}{\log(10) - \log(1)} = -40dB$$

The transfer function can written as G(s)=K/s^2

$$32 = 20 \log K - 40 \log 1$$

$$K = 10^{\frac{32}{20}} = 39.8$$

$$G(s) = 39.8/s^{2}$$

Find the transfer function- Try at Home

