

EV Charging Troubleshooting Instructions Document

Introduction

This document contains standard troubleshooting procedures for common EV charging-related issues. These instructions are intended to help support teams guide customers effectively and escalate issues whenever required.

1. Manual Release Playbook

Issue Scenario

Gun stuck and unable to release the charging cable.

Instructions

1. Stop the charging session from the ChargeMOD app.
 2. Use the vehicle key to lock and unlock the vehicle 3 times, then try removing the gun.
 3. If the gun is still not released, press the unlock button on the vehicle dashboard 2 times and try removing the gun again.
 4. Turn the vehicle ignition ON and try removing the gun.
(This step should only be tried for Tata vehicles.)
 5. If the issue still persists, apply the brake and engage the hand brake.
Then turn the vehicle ignition ON and wait for 10 seconds.
After that, turn the ignition OFF and release the hand brake.
(Release the brake only if the vehicle will not move.)
Then try removing the gun again.
(This step should only be tried for Tata vehicles.)
 6. If no other charging sessions are running at the station, restart the charger by turning the machine power OFF and ON.
 7. Alternatively, after restarting the machine, when the gun status changes to "Preparing," start and stop the charging session once again, then unlock and try removing the gun.
 8. If the issue is still not resolved, explain the manual release option to the customer or share the manual release video/instructions.
-

2. Handshake Timeout Instructions

Issue Scenario

Preparing state for more than 2 minutes OR Preparing → Finished without entering Charging state.

Instructions

1. Confirm whether the vehicle ignition is OFF, the brake is applied, the hand brake is engaged, and the vehicle is locked using the key.
 2. Remove the gun from the vehicle and reconnect it properly once again.
 3. Press and hold the gun firmly into the vehicle charging port and initiate the charging session within 40 seconds.
 4. If another connector is available, ask the user to try charging using the other connector.
 5. If the same issue continues, ask the user to move the vehicle slightly forward or backward and try charging again.
 6. If the charger supports reset, perform a charger reset. Otherwise, turn the machine OFF and ON, then try charging again.
 7. If the issue repeats, ask the user to try another connector on the same charger or a nearby charger.
 8. If the issue is still not resolved, ask the user to try another station. Inform the technical team to monitor the charger.
-

3. Low SoC Charging Instructions

Issue Scenario

Vehicle refusing DC fast charging due to very low State of Charge (SoC below 15%).

Instructions

1. Ask the user to move the vehicle slightly forward and backward, then try charging again.
2. Press and hold the gun firmly into the vehicle charging port and initiate the charging session within 40 seconds.
3. If another connector is available and free on the charger, ask the user to try charging using the other connector.
4. If the charger supports reset, perform a clear cache and reset operation. Otherwise, turn the machine OFF and ON, then try charging again.

5. If the vehicle is still not charging, ask the user to increase the battery level by around 10% using an AC charger and then retry DC charging.
 6. If AC charging is not available, suggest using a portable charger with a 3-pin socket if available.
-

4. Loose Gun / Loose Connector Instructions

Issue Scenario

Charger status continuously changing between Available and Preparing without reaching Charging state.

Instructions

1. During charging initiation, try removing the gun once.
 2. If the gun can be removed easily, inform the customer that the gun is not locked properly and the issue is due to a loose connection.
 3. Reconnect the cable properly and ensure that the vehicle is locked.
 4. Press and hold the gun firmly into the vehicle charging port and initiate the charging session within 40 seconds.
 5. If another connector is free and available on the machine, ask the user to try charging using the other connector.
 6. Ask the user to move the vehicle slightly forward and backward, then try charging again.
 7. If the machine supports reset, perform a clear cache and reset operation. Otherwise, turn the machine OFF and ON, then try charging again.
 8. If a manual lock option is available, try using it. Otherwise, share the related manual lock video/instructions with the customer.
 9. If the issue is still not resolved, ask the user to try AC charging first and then retry DC charging. If the issue still continues, suggest another available station.
 10. If the same issue has been reported by other customers on this machine, report it to the technical team.
-

5. Supply Side Issue / Voltage Issue Instructions

Issue Scenario

Machine fault showing OR charging stopping due to a supply side issue.

Instructions

1. Check the machine display. Confirm whether the machine display is ON, the network is connected, and whether any error message is being displayed.
 2. If everything appears normal, check the panel box and confirm whether 3-phase supply is available and the voltage is proper.
 3. If there is a voltage issue or supply is missing in any phase, inform the customer that it is a supply side issue and charging can resume only after the power supply becomes stable.
 4. If required, suggest a nearby available charging station to the customer.
-

6. Charger Disconnect / Network Issue

Instructions

Issue Scenario

Charger showing “Disconnected” during the charging session.

A. Charger Showing Disconnected

Instructions

1. Check whether the machine display is ON.
2. If other chargers are available at the station, check whether all chargers are disconnected.
Also confirm whether all chargers got disconnected at the same time.
3. Check whether supply is available in all 3 phases.
4. Check whether the network is connected on the machine display and whether the network symbol is showing properly.
5. If the network is not connected, turn the machine power OFF from the panel box, wait for 10 seconds, and turn it ON again.
6. If the network does not reconnect even after waiting for 10 minutes, guide the customer to another available station.
7. Report the issue to the technical team.

B. Network Disconnect During Charging

Instructions

1. Check the last log. If the current time log is not available, confirm that the charger is disconnected.
 2. Inform the customer that the issue is due to a network disconnection.
 3. If the charging needs to be stopped, ask the customer to press the emergency button and turn it to the right to release it, then remove the gun.
(Perform this step only if no other vehicles are charging on the charger.)
 4. If that does not work, turn the machine power OFF from the panel box to stop charging.
(Perform this step only if no other vehicles are charging on the charger, or only after getting permission from customers whose charging sessions are active.)
-

C. Machine Trip Issue

Instructions

1. Confirm whether the machine is completely OFF.
 2. Check whether supply is available in all 3 phases.
 3. If supply is available, check the panel box.
If it can be opened, check whether any breaker has tripped.
 4. If a breaker is tripped, turn it ON and check whether the machine powers ON properly.
 5. If no external breaker issue is found, inform that the trip may be from inside the machine and a technician needs to inspect it.
 6. Report the issue to the concerned person / technical team.
-

7. Vehicle-wise Gun Lock Release Instructions

MG Vehicles

Instructions

1. Check whether the charging gun status is showing as “Finishing”.

2. Check whether the vehicle is unlocked.
If yes, use the remote key to lock and unlock the vehicle 3 times.
Then gently push the gun inward once and try removing it.
 3. **For Windsor EV:**
Turn the vehicle ignition mode ON.
Press and hold the brake pedal while trying to remove the gun.
 4. If it is a single-gun machine, press and release the emergency button once, then try removing the gun.
 5. If the gun is still not removed, turn OFF the machine
(*only if no other vehicle is charging at the station*)
and try removing the gun again.
 6. If the gun is still not released after turning OFF the machine, turn the panel ON again.
When the machine screen shows “Preparing” status, start and stop the charging session once.
After the status changes to “Finishing”, try removing the gun again.
 7. As the next step, turn the vehicle completely OFF and central lock the vehicle.
Wait for 5 minutes, then unlock the vehicle and try removing the gun again.
 8. If the issue is still not resolved after trying all the above steps, inform the customer to contact the showroom/service center.
-

BYD Vehicles

Instructions

1. Check whether the charging gun status is showing as “Finishing”.
 2. Check whether the vehicle is unlocked.
If yes, use the remote key to lock and unlock the vehicle 3 times.
 3. Then gently push the gun inward once and try removing it.
 4. If it is a single-gun machine, press and release the emergency button once, then try removing the gun.
 5. If the gun is still not removed, turn OFF the machine
(*only if no other vehicle is charging at the station*)
and try removing the gun again.
 6. If the gun is still not released after turning OFF the machine, turn the panel ON again.
When the machine screen shows “Preparing” status, start and stop the charging session once.
After the status changes to “Finishing”, try removing the gun again.
 7. As the next step, turn the vehicle completely OFF and central lock the vehicle.
Wait for 5 minutes, then unlock the vehicle and try removing the gun again.
-

Mahindra Vehicles

Instructions

1. Check whether the charging gun status is showing as “Finishing”.
 2. Check whether the vehicle is unlocked.
If yes, use the remote key to lock and unlock the vehicle 3 times.
 3. Then gently push the gun inward once and try removing it.
 4. If it is a single-gun machine, press and release the emergency button once, then try removing the gun.
 5. If the gun is still not removed, turn OFF the machine
(*only if no other vehicle is charging at the station*)
and try removing the gun again.
 6. If the gun is still not released after turning OFF the machine, turn the panel ON again.
When the machine screen shows “Preparing” status, start and stop the charging session once.
After the status changes to “Finishing”, try removing the gun again.
 7. As the next step, turn the vehicle completely OFF and central lock the vehicle.
Wait for 5 minutes, then unlock the vehicle and try removing the gun again.
-

Hyundai / Kia Vehicles

Instructions

1. Check whether the charging gun status is showing as “Finishing”.
 2. Press the vehicle unlock button 2 times and try removing the gun.
 3. If it is a single-gun machine, press and release the emergency button once, then try removing the gun.
 4. If the gun is still not removed, turn OFF the machine
(*only if no other vehicle is charging at the station*)
and try removing the gun again.
 5. If the gun is still not released after turning OFF the machine, turn the panel ON again.
When the machine screen shows “Preparing” status, start and stop the charging session once.
After the status changes to “Finishing”, try removing the gun again.
 6. As the final step, inform the customer to contact the showroom/service center.
-

Mercedes-Benz Vehicles

Instructions

1. Check whether the charging gun status is showing as “Finishing”.
2. Press the vehicle unlock button 2 times and try removing the gun.

3. If it is a single-gun machine, press and release the emergency button once, then try removing the gun.
 4. If the gun is still not removed, turn OFF the machine
(*only if no other vehicle is charging at the station*)
and try removing the gun again.
 5. If the gun is still not released after turning OFF the machine, turn the panel ON again.
When the machine screen shows “Preparing” status, start and stop the charging session once.
After the status changes to “Finishing”, try removing the gun again.
 6. As the final step, inform the customer to contact the showroom/service center.
-

Prepared By

Name: Athira S

Designation: Customer Support Manager

Date: 14/05/2026