

Notes:

- 1) Adaptor is the white adaptor used in lab.
- 2) FUSE in the output of the relay 1 is important, if RL1 fails, then the system may burn in case of there is no fuse!

 3) For caution, do not connect V_GND_in and V_GND_out for U2, for others, it is easier to connect pints V_GND_in to V_GND_out but not recommended!

 4) Do not try to understand rule 3, just connect as in the diagram:) Do not connect any of V_GND_in to V_GND_out.