

## Notes:

- 1) Adaptor is the white adaptor used in lab.
- 2) FUSE in the output of the relay 1 is important, if RL1 fails, then the system may burn in case of there is no fuse!

  3) For caution, do not connect V\_GND\_in and V\_GND\_out for U2, for others, it is easier to connect pints V\_GND\_in to V\_GND\_out but not recommended!

  4) Do not try to understand rule 3, just connect as in the diagram:) Do not connect any of V\_GND\_in to V\_GND\_out.