
MC-44DM/44DME TM-241A/E (MULTI FUNCTION MICROPHONE WITH AUTOPATCH)

MC-44DM/MC-44DME SCHEMATIC DIAGRAM




MC-44DM/MC-44DME PARTS LIST

Ref. No.	New parts	Parts No.		Description	
		A02-0898-18	Case (Front)	DTMF	М
		A02-0899-18	Case (Front)	DTMF (With TONE)	W
		A02-0901-08	Case (Rear)	DTMF	
		B50-8293-18	Instruction ma	nual	w
		B50-8289-18	Instruction mai	M	
		E30-2149-08	Curl cord		
		G13-0933-08	Cushion		
		K29-3165-08	Knob	PTT	
		K29-3167-18	Key top	DTMF	
		K29-3168-18	Knob	UP	
		K29-3169-18	Knob	DOWN	
SW2		S31-1422-08	Slide switch	LOCK	
SW1		S50-1431-08	Micro switch	PTT	
S7, 8		S59-1409-28	Switch	UP, DOWN	
		T91-0383-08	Microphone ele	ement (Condenser microphone)	

TM-241A/E

MC-44 (MULTI FUNCTION MICROPHONE)

MC-44 SCHEMATIC DIAGRAM




MC-44 PARTS LIST

Ref. No.	New parts	Parts No.		Description
		A02-0896-18	Case (Front)	
		A02-0900-08	Case (Rear)	
		B50-8293-18	Instruction ma	nual
		E30-2149-08	Curl cord	
	İ	G13-0933-08	Cushion	
		K29-3165-08	Knob	PTT
		K29-3168-18	Knob	UP
		K29-3169-18	Knob	DOWN
İ		K29-3170-08	Knob	CALL, VFO, MR, PF
SW2		S31-1422-08	Slide switch	LOCK
SW1		S50-1431-08	Micro switch	PTT
S7, 8		S59-1409-28	Switch	UP, DOWN
		T91-0383-08	Microphone el	ement (Condenser microphone)

TM-241A/E

MC-44E (MULTI FUNCTION MICROPHONE)

MC-44E SCHEMATIC DIAGRAM




MC-44E PARTS LIST

Ref. No.	New parts	Parts No.		Description
		A02-0897-18	Case (Front)	With TONE
		A02-0900-08	Case (Rear)	
		B50-8293-18	Instruction ma	nual
		E30-2149-08	Curl cord	
		G13-0933-08	Cushion	
		K29-3165-08	Knob	PTT
		K29-3168-18	Knob	UP
		K29-3169-18	Knob	DOWN
		K29-3170-08	Knob	1750, VFO, MR, PF
SW2		S31-1422-08	Slide switch	LOCK
SW1		S50-1431-08	Micro switch	PTT
S7, 8		S59-1409-28	Switch	UP, DOWN
		T91-0383-08	Microphone el	ement (Condenser microphone)

TM-241A/E

TSU-6 (CTCSS UNIT)

TSU-6 EXTERNAL VIEW



TSU-6 PARTS LIST

Ref. No.	New Parts	Parts No.	D	escription				
de imus	CTCSS UNIT (X52-3100-00)							
C1	NE HE	CK73FB1H102K	Chip C	1000pF	K			
C2		C92-0507-05	Tantal	4.7µF	6.3WV			
C3	P	C92-0520-05	Tantal	22µF	4.0WV			
C4, 5		CK73EB1E104K	Chip C	$0.1\mu F$	K			
C6		CK73EB1H223K	Chip C	0.022µF	K			
C7		CK73EB1E104K	Chip C	0.1µF	K			
C8, 9		CC73FCH1H150J	Chip C	15pF	J			
C10	No. of the last	CK73FB1H102K	Chip C	1000pF	K			
C11		CK73FB1E473K	Chip C	0.047µF	K			
C12	P-9198	C92-0507-05	Chip tan.	4.7µF	6.3WV			
C13		C92-0534-05	Chip tan.	33μF	4.0WV			
CN1		E40-5121-05	Pin connec	ctor (10P)				
×1		L77-1313-05	X'tal resonator 4.194304MF		304MH			
R1-10		RK73FB2A000J	Chip resist	or				
R12-14		RK73FB2A000J	Chip resist	or				
VR1		R12-3460-05	Trimming	pot. 33kΩ	:			
Q1		DTC144TK	Digital trai	nsistor				
Q2		DTA114EK	Digital trai	nsistor				
Q3		2SC2712(GR)	Chip trans	istor				
IC1		MN6520	IC					
IC2		MN4094BS	IC					

TSU-6 REFERENCE DATA

Tone frequency and MN6520 (IC1) relationship

Thought to the	MN6520 terminal					
Tone frequency	<u>S6</u>	S5	S4	<u>S3</u>	S2	S1
(Hz)		٨	/N4094	BS termi	nal	
	Q1	Q2	Q3	Q4	Q7	QS
67.0	L	Н	Н	Н	L	Н
71.9	L	Н	Н	Н	L	L
74.4	L	Н	Н	L	Н	Н
77.0	L	Н	Н	L	Н	L
79.7	L	Н	Н	L	L	Н
82.5	L	Н	Н	L	L	L
85.4	L	Н	L	Н	Н	Н
88.5	L	Н	L	Н	Н	L
91.5	L	Н	L	Н	L	Н
94.8	Н	Н	Н	L	L	Н
100.0	Н	Н	Н	L	L	L
103.5	Н	Н	L	Н	Н	Н
107.2	Н	Н	L	Н	Н	L
110.9	Н	Н	L	Н	L	Н
114.8	Н	Н	L	Н	L	L
118.8	Н	Н	L	L	Н	Н
123.0	Н	Н	L	L	Н	L
127.3	Н	Н	L	L	L	Н
131.8	- Н	Н	L	L	L	L
136.5	Н	L	Н	Н	Н	Н
141.3	Н	L	Н	Н	Н	L
146.2	а Н з я	L	Н	Н	L	Н
151.4	Н	L	Н	Н	L	L
156.7	Н	L	Н	L	Н	Н
162.2	Н	L	Н	L	Н	L
167.9	Н	L	Н	L	L	Н
173.8	Н	L	Н	L	L	L
179.9	Н	L	L	Н	Н	Н
186.2	Н	L	L	Н	Н	L
192.8	Н	L	L	Н	,L	Н
203.5	Н	L	L	Н	L	L
210.7	Н	L	L	L	Н	Н
218.1	Н	L	L	L	Н	L
225.7	Н	L	L	L	L	Н
233.6	Н	L	L	L	L	L
241.8	L	Н	Н	Н	Н	Н
250.3	L	Н	Н	Н	Н	L

Table 1

TSU-6 FINE ADJUSTMENT OF TONE FREQUENCY

The tone frequency can be fine adjusted with an interval of 0.5% step over the range of 0 to +1.5%. Ground the T1 (pin 10) and T2 (pin 9) of IC1 to obtain the desired frequency.

T2	Т1		1
X	X	0%	1
×	0	+0.5%	1
0	X	+1.0%	1
0	0	+1.5%	
X	X O X	+0.5%	

O: GND, X: OPEN

Table 2