COMS20001 lab. worksheet: week #14

• Both the hardware and software in MVB-2.11 is managed by the IT Services Zone E team. If you encounter a problem (e.g., a workstation that fails to boot, an error when you try to use some software, or you just cannot log into your account), they can help: either talk to them in room MVB-3.41, submit a service request online via

http://servicedesk.bristol.ac.uk

- or talk to the dedicated CS Teaching Technologist, Richard Grafton, in room MVB-2.07.
- We intend this worksheet to be attempted, at least partially, in the associated lab. session. Your attendance is important, since this session represents a central form of feedback and help for COMS20001. Perhaps more so than in units from earlier years, *you* need to actively ask questions of and seek help from either the lectures and/or lab. demonstrators present: passively expecting them to provide solutions is less ideal.
- The questions are roughly classified as either L (for coursework related questions that should be completed in the lab. session), or A (for additional questions that are entirely optional). Keep in mind that we only *expect* you to complete the first class of questions: the additional content has been provided *purely* for your benefit and/or interest, so there is no problem with nor penalty for totally ignoring it (since it is not directly assessed).

Before you start work, download and unarchive the file

http://www.ole.bris.ac.uk/bbcswebdav/courses/COMS20001_2015/csdsp/os/sheet/lab/lab-2_q.tar.gz

somewhere secure^b in your file system: it is intended to act as a starting point for your own work, and will be referred to in what follows.

^aExecute the command tar xvfz lab-2_q.tar.gz from a BASH shell (e.g., in a terminal window), or use the archive manager GUI (available by using the menu Applications→Accessories→Archive Manager or directly executing file-roller) if you prefer.

^bFor example, the Private sub-directory in your home directory.

Q1[L]. This question acts as a practical exploration of interrupts, interrupt handling and system calls. Doing so demands some understanding of the hardware/software interface, meaning the content of this worksheet a) has more low-level detail than some others, is b) is important because it act as a basis on which most higher-level functionality is built on.

Although the worksheet concludes with a set of challenges relating to experimental exploration, the fundamental goal throughout is improved understanding of the material. Put another way, the work you do will be biased toward reading and understanding rather than programming at this point. It is crucial *not* to view this as optional effort: carefully working through what is, admittedly, a detailed worksheet will allow you to more easily and rapidly engage with the intellectual vs. engineering challenges involved.

Q1–§1 Explore the archive content

As shown by Figure 1, the content and structure of the archived material provided matches the worksheet from week #13.

Q1-§2 Understand the archive content

image.1d Figure 3 illustrates the linker script image.1d. It controls how 1d produces the kernel image from object files, which, in turn, stem from compilation of the source code files; the resulting layout in memory is illustrated by Figure 2.

interrupt.[sh] Figure 4 and Figure 6 illustrate the header file interrupt.h and source code interrupt.s.
Noting the former now has some content, unlike the worksheet from week #13, the latter can be considered as two parts:

• The bottom part supports initialisation of the interrupt handling mechanism, i.e., how interrupt handlers will be invoked. The existence of this part is motivated by a problem: in order to function correctly, we know the interrupt vector table needs to be placed at address $00000000_{(16)}$. *However*, due to the way QEMU works (i.e., the fact it will load the kernel image at address $70010000_{(16)}$) it cannot be loaded *directly* at this address. The solution is to load it somewhere *else* instead, then copy it into place.

- Lines #42 to #49 define the 8-entry interrupt vector table, with one entry per interrupt type.
- Lines #55 to #65 implement a function table_copy that copies the interrupt vector table to address 00000000₍₁₆₎.
- Lines #74 to #84 implement two functions irq_enable and irq_unable which enable and disable IRQ interrupts respectively; since these have global scope, and have a matching prototype in interrupt.h, all of the high-level functions in kernel.c can use this low-level functionality without resorting to inline assembly language.
- The top part captures three low-level interrupt handler implementations, one for each type that could be invoked using the interrupt handling mechanism described above.
 - Lines # 6 to #14 implement handler_rst: this function is similar to the one found in the worksheet from week #13, except that it now a) starts by calling table_copy, then b) initialise both the SVC and IRQ mode stacks, before finally c) invoking kernel_handler_rst.
 - Lines #16 to #22 implement handler_irq, while lines #24 to #30 implement handler_svc. These functions are similar in form: they handle the two remaining types, namely IRQ and supervisor call interrupts. Using handler_irq as an example, it a) corrects the return address per the ARM documentation, b) pushes all caller-save registers to the IRQ mode stack, c) invokes kernel_handler_irq, then, after it returns, d) pops all caller-save registers from the IRQ mode stack, before finally e) returning to wherever execution was stopped in order to handle the interrupt.

kernel.[ch] Figure 5 and Figure 7 illustrate the header file kernel.h and source code kernel.c. The latter implements three high-level interrupt handler functions: in this example the goal is to demonstrate when such interrupts are raised and handled (rather than perform some meaningful behaviour), so each function is fairly simple.

- kernel_handler_rst is invoked by handler_rst every time a reset interrupt is raised and needs to be handled.
 - Lines #13 and #14 configure the emulated UART, namely the PL011_t instance UART0: the comments
 briefly describe each step, which each amount to setting various device registers appropriately. In
 short, the UART is configured st. it raise an interrupt each time it receives a byte.
 - Lines #16 to #19 configure the GIC, namely the GICC_t and GICD_t instances GICC0 and GICD0: the comments briefly describe each step, which each amount to setting various device registers appropriately. In short, the GIC is configured st. the UART interrupt signal (i.e., #44) is distributed (or connected) to the processor IRQ interrupt signal.
 - Line #21 then enables IRQ interrupts wrt. the processor: this unmasks the IRQ interrupt signal, meaning any interrupt from the GIC is now "visible" to and so handled by the processor.
 - Lines #31 to #37 are somewhat similar way to the worksheet from week #13, in the sense an infinite outer while loop implies the function never returns. Each iteration executes
 - * a number of nop instructions intended to realise a delay for some fixed period, then
 - * a svc instruction intended to raise a supervisor call interrupt, i.e., perform an system call.
- kernel_handler_irq is invoked by handler_irq every time a IRQ interrupt is raised and needs to be handled. Three of the steps in [1, Section 4.11.3] are needed here, which are numbered to match. Although the steps numbered #2 and #5 are standard boiler-plate we need to include for *any* handler of this type, #4 deals specifically with interrupts from the UART: it first tests whether or not the interrupt stems from the UART, then, if so, takes some action to handle it. In this case, the action is captured as follows:
 - Line #50 receives some input via the PL011_t instance UART0 by invoking PL011_getc: since we know the interrupt must have been raised due to a byte being received, we assume this is the case. That is, we omit any checking as why the UART raised the interrupt, which might be required in a general context.
 - Lines #52 to #55 transmit some output via the PL011_t instance UARTO by invoking PL011_putc, thus
 demonstrating the interrupt was handled.
 - Line #57 is fairly crucial: it basically signals to the interrupt source, in this case the UART device, that the interrupt it has raised was handled. Put another way, it clears (or cancels) the interrupt and so resets the interrupt generation logic in the device; this means it will then generate subsequent interrupts rather than mistakenly getting "stuck" with the current one.




Figure 1: A diagrammatic description of the material in lab-2_q.tar.gz.

• kernel_handler_svc every time a supervisor call interrupt is raised and needs to be handled: this occurs whenever a svc instruction is executed. Line #71 transmits some output via the PL011_t instance UARTO by invoking PL011_putc, thus demonstrating the interrupt was handled.

Q1-§3 Experiment with the archive content

Following the same approach as in the worksheet from week #13, first launch QEMU then gdb. Issue the

continue

command to gdb in the debugging terminal so the kernel image is executed. Assuming the emulation terminal has the UI focus, you should observe two different behaviours:

- periodically, without any user interaction, a 'T' character is written to the emulation terminal: this demonstrates a supervisor call interrupt was raised and then handled first by handler_svc and then by kernel_handler_svc, and also
- whenever you press a key, a 'K' character plus the key pressed are written to the emulation terminal: this demonstrates an IRQ interrupt was raised (i.e., by the UART) and then handled first by handler_irq and then by kernel_handler_irq.

Note that wrt. execution of instructions by the processor, pressing a key is an asynchronous event: it could occur at *any* time. However, a supervisor call interrupt is synchronous since it occurs as the result of executing a svc instruction. Put another way, the behaviour of this kernel could be summarised as follows. It is basically "stuck" in an infinite loop, which it enters when the processor is reset. The loop periodically executes a svc instruction to cause a supervisor call interrupt (and therefore write a 'T' character). However, when a key is pressed, it suspends this behaviour to handle the resulting IRQ interrupt (by writing a 'K' character); once complete, execution of the loop is resumed.

Q1-§4 Next steps

There are various things you could (optionally) do next: here are some ideas.

An effective way to gain insight into an example of this type, in which the timing of events is crucial, is by drawing a time-line to illustrate said events. For example, by including a) when events (e.g., interrupts) occur, b) what the processor and memory (e.g., stack) state is, and c) what instructions (i.e., what function) is being executed at different periods of time, one can align the observed behaviour with the source code. Try to construct such a diagram for this example, limiting the duration to the first few seconds at most (but including at least one key press event).




Figure 2: A diagrammatic description of the memory layout realised by image.1d.

- **Q2[A].** Consider the printf (for "print formatted") function, which is provided by the **C** standard library. In reality, each invocation of printf (and variants) results in a 2-step process: it
 - parses the format string, populating it with the (variable length list of) arguments, then
 - perform a system call into the kernel st. the formatted result is written to a file descriptor (e.g., typically stdout by default).

From the perspective of a caller, this approach offers a convenient API. For example, the traditional "hello world" program is (by design) fairly trivial:

```
#include <stdio.h>
int main( int argc, char* argv[] ) {
  printf( "hello world\n" );
  return 0;
}
```

To achieve the required result, however, printf must interact with the kernel by performing system calls. So what if printf were unavailable? This question asks you to develop an alternative to the program above. The goal is to write the string "hello world" to stdout as before, but to do so by performing the system calls printf would *yourself*; the rationale is that doing this forces you to explore and hence understand the user-facing side of the system call interface, which complements the kernel-facing side studied via QEMU.

Your exact solution will depend on various concrete facts, such as the kernel (e.g., Windows vs. Linux) and processor type (e.g., ARM vs. x86). So, for the sake of concretness, imagine you develop your solution on a lab. workstation with a Linux 3.10.x kernel (viz. Centos 7) on an x86-64 (Core i7) processor. The ideal, step-by-step approach would be:

- Replace the implementation that uses printf with an equivalent that uses write; this is one step lower-level, since write is a wrapper around a system call of the same name.
- Replace the implementation that uses write with an equivalent that uses syscall; this is one step lower-level, since syscall is a generic way to perform any system call provided you know the system call identifier (i.e., which corresponds to write).

http://en.wikipedia.org/wiki/Hello_world_program

```
SECTIONS {
       /* assign address (per QEMU)
. = 0x70010000;
/* place text segment(s)
2
       .text : { kernel/interrupt.o(.text) *(.text .rodata) }
       /* place data segment(s)
        .data : {
                                                      *(.data
                                                                         ) }
8
9
        /* place bss segment(s)
       /* align address (per AAPCS) */
- ALIGN(8);
- ALIGN(8);
                                                      *(.bss
                                                                         ) }
10
11
       /* allocate stack for irq mode */
       . = . + 0x00001000;
tos_irq = .;
13
14
       /* allocate stack for svc mode */
. = . + 0x00001000;
15
16
       tos_svc = .;
17
```

Figure 3: image.ld

```
#ifndef __INTERRUPT_H
#define __INTERRUPT_H

// enable IRQ interrupts
extern void irq_enable();
// disable IRQ interrupts
extern void irq_unable();

#endif
#endif
```

Figure 4: kernel/interrupt.h

```
#ifndef __KERNEL_H
#define __KERNEL_H

#include <stddef.h>
#include <stdint.h>

#include "GIC.h"
#include "PL011.h"
#include "SP804.h"

#include "interrupt.h"

#endif
#endif
```

Figure 5: kernel/kernel.h

```
/* Each of the following is a low-level interrupt handler: each one is
     * tasked with handling a different interrupt type, and acts as a sort
* of wrapper around a high-level, C-based handler.
2
3
                                                  @ initialise interrupt vector table
    handler_rst: bl
                        table_copy
                                                  @ enter IRQ mode with no interrupts
8
                  msr
                        cpsr, #0xD2
                  ldr
                        sp, =tos_irq
                                                  @ initialise IRQ mode stack
10
                        cpsr. #0xD3
                                                  @ enter SVC mode with no interrupts
                  msr
11
                                                  @ initialise SVC mode stack
                        sp, =tos_svc
13
                  b1
                        kernel_handler_rst
                                                  @ invoke C function
14
                  b
                                                  @ halt
15
16
    handler_irg: sub
                        lr, lr, #4
                                                   @ correct return address
                  stmfd sp!, { r0-r3, ip, lr } @ save
                                                             caller-save registers
19
                        kernel_handler_irq
                                                  @ invoke C function
20
21
                  ldmfd sp!, { r0-r3, ip, lr } \, 0 restore caller-save registers
22
                  movs pc, lr
                                                  @ return from interrupt
23
24
    handler_svc: sub
                       lr, lr, #0
                                                   @ correct return address
25
                  stmfd sp!, { r0-r3, ip, lr } @ save
                                                           caller-save registers
26
27
                        kernel_handler_svc
                                                  @ invoke C function
28
29
                  ldmfd sp!, { r0-r3, ip, lr } @ restore caller-save registers
                  movs pc, lr
                                                   @ return from interrupt
31
32
    /* The following captures the interrupt vector table, plus a function
33
     * to copy it into place (which is called on reset): note that
34
35
       - for interrupts we don't handle an infinite loop is realised (to
     * to approximate halting the processor), and
* - we copy the table itself, *plus* the associated addresses stored
37
38
          as static data: this preserves the relative offset between each
39
         ldr instruction and wherever it loads from.
40
41
42
                                                                            vector -> SVC mode
    table_data: ldr pc, address_rst
                                                  @ reset
43
                                                   @ undefined instruction vector -> UND mode
44
                  ldr
                                                   @ supervisor call
                                                                            vector -> SVC mode
                        pc, address_svc
45
                  b
                                                  @ abort (prefetch)
                                                                            vector -> ABT mode
46
                  b
                                                   @ abort
                                                               (data)
                                                                            vector -> ABT mode
47
                                                   @ reserved
                  b
48
                  ldr
                        pc, address_irq
                                                   @ IRQ
                                                                            vector -> IRQ mode
49
                                                                            vector -> FIQ mode
50
51
    address_rst: .word handler_rst
52
    address_svc: .word handler_svc
53
    address_irq: .word handler_irq
54
    table_copy: mov
                        r0, #0
                                                  @ set destination address
                        r1, =table_data
                  ldr
                                                  @ set source
                                                                      address
57
                  ldr
                        r2, =table_copy
                                                  @ set source
                                                                      limit
58
59
                        r3, [ r1 ], #4
                                                  @ load word, inc. source
    table_loop: ldr
                                                                                   address
60
                        r3, [ r0 ], #4
                                                  @ store word, inc. destination address
                  str
61
                  cmp
                        r1, r2
63
                        table_loop
                                                  @ loop if address != limit
64
65
                  mov
                        pc, lr
                                                  @ return
66
67
    /* These function enable and disable IRQ interrupts respectively, by
     * toggling the 7-th bit of CPSR to either 0 or 1.
69
70
71
72
73
74
    .global irq\_enable
    .global irq_unable
    irq_enable:
                        r0,
                              cpsr
                                                   @ enable IRQ interrupts
75
76
77
                  bic
                        r0, r0, #0x80
                        cpsr_c, r0
                  msr
78
                  mov
                        pc. lr
79
    irq_unable: mrs
                               cpsr
                                                  @ disable IRQ interrupts
81
                        r0, r0, #0x80
82
                        cpsr_c, r0
83
84
                  mov
                        pc, lr
```

Figure 6: kernel/interrupt.s

```
#include "kernel.h"
2
 3
     void kernel handler rst() {
        /* Configure the mechanism for interrupt handling by
         * - configuring UART st. an interrupt is raised every time a byte is
         * - configuring GIC st. the selected interrupts are forwarded to the

* processor via the IRQ interrupt signal, then

* - enabling IRQ interrupts.
 8
10
12
                                    |= 0x00000010; // enable UART (Rx)
= 0x00000301; // enable UART (Tx+Rx)
13
        {\tt UART0->IMSC}
                                                                               (Rx) interrupt
14
        UARTO->CR
15
       16
                                                                                     interrupts
                                                                               (Rx) interrupt
18
19
20
21
        irq_enable();
22
23
        /* Force execution into an infinite loop, each iteration of which will
         ^{\ast} - delay for some period of time, which is realised by executing a
25
26
27

    * large, fixed number of nop instructions in an inner loop, then
    * - execute a supervisor call (i.e., svc) instruction, thus raising

28
             a software-interrupt (i.e., a trap or system call).
29
30
31
        while( 1 ) {
          for( int i = 0; i < 0x20000000; i++ ) {
   asm volatile( "nop" );</pre>
32
33
34
35
          asm volatile( "svc 0" );
36
37
38
39
       return;
40
41
     void kernel_handler_irq() {
43
       // Step 2: read the interrupt identifier so we know the source.
44
45
        uint32_t id = GICC0->IAR;
46
47
        // Step 4: handle the interrupt, then clear (or reset) the source.
48
49
       if( id == GIC_SOURCE_UART0 ) {
50
          uint8_t x = PL011_getc( UART0 );
51
          PL011_putc( UART0, 'K' );
PL011_putc( UART0, '<' );
PL011_putc( UART0, '<' );
PL011_putc( UART0, '>' );
52
53
54
55
56
57
58
59
          UART0 \rightarrow ICR = 0x10;
60
       // Step 5: write the interrupt identifier to signal we're done.
61
        GICC0 \rightarrow EOIR = id;
62
63
64
65
     void kernel_handler_svc() {
       /* Each time execution reaches this point, we are tasked with handling
 * a supervisor call (aka. software interrupt, i.e., a trap or system
66
67
68
         * call).
69
70
71
       PL011_putc( UART0, 'T' );
72
```

Figure 7: kernel/kernel.c

• Replace the implementation that uses syscall with an equivalent that uses inline assembly language; this is one step lower-level, since now you need to replicate what syscall itself does. This means using the system calling convention for the processor (e.g., x86) you intend to execute the result on.

If you really get stuck,

http://en.wikibooks.org/wiki/X86_Assembly/Interfacing_with_Linux

offers an introduction of sorts.

Q3[A]. strace (or "system trace") is a tool which can trace the systems calls made, signals received and resources used by some process (and any sub-processes). strace provides a vast range of functionality, but even a basic understanding of how to use it can help you understand and debug programs: it is particularly valuable when the associated source code is not available (so cannot be recompiled, and therefore potentially not easily debugged using gdb), or where an *executing* process needs to be debugged *without* (necessarily) interfering with or terminating it.

It *also* offers an excellent way to see how programs interact with the kernel, the details of which are normally (by design) abstracted by mechanisms such as the C standard library (per the question above). This question is vague and open ended: the goal is simply to point out strace exists. So, try it out: execute the command

strace ls

and marvel at how many (and which) system calls 1s needs to produce a list of files in the current directory. Based on this, think about some previous coursework from COMS10002: can you optimise your solution somehow based on what strace shows about how it behaves?

References

[1] ARM Limited. RealView Platform Baseboard for Cortex-A8. Technical Report HBI-0178, 2011. http://infocenter.arm.com/help/topic/com.arm.doc.dui0417d/index.html.