karma

User Guide



Version 4.3.2 | 12/2018

© Copyright 2018 by ERM Electronic Systems Ltd.

ERM Advanced Telematics

16 Haim Shapira st. Rishon LeZion, 7570418 Israel | Phone: 972-3-9413313 Fax: 972-3-9413316

http://ermtelematics.com | info@ermtelematics.com

Contents

1. Introduction to ERM Karma 4
1.1 Karma Functionality 4
2. Logging in to Karma 5
2. Find What You're Looking For 5
3. Ask Questions and Get Visual Answers 5
3. Know Your Karma 7
3.1 Vehicle Cards List 7
3.2 Zoom in For More Information 8
3.3 Vehicle Card Details 9
4. Ask a Question 11
5. Creating Reports 12
6. Editing Reports 16
7. Driving Behavior 16
8. karma Dashboard 19
8.1. Karma Dashboard Status 19
8.2. Sub-Fleets 19
8.3. How to Create Sub-Fleet Reports 20
8.4. Graphic View Mode 20
8.5. Notification Table 21
9. Adding POIs (Points of Interest) 22
10. Viewing and Editing POIs 23
11. Planning a Route 24
12. Creating Notifications 28
12.1 Creating a New Notification 28
12.2 Stages to Defining Notifications 29
13. Creating Your Own Shortcuts 29
13.1 Creating a Shortcut to a Question 29
13.2 Creating a Shortcut to a Report 31
14. Viewing and Editing Settings 33
14.1 Managing Users, Access, Drivers, and Vehicles 33
14.2 Adding New Fuel Details 34
14.3 Adding New Maintenance Details 35
14.4 Adding New Tires Details 36
15. Odometer Update 37

15.1 New Vehicle 37
15.2 Existing Vehicle 37
15.3 Changing from the Dashboard 37
16. More Karma Tips 38
17. Contacting Support 39

1. Introduction to ERM Karma

Karma is a revolutionary, easy-to-use fleet management system, which offers a fresh solution for a real-time reporting system for drivers, vehicles, and roads.

The intuitive design allows Karma to function like an everyday application, which can be easily customized to the user's specific needs.

The Karma concept was developed based on ERM's rich experience and deep understanding of the global fleet management, tracking, vehicle security and the telematics industry.

Karma is designed to provide immediate, real-time answers to fleet managers' and owners' questions.


1.1 Karma Functionality

With Karma, you can:

- Track your vehicles in real-time.
- Visually track your vehicles and focus on what you want to know.
- Simply ask your natural-language questions, and get detailed, visual answers in real-time.
- Generate detailed informative reports based on any of the Karma managed parameters, such as driver, vehicle, or events based on fuel, speed, driving behavior, temperature, and so on.
- Add POIs (points of interest) and plan the efficient route for a particular trip.
- Get notifications based on any of the Karma-managed parameters such as speed, drivers' routes, fuel status, driving behavior, geo fences, accidents events, location relative to points of interest, and so on.
- Have your drivers' behavior rated to better assess their performances.
- And much more…

2. Logging in to Karma

1. Login to Karma from your PC using the following URL: http://karma.online.
   Only use Google Chrome to access Karma.



2. Enter the credentials given to you by your ERM representative; and choose your preferred language.
3. Either press Enter, or click the green arrow to the right of the Password field.

2. Find What You're Looking For


Karma enables you to find the information you need in the most suitable way for you:

- Ask questions and get visual answers
- Generate reports according to specified parameters

3. Ask Questions and Get Visual Answers

On the Home Page, you can either:

- Type what you are looking for in the search field, and get a visual answer on the map.
- Generate reports by vehicles, drivers or roads.



Tip

- You can quickly start from the Quick Launch toolbar, on the top right, by clicking either the driver or vehicle icon.

A real-time vehicles overview is displayed with a list of all drivers and vehicles.


Example:



3. Know Your Karma


3.1 Vehicle Cards List

The Karma main screen presents a visual graphical view of the fleet/vehicles on a map. The Vehicle Cards List, displayed on the left, includes all fleet vehicles by vehicle ID or by driver, grouped by ignition status (on/off).




The example below illustrates a Vehicle Cards List presented by driver names.

There are nine vehicles with ignition ON and 29 with ignition OFF. By clicking any of the cards, the card expands and more details about the vehicle and the drivers are displayed.



3.2 Zoom in For More Information

Karma enables fleet managers to get a real-time snapshot of their fleet status, and then zoom in for more information. By clicking a vehicle icon on the map, or clicking any of the vehicle cards in the Vehicle Cards List on the left, more detailed information is displayed.



TM - Total values of current month

T1- Including Start Point (applicable after system refresh)

For vehicles with an eFuel unit, the fuel tank turns to red if the tank has less than 12% fuel.

Place the mouse on any vehicle icon, or click it, to display more information icon, including:

- ✓ Driver name
- ✓ Current speed
- ✓ Slope of the road
- ✓ Fuel status (only if ERM eFuel is installed in the vehicle)
- ✓ Last trip mileage
- ✓ Odometer
- ✓ Battery charge condition
- ✓ Battery life (SoH)
- ✓ Battery voltage
- ✓ Last trip max speed
- ✓ Eco driving grade
- ✓ Communication reception indication
- ✓ Live signal

It also displays external parameters, such as:

- ✓ Outside temperature
- ✓ Weather status icon
- ✓ Street view
- ✓ Local time
- ✓ Wind direction
- ✓ Wind speed



And more…

3.3 Vehicle Card Details


1. Choose one of the cards in the Vehicle Cards List to open the vehicle card. The Vehicle Card is the main window for detailed information about the vehicle, the driver and the last trip made.

   The Vehicle Card contains:





   For additional information, you can open any of the labels:

   - ✓ Status
   - ✓ Driver details
   - ✓ Vehicle details
   - ✓ Way details
   - ✓ Notifications
   - ✓ Reception status
   - ✓ Send commands (if available)











2. Click **View Last Trip** to view details of the vehicle's last trip on the map with a color-coded indication of speed, driving behavior, eco driving, idle time and other events.

   The colors meanings are specified in the tabs table which pops up during this scenario. The color codes represent different parameters, as shown in the following figure.



In addition, new event-based content is added to the Vehicle Card when Karma is asked to display content such as Driving Behavior, Accidents, and so on.

The example below is applicable to “Driving Behavior” and “Accidents” search term scenarios.




4. Ask a Question

Karma incorporates a unique way to experience fleet management. It enables generating reports on-the-fly, as well as presenting a live visual presentation of the fleet/vehicle on a map for a simple query.

Answers for natural language queries such as: “show moving vehicles” or “cars with engine off” or “speed events over 120” are immediately displayed on the map.

With Karma, you can find specific answers to many commonly asked questions. By typing what you are looking for, in simple words, a detailed, visual answer is provided, including additional related information.




You can use a single parameter query, such as "David Smith location"; or multiple parameter queries, such as: "show all refuels today" or "driving behavior David Smith yesterday".

For more query-related question options:

1. Click the ‘How to ask questions in the system?’ link at the Home Page, to view suggestions of relevant topics and questions that you can use.



2. Expand a Question Type, and then select a specific question.



The query syntax is displayed in the search field without the variable. Variables are displayed in the query in *Italics*. To change the variable value, enter a new variable value in the search field in the same location as the query. For example, to replace driver's name with *John Noise* in the 'max speed *Thomas George John* yesterday' query, edit the text in the search field to: **max speed John Noise yesterday**.


See also "Creating a Shortcut to a Question" section.

5. Creating Reports


To generate reports:


1. Click either the **Driver** or **Vehicle** icon on the left side of the Home Page to generate a report, according to specified parameters.

   Subcategories are displayed horizontally next to your selection.




2. Click a subcategory. For example, if you selected Drivers, you might want to generate a report about Speed.
3. Define the period covered by the report in the left panel.
4. Select the relevant vehicles/drivers in the table.
5. Enter text in the Filter field to narrow which vehicles/drivers appear in the list.
6. Click **Report**.
   A generated tabular report is displayed.






Note: For Driving Behavior only, when you click Report and click View for any of the report rows, you have the option to select the **Bar Chart** or **Line Chart** checkbox.




7. Click the expand icon to view more information on a specific record.
   The example below demonstrates how the fuel used is displayed for a specific driver.



8. For each record, click the View button to view the specific event on the map, or relevant report, and receive additional information.

The results are displayed on the map.



9. Click Create Shortcut if you want to send a shortcut to generate the report in the future. Shortcuts are displayed in the lower-right corner of the Home page.



Icons which include an envelope indicate that these reports are configured to be sent by email. You can:

- ✓ Click any of the Report shortcuts to generate the report.
- ✓ Click the  icon to display the Edit and Delete options. For more details, see "Editing Reports".

See also "Creating a Shortcut to a Report".

Tip

- In the View page, click the Back icon at the bottom of the map to return to the report.

6. Editing Reports


1. Click the  icon on one of the Report shortcut icons on the Home page and then click Edit. The Shortcut Creation page is displayed with the stages displayed in the Navigation Panel.
2. Proceed with redefining the report and the shortcut, as described in "Creating a Shortcut to a Report".

7. Driving Behavior

The Driving Behavior feature analyzes different maneuvers that the eSafe device (installed in the vehicle) reports. Driving Behavior events include all abnormal maneuvers, such as turning while accelerating, aggressive braking, driving harshly on bumps, and so on. The Karma Driving Behavior report provides a relative grade for each driver's driving behavior for the period specified for the report.

You can generate the Driving Behavior report in one of the following ways:

- By typing in the search field any question related to driving behavior, such as: 'Driving behavior events' / 'Driving behavior last week' / 'David's driving behavior'




Driver Behavior Events

Maneuver Type

Event by Location. Option to View Trip

To view more details:


1. Click **Way Details** in the Vehicle Card.
2. More details are displayed in the Vehicle Card and Trip Details.



3. Generating driving behavior report:
   - Click on the **Drivers** icon on the Home Page.
   - Click on the **Behavior** icon.




The behavior lists the relative behavior status to group behavior, and relative grades for each driver.
Example:



Click any of the blue text links to view more details. Each route has indicators of the Start and End positions, and color-coded sections to indicate vehicle speed, driving behavior score, idle time and maneuvers.

When you click the **View** next to a row, or **Print** in the area above the table, the Driving Behavior report for the selected driver is displayed, as shown.

Note: This schematic does not show the option for selecting a Bar Chart or a Line Chart. For details on generating a Driving Behavior report, see "Generating Driving Behavior Reports".




8. karma Dashboard

- Click on the Fleet icon on the desktop



- The Karma dashboard will open

8.1. Karma Dashboard Status



1. The user can select which vehicles to view according to their status.
2. By default, Moving Vehicles, Ignition On, Idle, Ignition Off, Asset are the selection options.
3. By clicking on Select All, vehicles that are disconnected from the server will also be selected.
4. By clicking on Switch View, the user will be able to see the previous fleet view mode.
5. The Filter text box is a searching tool for users in order find sub fleets by their predefined name.

8.2. Sub-Fleets

1. On this screen, the user can see every vehicle in his fleet, divided to sub-fleets.
2. The top sub fleet headline represents a collection of the user's vehicles that were not belong to any of his other predefined sub-fleets.
3. The information is displayed on a table which contains the following columns: Vehicle, Driver, Speed, Fuel Percentage (%) and Address.
4. By Clicking the sub fleet view button will display that fleet's vehicles on a map.
5. Each of the table's rows contains vehicle information and a View button. By clicking the View button, the user is redirected to the vehicle's location on a map.

6. The sub fleets screen is refreshed every 30 seconds (visual refresh notification: the table collapses and expands automatically).
7. The table can be resized horizontally and vertically.

8.3. How to Create Sub-Fleet Reports

1. Click on fleet icon 
2. Click on switch view icon 


.
3. Go to 

.
4. Select the vehicle in the sub-fleet by dragging then into the sub-fleet area.
5. Click on 


.
6. Select the Icon and write the name for this sub-fleet and save.
7. On the main page a new icon is created.
8. By clicking on the icon, sub- fleet will appear on the dash-board.

8.4. Graphic View Mode

1. The information is displayed according the car status side bar.
2. The graphic mode is refreshed simultaneously with the sub fleet table.
3. There are three graphic modes: Speed, Eco, and Fuel.
4. Speed
   - When the mouse indicator is over a column, the Vehicle License Plate and Max Speed will be displayed.




   - By clicking a column, the user is redirected to the vehicle's location on a map.
5. Eco
   - By default, DVO and ECO are selected. The user has the option to deselect one of them.
   - DVO and ECO information are displayed in percentage.



- By clicking a column, the user is redirected to the vehicle's location on a map.


6. Fuel
   - Fuel Tank Quantity is displayed in percentage (%).
   - Fuel Tank Capacity and Fuel Quantity in % information is displayed.



   - By clicking a column, the user is redirected to the vehicle's location on a map.
   - In case it is grey, it means eFuel is not installed.

8.5. Notification Table

1. The following table contains the list of notifications that were created in the notifications section.
2. Each page contains up to 50 records per page, it is possible to scroll between the pages.
3. The table has the following columns: Vehicle, Driver, Type, Description, Location, Time, Info/ACK, and Status Remark.
4. Vehicle- Vehicle details
5. Driver – Driver's details
6. Type – Maneuver type
7. By clicking the notification type link, the following window opens



8. Description - The text to be sent when the notification occurs.
9. Location - The vehicle's location when the notification occurred.
10. Time - The date and address the maneuver occurred.
11. Info/ACK - Karma Notification App type.
12. Status Remarks – The user's remarks added to the notification.

9. Adding POIs (Points of Interest)

To add POIs for the routes your Fleet of vehicles requires:

1. Click the Road icon 


.

   Two additional icons are displayed on the screen.


2. Click the POI icon 


.

   A color-coded list of POIs is displayed.




   Note: You can click the **Filter** icon  in any of the column headers to filter the list. Enter free-text in the field, and select either Contains or Start With from the drop-down list.



3. Click 


.

   The POI Details window pops up.



4. Enter an address, name, and description for the POI.
5. Select a color according to your company's coding scheme.
6. Select the Fleet to which the POI pertains.
7. You can add Point of Interest directly on the map.

8. At the top right side of the map, click on POI.



9. Click on the +
10. A new POI is added to the center of the map.
11. The user can edit and fill in all the details according to his requirements, and then click "save".
12. The POI will appear on the map in adjustment with its selected color.

10. Viewing and Editing POIs

To view and edit existing POIs:

1. Click the Road icon 


.

   Two additional icons are displayed on the screen.


2. Click the POI icon 

.


   A color-coded list of POIs is displayed.



3. Click **View** for a POI to see it on the map.
   The POI is displayed on the map with the details in a balloon.



4. Click **Edit** if you want to make changes.
   The POI details become editable.



5. You can drag and drop the location of the arrow on the map.

   The address field gets updated. After you drop the arrow, you can also edit the Address field manually to ensure that the exact address is used.

6. Click **Save**.

11. Planning a Route

To plan the most efficient route for a particular trip:


1. Click the **Road** icon 


.

   Two additional icons are displayed on the screen.

2. Click the Route Planning icon 


   The Route Planning screen is displayed.



3. Click 

.

   The Route Planning page is displayed with a Navigation Panel to help guide you through the process.




4. Assign someone to the trip by selecting the vehicle/driver in the table provided.
   You can filter the list by vehicle or driver.
5. Enter a name for the trip.
6. Select whether you want to schedule the trip for **Today** or **Tomorrow**.

   The 'From' and 'To' dates and times are automatically populated


   a) Click the Calendar icon to open the Date Picker.

   b) Click the Clock icon to select a time.


7. Click **Next**.
   The Start Plan stage is displayed.




Note: From the Start Place through the Places stages, you can click the Filter icon in any of the column headers to filter the list. Enter free-text in the field, and select either **Contains** or **Start With** from the drop-down list.



8. Select a Start Place, and click **Next**.
   The End Place stage is displayed.




   The Places stage is displayed.




9. Select all POIs between the Start Place and the End Place.
   To Select All POIs, select the checkbox in the upper left corner of the table.

10. Click **Next**.
    The Advised Route is displayed on the map.
    Note: The map is displayed when you click Next, but not if you click Finish.




The right panel includes information on the number of POIs, the distance, and the estimated time. It also provides driving directions for each stop on the route.

11. Click **Notifications** (if you want to define one).
    The following window is displayed.



12. Define how long the vehicle needs to be inside or outside the POI, or within a certain radius.
13. Enter the message text to send.
14. If you toggle the Popup to on, you also need to select whether the notification is sent as Info or ACK (which requires the device to send an acknowledgement to the server).
15. Click **Accept**.
16. Click **Finish** in the Advised Route page. The Route Plan is added to the list of routes.




12. Creating Notifications

Using Notifications, you can receive quick updates about almost any information available on Karma.

12.1 Creating a New Notification


To create a new notification:

1. On the Home Page, click the **Notification** icon .
2. Click the **Create/Edit** icon .
   The following screen is displayed.



A Navigation Panel is displayed with the sequence of stages for defining notifications.

3. In the list stage, select the vehicle/s or Driver/s for which you want to receive notifications



For an overview of the process, see the next section - Stages to Define Notifications.

12.2 Stages to Defining Notifications

Defining Notifications involves five stages, as indicated in the Navigation Panel on the left.


1. **List** - Select the vehicle/driver for which you want to receive notifications.
2. **Triggers** – Select the triggers, for example: speed, battery, fuel, and so on; and define the specific parameter values that trigger a notification.
3. **Cycles** – Select the time period for which you want to receive notifications.
4. **Perform** – Add email addresses where notifications are sent.
5. **Summary** – Review the notification summary, and click **Finish** to confirm.

* Notifications are displayed by ID, which is determined by the creation date.

13. Creating Your Own Shortcuts

With Karma, you can assign your own custom shortcuts to reports or to questions (with the results displayed on the map).

Shortcuts are located on the lower right side of the Home Page.



By default, there are two predefined shortcuts which cannot be altered:

- ✓ **Vehicles** – Presents all fleet vehicles on the map in real-time.
- ✓ **Fleet** – Presents driver specific Vehicle Cards including current status, driver details, vehicle details and way details.

There are two ways to create a report shortcut:


1. When you are viewing any particular report, you can click the Create Shortcut button.
2. Launch the Create Shortcut process from the Home page, as described in:
   - Creating a Shortcut to a Question
   - Creating a Shortcut to a Report

13.1 Creating a Shortcut to a Question


To create a report shortcut from the Home page.

1. Click the **Add new shortcut** icon  in the lower right corner of the homepage.
2. Select an icon for the new shortcut. You may use the same icon more than once.
3. Type the shortcut description and click **Next**; for example, type **Refuel events**.

4. Click **Next**



5. Enter your query, for example: Fuel events.
   A list of questions is displayed:




6. Select a question and click **Next**.
   Once you define a question, the wizard skips the Report stage.

7. Review the Shortcut Summary, and click **Finish** if no other modifications are required.


   The shortcut cannot be edited after you click **Finish**. If you want to edit, simply delete the shortcut icon and create a new one.

13.2 Creating a Shortcut to a Report


1. Click the **Add new shortcut** icon  in the lower right corner of the homepage.
2. Select an icon for the new shortcut. You may use the same icon more than once.
3. Type the shortcut description and click **Next**; for example, type **Refuel events**.
4. Click **Next**.



To enter a shortcut to a report, **ignore** the upper part of the Question page.



5. Choose a report.
   The sub report types are displayed.



6. In the Report stage:
   A. Define the time period covered by the report.
   B. Check the **Email message** checkbox if you want Karma to send the report to your email address. In this case, the shortcut icon includes a small envelope, indicating that an automated report has been sent to your email.
   C. Select the drivers /vehicles from the table.

7. Click **Next**.

8. Review the Shortcut Summary, and click **Finish** if no other modifications are required.

   The shortcut cannot be edited after you click **Finish**. If you want to edit, simply delete the shortcut icon and create a new one.


14. Viewing and Editing Settings

Tip


- Adding, Editing, and Deleting Settings is only available with Partners Access Rights. Without those rights, information is read-only.

14.1 Managing Users, Access, Drivers, and Vehicles

To manage users, allow access, add drivers/vehicles, make fleet-related definitions and so on, click the **Settings** icon on the Home Page.




The following icons appear, enabling you to define or edit Karma settings:



- Add/Edit/Delete drivers.



- Add/Edit/Delete vehicles.



- Refers to assets tracking: Add, Edit, Delete assets.



- Presents the fleets listed in Karma; and enables defining each fleet's units of measurement.



- Add / Edit / Delete Karma users.



- Presents a list of the questions that were asked by Karma users during a configurable period.



- Presents vehicles which have been disconnected for over 48 hours.

14.2 Adding New Fuel Details

1. Click the **Settings** icon on the Home Page.
2. Click 


.


   The Fuel Settings page is displayed.



3. Select the time period that you want the report to cover.
4. Select the drivers/vehicles that you want included in the report.
5. Click **Next**.


The following page is displayed. This screenshot shows an example where no Fuel details have been added yet.



6. Click 

.


The following window appears.




7. Enter the date you added fuel, how much fuel you added, the odometer reading, and the location.
8. Upload the receipt for the fuel.
9. Click **Save**.

14.3 Adding New Maintenance Details

1. Click the **Settings** icon on the Home Page.
2. Click 


.
   The Maintenance Settings page is displayed.
3. Select the time period that you want the report to cover.
4. Select the drivers / vehicles that you want included in the report.
5. Click **Next**.
6. In the screen that appears, click 

   The following screen is displayed.




7. Enter the following details:
   - Date – Date of the current maintenance activity.
   - Next Date – Date of the next scheduled maintenance activity.
   - Odometer – Odometer reading at the time of the current maintenance activity.
   - Next Odometer – Odometer reading for the next maintenance activity.
   - Service Type – A brief description of the service done on the vehicle.
   - Replaced Parts – Identify which parts are being replaced.
   - Location – Location of the Repair.
8. Click **Upload** if you want to upload a receipt.
9. Click **Save**.

14.4 Adding New Tires Details

1. Click the **Settings** icon on the Home Page.
2. Click 

.
The Tires Settings page is displayed.
3. Select the drivers/vehicles that you want included in the report.
4. Click **Next**.


   A schematic of the vehicles with the placement of tires is displayed.



5. Click one of the red Add icons  to add a tire to the vehicle, or to the spare tires.
The Edit Tire window is displayed.

6. Complete the requested details:

   - Tire Size
   - Tire Odometer
   - Vehicle Odometer
   - Replace By (Indicates who replaced the tire)
   - Air pressure
   - Replaced Date



7. Click **Save**.

15. Odometer Update

15.1 New Vehicle


- When adding a new vehicle to the Karma, the user can update the vehicle's odometer manually.

  Note: This field will not be presented after the vehicle is created.



15.2 Existing Vehicle

- When the Vehicle card on the map is selected,
- The user clicks on "Vehicle Details" >>> "Odometer" >>> "Edit"
- Vehicle Odometer is then edited manually, and clicking on "save" is required to save the changes.



15.3 Changing from the Dashboard

- When the user clicks on the odometer at the vehicle's dashboard
- The ‘Set Odometer' window appears.
- Odometer is then edited manually, and clicking on "save" is required to save the changes.



Note: Change of the odometer will cause values differences in trips.

16. More Karma Tips

- Click the double line icon to view more general information.



- Click the map on the upper right side to toggle map type



- Change map to Street View for verifications. For example, driving behavior events related to the road (speed bumps, off-road, and so on.)



17. Contacting Support

For any clarifications, questions or to share feedback, feel free to contact us:

Email: support@erm.co.il

Skype: erm.support

