


- home
- electronics
- howto
- tools
- knowledge
- forum

### ADC in Atmega8 – Summary

If you have directly jumped to this section, then for a detailed explanation on ADC read this tutorial from the beginning. To summarize whatever we learnt till now:

Signals are set of values that convey information and are measured by any independent attribute like time or space. Analog signals are real world signals around us like sound and light. Digital signals are analog equivalents in digital or numeric format which are well understood by digital systems like microcontrollers. ADC is one such hardware which measures analog signals (Voltage) and produces a digital equivalent of the same signal.

ADC in AVR devices uses a technique known as successive approximation by comparing input voltage with half of reference voltage generated internally. The comparison continues by dividing the voltage further down and updating each bit in ADC register by 1 if input voltage is high, 0 otherwise. This process lasts 8 (for 8 bit ADC) or 10 (for 10 bit ADC) times and generates resulting binary output.



With regards to Atmega8 a few concepts to know beforehand are:


- 1. AVCC: This AVR pin supplies power to ADC. AVcc must not differ more than  $\pm$  0.3V from Vcc
- 2. AREF: Another AVR pin which can optionally be used as an external voltage reference pin.
- 3. Voltage Resolution: This is the smallest voltage increment which can be measured. For 10 bit ADC, there can be 1024 different voltages and for 8 bit ADC, there can be 256 different voltages.
- 4. Input voltage can be measured as: VIn [V] = (ADCH\*256+ADCL) \* VRef [V] / 1024 for 10 bit ADC
- 5. Input voltage can be measured as:  $VIn [V] = (ADCH)^* VRef [V]/256$  for 8 bit ADC
- 6. Hardware units like DAC (Digital to Analog converter), Comparator, SHA or S/H (Signal and Hold), SAR (Successive approximation register) together complete AD conversion.
- 7. Most AVR microcontrollers have built in ADC which reduces cost and space for an external ADC
- 8. Lastly, be informed that all ADC pins are connected to only one internal ADC, which means you need to do one conversion at a time.

#### **ADC Setup using Atmega8**

If you are already dizzy with the boring theory, then wake up; we will start some programming. If you are not aware of bits, ports and programming, I recommend you to read <u>AVR basics</u> and complete <u>blinking LED</u> project before you start this, because Port basics and programming basics are not part of this tutorial.

In this simple ADC project, we will set up adc in single conversion mode with 10 bit precision, complete a conversion and switch on and off two LED's based on the result

If you have already completed <u>blinking LED project</u>, then you already have all the parts required for this project. One more component which adds to the list is a variable resistor / pot. The image in the right tells you how and what to connect. Click on it for a pictorial representation of connections.



We will write a Pseudo-code for this project and then implement corresponding C code for the same.

Determine ports and pins for LED and ADC Configure LED Ports and Pins Setup and enable ADC While forever Start ADC conversion If ADC is high, turn on LED1 and turn off LED2 Else turn on LED2 and turn off LED1 End while

First, we will include header file io.h for this project

```
#include <avr/io.h>
```

Next, we will define two macros to ease our work of switching off and on the LED's #define PORT\_ON(port,pin) port |= (1 << pin) #define PORT\_OFF(port,pin) port &=  $\sim (1 << pin)$ 

With these two in place, we will create a framework for our program:

```
#include <avr/io.h>
#define PORT_ON(port,pin) port |= (1<<pin)</pre>
#define PORT OFF(port,pin) port &= ~(1<<pin)
int main(void)
  unsigned int adc value; // Variable to hold ADC result
                // Set PortD for LED output
  DDRD=0xff;
  PORTD = 0 \times 00;
                         // Clear PortD Pins
                Todo: Setup and enable ADC
        //
        //
                         While forever
        //
                         Start ADC conversion
        //
                         If ADC is high, turn on LED1 and turn off LED2
        //
                         Else turn on LED2 and turn off LED1
                         End while
  }
```

The next task is to configure ADC hardware

```
ADCSRA = (1<<ADEN) | (1<<ADPS2) | (1<<ADPS0); // ADEN: Set to turn on ADC //ADPS2: ADPS2 and ADPS0 set to make division factor 32
```

By setting ADCSRA in this way, we are turning on ADC and configuring division factor. If you are unsure on this, go back to <u>ADCSRA</u> Register section.

Now we need to set reference voltage. Here we will use external Aref voltage and turn off internal reference voltage. To do this, we need not write any extra code as REFS1 and REFS0 bit are cleared (0) by default. For more information, refer <u>ADMUX</u> tutorial.

Now select the pin which will be used as ADC input channel. Let us select PC5 in atmega8.

ADMUX=0x05; //Binary equivalent of 0101

If you need to use free running mode, then set ADFR bit. Again, if you need 8 bit precision, we can set ADLAR bit to 1. Since we are using single conversion with 10 bit resolution, we will not write any extra code here. This completes ADC setup and we will start the conversion.

To start a conversion, we need to set ADSC bit in ADCSRA register

```
ADCSRA = (1 << ADSC);
Rewriting our above code:
#include <avr/io.h>
#define PORT ON(port,pin) port |= (1<<pin)</pre>
#define PORT OFF(port,pin) port &= ~(1<<pin)</pre>
int
    main(void)
                                         // Variable to hold ADC result
        unsigned int adc value;
                        // Set Port D for LED output
        DDRD=0xff;
        PORTD = 0 \times 00;
                        // Clear PortD pins
        // Set ADCSRA Register with division factor 32
        ADCSRA = (1 < ADEN) \mid (1 < ADPS2) \mid (1 < ADPS0);
        ADMUX=0x05;
                        //Binary equivalent of 0101
        while (1)
                        //Forever since it is in single conversion mode
        {
                ADCSRA |= (1<<ADSC);
                // wait until conversion completes; ADSC=0 means Complete
                while (ADCSRA & (1<<ADSC));
                                         //Store ADC result
                adc_value = ADCW;
                // Todo: Set and toggle LED status
        }
  }
```

If you observe carefully we have used **ADCW** which is not found in Atmel datasheet. This is a compiler help which stores values of ADCL and ADCH. If we do not use this, then individually ADCH and ADCL should be polled. Also note that if we are using free running mode, then we need to check ADIF instead of ADSC as ADSC will never be zero in free running mode.

Now, all we need is to turn on and off LED's to check the result. Since we use 10 bit mode, we can use values from 0 through 1024. If ADC value is less than 512 then LED1 should be turned on else LED2.

Our complete code will now be:

```
#include <avr/io.h>
#define PORT_ON(port,pin) port |= (1<<pin)</pre>
```

```
#define PORT OFF(port,pin) port &= ~(1<<pin)</pre>
int main(void)
  {
  unsigned int adc_value;
                                // Variable to hold ADC result
              // Set Port D for LED output
  DDRD=0xff;
  PORTD = 0 \times 00;
                       // Clear Portd pins
        ADCSRA = (1 << ADEN) \mid (1 << ADPS2) \mid (1 << ADPS0);
        // Set ADCSRA Register with division factor 32
  ADMUX=0x05;
                //Binary equivalent of 0101
                //Forever since it is in single conversion mode
  while (1)
                               // Start conversion
        ADCSRA
               |= (1<<ADSC);
                while (ADCSRA & (1<<ADSC));
                // wait until conversion completes; ADSC=0 means Complete
        adc_value = ADCW;
                                //Store ADC result
                if (adc value < 512)
        PORT OFF(PORTD,6);
                              // Clear 6th bit
        PORT ON (PORTD,7);
                               // Set 7th bit
        else
        {
                PORT ON(PORTD,6);
                                       // Set 6th bit
                PORT OFF (PORTD,7); // Clear 7th bit
        }
```

To test this, connect a 10K variable resistor to PC5 as shown in the image. Connect two LED's with resistor to PORTD, pin 6 and pin7 (PD6 and PD7)

Turn the pot and see the result of your hard work, if at all you have tried making this.

This completes our ADC tutorial. If you have any issues in making this work for you, or any questions related to ADC, then direct it in the <u>forum</u>. You can download the compiled C code, **make** file along with .hex code <u>here</u>.


#### **Tutorial index:**

- 1. Introduction to ADC
- 2. Successive-approximation technique
- 3. ADCSRA Register
- 4. ADMUX, ADCH & ADCL Registers
- 5. Designing & Programming ADC in Atmega8

```
«<u>Previous</u> - § - Next»
```



# **Featured Videos**



Advertisements

### **Recent Articles**

#### **Atmega8 Development Board**

A great step-by-step tutorial on building your own Atmel AVR based Atmega8 development board. The board is ideal for beginners with detailed explanation and pictures More...

#### **L293D Motor Driver**

For robots to do work, you need to know how to control a motor. L293D is a cleverly packed IC which can control two DC motors in both directions: forwards and reverse. Here is a detailed explanation of building a board based on L293D ICMore...

### **Hobby Servo Tutorial**

Servo Motor is a device which uses error-sensing feedback signals to determine and control the position of a motor shaft. The term "servomechanism" closely relates to servo motors...More...

# **Blinking LED Tutorial**

This is similar to what we achieve in any "Hello World" program. However, it is not just limited to blinking LED but scratches the surface of AVR-GCC programming... More...

### **Kindly Donate**

If this site has helped you, then kindly consider a Donation to say "Thank You!!". Donation might help us keep all this information available for free and also pay for the resources.

If that is difficult, then a simple "Hi" in the forum would still do good :)



<u>HOME</u> | <u>ELECTRONICS</u> | <u>HOWTO</u> | <u>KNOWLDGE</u> | <u>TOOLS</u> | <u>FORUM</u> <u>Contact Us</u> | <u>Disclaimer & Privacy</u> | <u>Sitemap</u>

© Copyright 2010 - 2017 **ROBOT PLATFORM** All Rights Reserved

