

User Manual



CubeSuite for Android/iOS: scan the QR code


CUBE BABY AC is a portable and multifunctional electrical acoustic guitar effector. It has 3 editable presets, the users also can customize effectors chain and save. CUBE BABY AC has built-in battery, it has 3-band EQ, Compressor, automatic real time ANTI-Feedback Chorus, Tremolo, Delay, Reverb, 8 IR slots and a Tuner. Beside, it support mobile phone recording jack, BT, and computer sound card. It integrates a variety of function, it is easy-carry has excellent sound! It could be a good partner of your guitar.


II. The Power Supply

- It is equipped with built-in battery for power supply, which can last for 6 hours after full charge.
- It can charge with the 5V adapter or the power bank.
- When the battery run low, you can use the DC 5V/2A adapter, you need 2 hours to fully charge the battery.

III. Effectors Chain

Tuner→EQ →Compressor→ANTI Feedback→Tremolo/Chorus→Delay/Reverb→IR CAB





① **IN:** 1/4" MONO audio input jack.


② **Power switch.**

③ **USB jack:** Use to charge the battery/the CUBE BABY AC can be sound card of computer/you can edit 3 groups of presets on computer/you can import the IR on computer.

④ **Audio output jack:** It support mobile phone recording.

⑤ **Earphone output.**

⑥ **OUT:** 1/4" MONO audio output jack.



① **TREB:** Treble knob.

② **MID:** Middle knob.

③ **BASS:** Bass knob.

④ **COMP:** Compressor knob.

⑤ **ANTI FB:** ANTI-Feedback knob.

⑥ **MOD:** CHORUS/TREMOLO.

⑦ **SPACE:** Adjust the ratio of wet and dry of REVERB/DELAY.

⑧ **TIME:** Adjust the feedback speed of echo repeats of REVERB/DELAY.

⑨ **IR CAB:** 8 IR slots.

⑩ **VOLUME:** Volume knob.

⑪ **BT indicator.**

⑫ **Charging indicator.**

⑬ **C footswitch.**

⑭ **B footswitch.**

⑮ **A footswitch.**

⑯ **3 indicators.**

Attention: Please make sure that CUBE BABY AC is in LIVE mode, then you can listening-test the 1-6 items of effectors below.

1.EQ editor

- **TREB knob.**
- **MID knob.**
- **BASS knob.**

2.COMP

- **COMP:** Compressor knob.

3.ANTI FB

- **ANTI FB:** ANTI-Feedback knob,it provide automatic real time anti-feedback, up to 8 high-precision notch.

4.MOD

- **MOD knob:** the left half circle is used for CHORUS, the right half circle is used for TREMOLO. When the knob is at middle, the indicator turned off, it means the MOD has been turned off.

5.SPACE

- **SPACE knob:** The left half circle is used for REVERB, the right half circle is used for DELAY. When the SPACE knob is at middle, the SPACE and TIME indicators will turned off at same time, it means the SPACE module has been turned off.
- **TIME knob:** Adjust feedback speed of echo repeats of SPACE.

6.IR CAB

- **IR CAB knob:** Select the types of IR. A total of 9 slots, the first slot means the IR has been turned off, the 2-9 slots are 8 types of IR.

SLOT	IR NAME
1	Base on The IR has been turned off
2	Base on Mart 45 Piezo 3C
3	Base on Acoustic2-Impulse
4	Base on Wurlitzer 1
5	Base on Mart 45 Soundhole 5c
6	Base on Soldano 2inch cap-dc
7	Base on On Axis grille
8	Base on Taylor 314ce-Soundelux
9	Base on Pro Jr floor

● You can import the IR files to CUBE BABY AC on computer. The previously IR will overwritten with the current IR.

7.TUNER


In TUNER mode, these six knobs represent the six strings of the guitar. When you turning the string, the corresponding knob indicator will light on.

In TUNER mode, when you turning the string, these three knobs show the pitch:

The ► indicator lighting up means the string is pitching too low;

The ■ indicator lighting up means the string is at the correct pitch;

The ◀ indicator lighting up means the string is pitching too high.



Press and hold the B+C footswitchs at the same time for 2 seconds to enter TUNER mode.

8.BT

● This product supports BT, you can press and hold the "A+B" footswitchs at the same time for 2 seconds to turn on/off BT. When the indicator lighting up blue, it means the BT has been connected, then your phone can paly music to the CUBE BABY AC. When the indicator flashing blue, it means that BT is turnning on, but not in connection.

9. Mobile Phone recording

● This product supports phone recording function, you can use the recording cable to connect the Phone and CUBE BABY AC, then you can use your Phone to get a high quality recording.

VII. LIVE/PRESET/EDIT Mode

EN

● CUBE BABY AC has three operation modes, LIVE mode is real-time performance mode, EDIT mode is use for edit the three presets, PRESET mode is the most common state for performance. The initial power-on default enters PRESET mode, tap the combination nail "B+C" for LIVE mode, or tap the combination nail "A+B" for EDIT mode.

● PRESET mode is the most normal playing state, you can use LIVE or EDIT to edit and save three presets, then Three presets can be used by free footswitchs conveniently in PRESET mode.

● In LIVE mode, visual operations can be performed, knobs timbre effect is what you see is what you get, it is suitable for you to customize a effectors chain. You can use the knobs to improvise the timbre when you performing.

● In EDIT mode, you can fine-tune and edit 3 groups of presets, better for contrast with other preset's tones.

A. Function Introduction of PRESET mode.

PRESETS	EFFECTORS CHAIN
A Footswitch	EQ+ANTI FB+REVERB+Mart 45 Piezo 3C
B Footswitch	EQ+ANTI FB+CHORUS+Acoustic2-Impulse
C Footswitch	EQ+ANTI FB

● In PRESET mode, the VOLUME knob is the final output volume value, you can listen and use the three presets in real time, but you cannot use knobs to edit timbre. The A/B/C footswitchs represent 3 presets, when the preset had been selected, the current footswitch- indicator flashing. If all three indicators are off, the device is in Bypass.

B. Function Introduction of LIVE mode.

- When enter LIVE mode, the default final output volume value in this mode is 80%, the VOLUME knob is use for adjust the level of current effectors chain.
- In LIVE mode, the A/B/C footswitchs can use to open/close the corresponding effect module, the corresponding footswitch-indicator is flashing/went off. Users can customize the effectors chain, then press and hold the A/B/C to save.
- In LIVE mode, the knob lights have only 2 states: lighting on/went off. If the knob light is off, it means that the effect of this knob is not on; If the knob light is on, it means that the effect has been turned on, and the knob timbre effect is what you see is what you get.

C. Function Introduction of EDIT mode.

- Switch to EDIT mode when you tap A+B, the machine will retain the data in the corresponding knobs before switching.
- In EDIT mode, the machine always retain the output volume value before switching to EDIT.
- The knob lights have only 3 states: lighting on/went off/flashing. If the knob light is off, it means that the effect of this knob is not on; If the knob light is on, it means that the effect has been turned on, and the knob timbre effect is what you see is what you get; If the knob light flashing, it means that the effect has been turned on, but the knob timbre what you get is diffrent from what you see.
- After you turn the knob, the flashing knob light will become lighting on, The previously data will overwritten with the current knob value. When the knob light lighting on, the knob timbre effect is what you see is what you get.
- In EDIT mode, the machine always retain the output volume value before switching, the VOLUME knob is use for adjust the level of current effectors chain.
- After editing the effectors chain, then switch to PRESET mode, the VOLUME knob become the final output volume value. Therefore, it is recommended that after exiting EDIT mode, users immediately turn the volume knob to the position before entering

EDIT mode. So that you can restore the output volume value of the previous performing.

● In EDIT mode, the A/B/C footswitchs can use to open/close the corresponding effect module, the corresponding indicator light is flashing/went off. Users can fine-tune and edit 3 groups of presets, then press and hold the A/B/C to save.

VIII. How To Customize A Effectors Chain

EN

Let's try to customize a effectors chain similar to Preset "A".

1. When CUBE-BABY AC is turned on, tap the "B+C" to enter the LIVE mode. Then you need to turn off all the effectors, so that all the knob indicators had been turned off(except the VOLUME knob). Next step, you can turn the VOLUME knob to the value you like.

2. Tap the C footswitch to turn on the ANTI FB+EQ mudle, turn the TREB knob to the 9 o'clock position, turn the MID knob to the 9 o'clock position, turn the BASS knob to the 11 o'clock position, turn the COMP knob to the 8 o'clock position, turn the ANTI FB knob to the 12 o'clock position.

3. Tap the B footswitch to turn on the MOD+SPACE mudle. We don't need the MOD, so let's turn the MOD knob to the 12 o'clock position. Then, let's turn the SPACE knob to 11 o'clock position to turn on the REVERB effector. Next step, turn the TIME knob to 2 o'clock position.

4. Tap the A footswitch to turn on the IR mudle. Turn the IR CAB knob to the 2th slot, so we had select the "Mart 45 Piezo 3C".


5. Then let's adjust the level of current effectors chain, turn the VOLUME knob to the value you like.

6. At this time, we had customized a effectors chain, then let's press and hold the A footswitch for 2 second to save it to PRESET A.

7. Let's tap the "B+C" to enter the PRESET mode. You can use the new PRESET A now.


1. IR EDITOR

- ① IR files searching button: You can use it to find the IR on your computer.
- ② IR files display interface: Here is the IR files you had selected, you can click and listen it.
- ③ Microphone distance simulator: You can adjust the distance of microphone to speaker. When the distance closer, the sound louder; when the distance farther, the sound lower. SO, what you need to attention is: When the distance is 100%, you couldn't hear the voice.
- ④ IR saving location: You can use it to select the 1-8 locations of the IR slots of CUBE BABY AC.
- ⑤ Save button: Click this button to save.
- ⑥ The IR Factory reset option.
- ⑦ Click this button to Factory reset the parameters of 3 PRESETS.



2. PRESETS PARAMETERS EDITOR

- ① Select the Preset you need to edit. At this time, if the software and CUBE BABY AC are in the same Preset, you can hear the real-time sound of editing.
- ② Adjust the level of current effectors chain.
- ③ Adjust the IR.
- ④ Adjust feedback speed of echo repeats of SPACE.
- ⑤ SPACE effector editor: 0-13 is use to edit the REVERB, 14-17 is use to turn off SPACE, 18-31 is use to edit the DELAY.
- ⑥ MOD effector editor: 0-6 is use to edit the CHORUS, 7-8 is use to turn off MOD, 9-15 is use to edit the TREMOLO.
- ⑦ Adjust ANTI-Feedback.
- ⑧ Adjust the Compressor.
- ⑨ Adjust the Bass.
- ⑩ Adjust the Middle.
- ⑪ Adjust the Treble.
- ⑫ Save button: Click this button to save the PRESET.



Input	Standard 1/4" jack MONO/TS
Output	Standard 1/4" jack MONO/TS
Sample rate	48KHz/24bit
Battery Model/Type	603040
Battery Nominal Voltage	3.7V
Battery capacity	780mAh
Size	161(L)X57(W)X17.5(H)mm
Weight	260g
Attachment	Instruction, Charging cable, Recording cable

★ Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

CUBE BABY AC

多功能电箱木吉他效果器

用户说明书



手机端Android/iOS下载APP: 扫描二维码下载


CUBE-BABY AC是一款便携式多功能电箱木吉他效果器。CUBE-BABY AC预置有三组出厂音色，用户可自定义音色进行覆盖储存，也可以对预置音色进行编辑和保存。本效果器内置蓄电池，解决了长距离供电的问题。CUBE-BABY AC具备3段EQ调节器、压缩效果器、啸叫抑制功能、两种调制效果（合唱、颤音）、一种延时、一种混响、8种经典的IR琴体模拟以及一个高精度的校音器。另外CUBE-BABY AC还带有手机内录功能、BT无线音乐播放功能及电脑声卡功能。多种功能效果集于一身，体积小性能好、便于携带且音色优秀！是您不错的吉他伴侣。


二. 电源供应

- 本机设有内置电池供电，满电状态下可持续使用6小时。
- 可直接使用手机充电器或充电宝为本设备进行供电，本设备支持充电&用电同步进行。
- 设备充电时长取决于充电变压器的输出功率，以输出功率为DC5.0V/2.0A的充电器为例，在本设备内置电池耗尽的状态下进行充电，2小时可以充满。

三. CUBE-BABY AC的效果模块连接

调音器→均衡器→压缩→啸叫抑制器→颤音/合唱→延时/混响→琴体模拟。





① **IN**: 连接吉他信号输入。


② **电源开关**。

③ **USB接口**: 充电/电脑声卡/支持电脑软件编辑预置音色及导入IR文件。

④ **手机接口**: 用于手机内录。

⑤ **耳机输出**: 连接监听耳机。

⑥ **OUT**: 连接音箱或调音台。



- ① TREB: 高频调节旋钮
- ② MID: 中频调节旋钮
- ③ BASS: 低频调节旋钮
- ④ COMP: 压缩效果旋钮
- ⑤ ANTI FB: 啸叫抑制效果旋钮
- ⑥ MOD: 合唱/颤音效果旋钮
- ⑦ SPACE: 混响/延时效果干湿比旋钮
- ⑧ TIME: 混响/延时-时间速度旋钮
- ⑨ IR CAB: 琴体模拟选择旋钮
- ⑩ VOLUME: 输出音量增益旋钮
- ⑪ 无线音乐指示灯
- ⑫ 充电指示灯
- ⑬ C功能踩钉
- ⑭ B功能踩钉
- ⑮ A功能踩钉
- ⑯ 模块/踩钉指示灯

1.均衡调节模块

- **TREB**: 高频调节旋钮。
- **MID**: 中频调节旋钮。
- **BASS**: 低频调节旋钮。

2.压缩效果器模块

- **COMP**: 压缩效果调节旋钮。

3.啸叫抑制功能

- **ANTI FB**: 扫频防啸叫旋钮,提供智能实时扫频,智能提供最多8个高精度切口。

4.MOD模块

- **MOD旋钮**: 左半圈为合唱效果,右半圈为颤音效果。旋钮调至中间为关闭MOD模块,在关闭MOD模块时,MOD旋钮指示灯熄灭。

5.SPACE模块

- **SPACE旋钮**: 左半圈为混响效果,右半圈为延时效果。旋钮调至中间为关闭SPACE模块,在关闭SPACE旋钮时,SPACE旋钮灯和TIME旋钮灯同时熄灭。
- **TIME旋钮**: 调整SPACE模块的回声反馈的时间速度。

6.IR CAB模块

- **IR CAB旋钮**: 总共9档,第一档为关闭档位,2至9档为8种不同规格的琴体,下表为出厂预设琴体模拟。

档位	Ir名称
1	关闭琴体模拟
2	Base on Mart 45 Piezo 3C
3	Base on Acoustic2-Impulse
4	Base on Wurlitzer 1
5	Base on Mart 45 Soundhole 5c
6	Base on Soldano 2inch cap-dc
7	Base on On Axis grille
8	Base on Taylor 314ce-Soundelux
9	Base on Pro Jr floor


● CUBE-BABY AC支持用户加载第三方IR，请使用电脑软件CUBESUITE导入第三方IR文件，用户可针对上方列表的载入位置导入覆盖原厂的IR文件。

7.TUNER模块

在TUNER模式下此排旋钮对应代表吉他的六根弦，靠最左为6弦的音名对照，靠最右边为1弦的音名对照，调校时对应的旋钮会亮起。

在TUNER模式下此排旋钮为音准调校对照：

- 旋钮亮起时表示此时音高偏低；
- 旋钮亮起时表示此时音高接近准确；
- ◄ 旋钮亮起时表示此时音高偏高。



长踩B+C组合踩钉进入TUNER模式。

8.无线音乐输入功能

● CUBE-BABY AC 包含有BT无线音乐播放功能，方便用户在练习或演奏中播放伴奏，长踩组合踩钉“A+B”开启或关闭BT无线伴奏功能。设备未连接成功时，无线指示灯慢闪，当与手机/平板设置连接成功后，指示灯长亮蓝灯。

9.手机录音功能

● CUBE-BABY AC支持手机内录功能，通过随机附带的内录专用线，将本设备与您的手机/平板电脑进行连接，使用您手机/平板电脑即可实现高品质录音。

七. LIVE/PRESET/EDIT模式

CN

CUBE-BABY AC有三种操作模式，LIVE为实时演奏模式，EDIT为编辑模式，PRESET为预置模式。开机初始默认进入PRESET模式，短按组合踩钉“B+C”进行LIVE与PRESET模式的切换，短按组合踩钉“A+B”进行EDIT与PRESET模式的切换。

● PRESET模式为最常规的演奏状态，利用LIVE或者EDIT进行编辑和保存后的三组音色，在PRESET模式下即可用三个踩钉实现自由切换，灵活使用。

● LIVE模式可实现现场可视化操作，旋钮音色效果为所见即所得，适用于自定义音色，现场即兴调节音色参数，或者在现场模拟3组单块的演奏方式。

● EDIT模式适用于微调 and 编辑3组预置音色，也适用于在当前演奏时的最终输出音量值不变的情况下进行自定义音色，更利于与其他的预置音色进行对比。

A.PRESET模式功能介绍

预置位置	音色效果链
A 踩钉	EQ+ANTI FB+REVERB+Mart 45 Piezo 3C
B 踩钉	EQ+ANTI FB+CHORUS+Acoustic2-Impulse
C 踩钉	EQ+ANTI FB

● 在PRESET模式下，VOLUME旋钮为3个预置音色的最终输出音量值。在此模式下，可试听与使用三组预置音色，不可使用旋钮进行编辑音色。A/B/C踩钉代表3组预置音色，被选中的音色，对应的踩钉指示灯闪亮。若3个踩钉指示灯都为熄灭状态，即代表目前处于直通状态。

B.LIVE模式功能介绍

● 进入LIVE模式后，此模式下的默认最终输出音量值80%，此时VOLUME旋钮用于调校当前编辑音色链的输出电平值。

● 在LIVE模式下，A/B/C功能踩钉负责开启/关闭对应的效果模块，对应的踩钉指示灯为闪亮/熄灭，用户可自定义音色效果链，编辑完成后可长踩A/B/C任一踩钉进行覆盖保存。

● LIVE模式下，旋钮灯仅有2种状态：熄灭/常亮。若旋钮灯熄灭状态即代表此旋钮的效果未开启；若旋钮灯常亮状态即代表此旋钮的效果已开启，且目前旋钮的音色跟实际值相符。

C.EDIT模式功能介绍

● 当踩下A+B踩钉切换至EDIT模式时，机器会一直保留切换前的最终输出音量值。也会保留切换前的音色数据，保留在指定的旋钮上，仅保留1次。

● EDIT模式下，旋钮灯有3种状态：熄灭/常亮/闪亮。若旋钮灯熄灭状态即代表此旋钮的效果未开启；若旋钮灯闪亮状态即代表此旋钮效果已开启，但是目前旋钮的音色数据跟实际值不符，把旋钮调节后，即会丢失此旋钮之前保留的数据，旋钮灯转为常亮状态，之前保留的参数会被覆盖为当前旋钮值的参数；常亮状态即代表目前旋钮的音色数据跟实际值相符。

● 在进入EDIT模式时，会一直保留切换前的最终输出音量值，此时VOLUME旋钮用于调校当前编辑音色链的输出电平值。

● 若在EDIT模式编辑音色完毕后，切换到Preset模式，VOLUME旋钮立即成为3个预置音色的最终输出音量值。因此建议用户在退出Edit模式后，请立即把VOLUME旋钮调节到进入Edit模式前的位置，才能恢复到之前演奏状态的最终输出音量值。


● 在EDIT模式下，A/B/C功能踩钉负责开启/关闭对应的效果模块。用户可在EDIT模式下对预置音色进行微调 and 再次编辑，编辑完成后可长踩A/B/C任一踩钉进行覆盖保存。

以CUBE-BABY AC原厂预置‘A’踩钉的音色为例:

1. 开机初始化完毕后请短按组合踩钉“B+C”切换至LIVE模式，进入LIVE模式后请检查所有旋钮显示灯（除VOLUME旋钮）是否全部关闭，如有未关闭的效果请手动关闭。此时VOLUME旋钮用于调校当前编辑音色链的输出电平值，请将VOLUME旋钮调至适合的位置。
2. 短按C踩钉开启ANTI FB+EQ模块，将TREB旋钮调节到时针9点钟位置，MID旋钮调节到时针9点钟位置，BASS旋钮调节到时针11点钟位置，COMP旋钮调节到时针8点钟位置，ANTI FB旋钮调节到时针12点钟位置。
3. 接着短按B踩钉开启MOD与SPACE模块，此音色不需要使用MOD效果，先将MOD旋钮调节至时针12点钟的位置，关闭MOD效果。接着调节SPACE旋钮开启REVERB效果，将SPACE旋钮调至时针11点钟位置，将TIME旋钮调至时针2点钟位置。
4. 接着短按A踩钉开启IR CAB模块，将IR CAB旋钮调节至第2档的琴体模拟：Mart 45 Piezo 3C。
5. 最后调节音色链的输出电平值，请将VOLUME旋钮调至适合的位置。
6. 音色已编辑完毕，我选择将音色储存在A踩钉，长踩A踩钉，直至A踩钉的提示灯快速闪烁，接着指示灯恢复慢闪状态，表示音色已经储存完毕。
7. 此时，我编辑的音色已成功储存在PRESET预置模式，覆盖了A踩钉的音色。

1.自定义IR界面


- ① IR文件搜索框：通过此搜索框找到预备在电脑里的IR文件。
- ② IR文件显示框：显示被选中的IR文件，方便点击试听。
- ③ 拾音话筒距离模拟器：此旋钮用于调节话筒对音箱的拾音距离，距离越近声音越大，距离越远声音越小（注意:100%距离的情况下，音量0，需先调整距离，再试听IR）。
- ④ 储存位置：CUBE-BABY AC的IR储存位置序号，可选择1-8的储存位置。
- ⑤ 储存按钮：当选中第三方IR、调好话筒拾音距离、选择储存位置序号后，点击此按钮进行储存。
- ⑥ 点击此按钮为恢复出厂IR。
- ⑦ 点击此按钮，为3组预置音色恢复出厂参数。



2.预置参数调节界面

- ① 选择需要调节的预置（3组预置可供选择），软件和设备若处于同一组预置，则可以听到实时调节效果。
- ② 调节当前音色链的输出电平值。
- ③ 选择IR琴体模拟。
- ④ 调节SPACE模块的回声反馈的时间速度。
- ⑤ 参数0-13为混响效果，14-17关闭SPACE模块，18-31为延时效果。
- ⑥ 参数0-6为合唱效果，7-8关闭MOD模块，9-15为颤音效果。
- ⑦ 调节啸叫抑制功能大小。
- ⑧ 调节压缩效果大小。
- ⑨ 调节低频。
- ⑩ 调节中频。
- ⑪ 调节高频。
- ⑫ 音色保存按键。

备注：如果已经调节预置的参数，却没点击保存，则设备断电之后，恢复为调节之前的参数。



输入	标准 1/4" 单声道接口 /TS
输出	标准 1/4" 单声道接口 /TS
采样率	48KHz/24bit
电池型号规格	603040
电池标称电压	3.7V
电池容量	780mah
尺寸	161(L)X57(W)X17.5(H)mm
重量	260g
附件	说明书、充电线、内录连接线
修订	20240606