



User Manual

CUBE BABY BASS



EN Preface


CUBE BABY BASS is a portable and multifunctional electric bass effector. It has 3 editable presets, the users also can customize effectors chain and save. CUBE BABY BASS has built-in battery, it has Booster, 3-band EQ, Compressor, Chorus, Phaser, Delay, Reverb, 8 IR slots and a Tuner. Beside, it support mobile phone recording jack, BT, and computer sound card. It integrates a variety of function, it is easy-carry and it has excellent sound!

EN The Power Supply


- It is equipped with built-in battery for power supply, which can last for 6 hours after full charge.
- It can charge with the 5V adapter or the power bank.
- When the battery run low, you can use the DC 5V/2A adapter, you need 2 hours to fully charge the battery.

EN Effectors Chain

Tuner → Booster → EQ → Compressor → Phaser/Chorus → Delay/Reverb → IR CAB



EN Rear Panel



① **IN:** 1/4"MONO audio input jack.

② **Power switch.**


③ **USB jack:** Use to charge the battery/the CUBE BABY BASS can be sound card of computer/you can edit 3 groups of presets on computer/you can import the IR on computer.

④ **Audio output jack:** It support mobile phone recording.

⑤ **Earphone output.**

⑥ **OUT:** 1/4"MONO audio output jack.

EN Front Panel



- ① **BOOST:** Boost knob.
- ② **TREB:** Treble knob.
- ③ **MID:** Middle knob.
- ④ **BASS:** Bass knob.
- ⑤ **COMP:** Compressor knob.
- ⑥ **MOD:** CHORUS/PHASER.
- ⑦ **SPACE:** Adjust the ratio of wet and dry of REVERB/DELAY.
- ⑧ **TIME:** Adjust the feedback speed of echo repeats of REVERB/DELAY.
- ⑨ **IR CAB:** 8 IR slots.
- ⑩ **VOLUME:** Volume knob.
- ⑪ **BT indicator.**
- ⑫ **Charging indicator.**
- ⑬ **C footswitch.**
- ⑭ **B footswitch.**
- ⑮ **A footswitch.**
- ⑯ **3 indicators.**

EN Effectors Module

Attention: Please make sure that CUBE BABY BASS is in LIVE mode, then you can listening-test the 1-6 items of effectors below.

1. BOOST

- **BOOST:** Booster knob.

2. EQ editor

- **TREB knob.**
- **MID knob.**
- **BASS knob.**

3. COMP

- **COMP:** Compressor knob.

4. MOD

- **MOD knob:** The left half circle is used for CHORUS, the right half circle is used for PHASER. When the knob is at middle, the indicator turned off, it means the MOD has been turned off.

5. SPACE

- **SPACE knob:** The left half circle is used for REVERB, the right half circle is used for DELAY. When the SPACE knob is at middle, the SPACE and TIME indicators will turned off at same time, it means the SPACE module has been turned off.
- **TIME knob:** Adjust feedback speed of echo repeats of SPACE.

6. IR CAB

- **IR CAB knob:** Select the types of IR. A total of 9 slots, the first slot means the IR has been turned off, the 2-9 slots are 8 types of IR.


SLOT	IR NAME
1	Base on The IR has been turned off
2	Base on Jensen 10 441
3	Base on Studio 22 441 Edge
4	Base on SWR 15 4050
5	Base on Work 15 441 Edge
6	Base on TP5-PV-421
7	Base on TP5-PV-D112
8	Base on Work 15 4050
9	Base on EV 12V 441

● You can import the IR files to CUBE BABY BASS on computer. The previously IR will be overwritten with the current IR.

7. TUNER

In TUNER mode, these six knobs show the note name of the bass. If your bass just has 4 strings, so you only look at the knobs with the E、A、D、G.

In TUNER mode, when you turn the string, these three knobs show the pitch:
 The ► indicator lighting up means the string is pitching too low;
 The ■ indicator lighting up means the string is at the correct pitch;
 The ◀ indicator lighting up means the string is pitching too high.



Press and hold the B+C footswitches at the same time for 2 seconds to enter TUNER mode.

8.BT

● This product supports BT,you can press and hold the "A+B" footswitchs at the same time for 2 seconds to turn on/off BT.When the indicator lighting up blue,it means the BT has been connected, then your phone can play music to the CUBE BABY BASS.When the indicator flashing blue,it means that BT is turning on,but not in connection.

9.Mobile Phone recording

● This product supports phone recording function,you can use the recording cable to connect the Phone and CUBE BABY BASS,then you can use your Phone to get a high quality recording.

EN LIVE/PRESET/EDIT Mode

● CUBE BABY BASS has three operation modes,LIVE mode is real-time performance mode,EDIT mode is use for edit the three presets,PRESET mode is the most common state for performance.The initial power-on default enters PRESET mode, tap the combination nail "B+C" for LIVE mode,or tap the combination nail "A+B" for EDIT mode.

● PRESET mode is the most normal playing state,you can use LIVE or EDIT to edit and save three presets,then Three presets can be used by free footswitchs conveniently in PRESET mode.

● In LIVE mode,visual operations can be performed,knob timbre effect is what you see is what you get,it is suitable for you to customize a effectors chain.You can use the knobs to improvise the timbre when you performing.

● In EDIT mode,you can fine-tune and edit 3 groups of presets, better for contrast with other preset tones.

A. Function Introduction of PRESET mode.

PRESETS	EFFECTORS CHAIN
A Footswitch	Boost+EQ+Compressor+Jensen 10 441
B Footswitch	Boost+EQ+Compressor+Studio 22 441 Edge
C Footswitch	Boost+EQ+Compressor+Chorus+EV 12V 441

● In PRESET mode,the VOLUME knob is the final output volume value,you can listen and use the three PRESETS in real time,but you cannot use knobs to edit timbre.The A/B/C footswitchs represent 3 PRESETS,when the PRESET had been selected,the corresponding footswitch-indicator flashing.If all three indicators are off,the device is in Bypass.

B.Function Introduction of LIVE mode.

● When enter LIVE mode,the default final output volume value in this mode is 80%,the VOLUME knob is use for adjust the level of current effectors chain.

● In LIVE mode,the A/B/C footswitchs can use to open/close the corresponding effect module,the corresponding footswitch-indicator is flashing/went off.Users can customize the effectors chain,then press and hold the A/B/C to save.

● In LIVE mode,the knob lights have only 2 states:lighting on/went off.If the knob light is off,it means that the effect of this knob is not on;If the knob light is on,it means that the effect has been turned on,and the knob timbre effect is what you see is what you get.

C.Function Introduction of EDIT mode.

● Switch to EDIT mode when you tap A+B,the machine will retain the data in the corresponding knobs before switching.

● In EDIT mode,the machine always retain the output volume value before switching.

● The knob lights have only 3 states:lighting on/went off/flashing.If the knob light is off,it means that the effect of this knob is not on;If the knob light is on,it means that the effect has been turned on,and the knob timbre effect is what you see is what you get;If the knob light flashing,it means that the effect has been turned on,but the knob timbre what you get is diffrent from what you see.

- After you turn the knob, the flashing knob light will become lighting on. The previously data will be overwritten with the current knob value. When the knob light is lighting on, the knob timbre effect is what you see is what you get.
- In EDIT mode, the machine always retains the output volume value before switching. The VOLUME knob is used for adjusting the level of the current effectors chain.
- After editing the effectors chain, then switch to PRESET mode, the VOLUME knob becomes the final output volume value. Therefore, it is recommended that after exiting EDIT mode, users immediately turn the volume knob to the position before entering EDIT mode. So that you can restore the output volume value of the previous performing.
- In EDIT mode, the A/B/C footswitches can be used to open/close the corresponding effect module, the corresponding footswitch-indicator is flashing/went off. Users can fine-tune and edit 3 groups of PRESETS, then press and hold the A/B/C to save.

EN How To Customize A Effectors Chain

Let's try to customize a effectors chain similar to Preset "A".


1. When CUBE-BABY BASS is turned on, tap the "B+C" to enter the LIVE mode. Then you need to turn off all the effectors, so that all the knob indicators had been turned off (except the VOLUME knob). Next step, you can turn the VOLUME knob to the value you like.
2. Tap the C footswitch to turn on the COMP+EQ module, turn the BOOST knob to the 12 o'clock position, turn the TREB knob to the 3 o'clock position, turn the MID knob to the 9 o'clock position, turn the BASS knob to the 10 o'clock position, turn the COMP knob to the 12 o'clock position.
3. Then let's look at the MOD+SPACE module. We don't need the MOD and SPACE, so keep the B footswitch indicator off.
4. Tap the A footswitch to turn on the IR module. Turn the IR CAB knob to the 2th slot, so we had select the "Jensen 10 441".

5. Then let's adjust the level of current effectors chain,turn the VOLUME knob to the value you like.
6. At this time,we had customized a effectors chain,then let's press and hold the A footswitch for 2 second to save it to PRESET A.
7. Let's tap the "B+C" to enter the PRESET mode.You can use the new PRESET A now.

EN The Software Interface


1. IR EDITOR

- ①IR files searching button:you can use it to find the IR on your computer.
- ②IR files display interface:here is the IR files you had selected,you can click and listen it.
- ③Microphone distance simulator:you can adjust the distance of microphone to speaker.When the distance closer,the sound louder; when the distance farther,the sound lower.SO,what you need to attention is:When the distance is 100%,you couldn't hear the voice.
- ④IR saving location:you can use it to select the 1-8 location of IR slots of CUBE BABY BASS.
- ⑤Save button:click this button to save.
- ⑥The IR Factory reset option.
- ⑦Click this button to Factory reset the parameters of 3 PRESETS.



2. PRESETS PARAMETERS EDITOR

- ① Select the Preset you need to edit. At this time, if the software and CUBE BABY BASS are in the same Preset, you can hear the real-time sound of editing.
- ② Adjust the level of current effectors chain.
- ③ Adjust the IR.
- ④ Adjust feedback speed of echo repeats of SPACE.
- ⑤ SPACE effector editor: 0-13 is use to edit the REVERB, 14-17 is use to turn off SPACE, 18-30 is use to edit the DELAY.
- ⑥ MOD effector editor: 0-6 is use to edit the CHORUS, 7-8 is use to turn off MOD, 9-14 is use to edit the PHASER.
- ⑦ Adjust the Compressor.
- ⑧ Adjust the Bass.
- ⑨ Adjust the Middle.
- ⑩ Adjust the Treble.
- ⑪ Adjust the Boost.
- ⑫ Save button: click this button to save the PRESET.





EN Technical Parameters

Input	Standard 1/4" jack MONO/TS
Output	Standard 1/4" jack MONO/TS
Sample rate	48KHz/24bit
Battery Model/Type	603040
Battery capacity	780mah
Battery Nominal Voltage	3.7V
Size	161(L)X57(W)X17.5(H)mm
Weight	260g
Attachment	Instruction,Charging cable,Recording cable

用户说明书

CUBE BABY BASS 多功能贝斯效果器



CN 前言


CUBE-BABY BASS是一款便携式多功能贝斯效果器。CUBE-BABY BASS预置有三组出厂音色，用户可自定义音色进行覆盖储存，也可以对预置音色进行编辑和保存。本效果器内置蓄电池，解决了长距离供电的问题。CUBE-BABY BASS具备了激励效果器、3段EQ调节器、压缩效果器、两种调制效果(合唱、相移)、一种延时、一种混响、8种经典的贝斯IR箱体模拟以及一个高精度的校音器。另外CUBE-BABY BASS还带有手机内录功能、BT无线音乐播放功能及电脑声卡功能。多种功能效果集于一身，体积小性能好、便于携带且音色优秀！

CN 电源供应


- 本机设有内置电池供电，满电状态下可持续使用6小时。
- 可直接使用手机充电器或充电宝为本设备进行供电，本设备支持充电&用电同步进行。
- 设备充电时长取决于充电变压器的输出功率，以输出功率为DC5.0V/2.0A的充电器为例，在本设备内置电池耗尽的状态下进行充电，2小时可以充满。

CN CUBE-BABY BASS的效果模块连接

调音器→激励→均衡器→压缩→相移/合唱→延时/混响→箱体模拟。



CN 后置面板功能图解



① **IN:** 连接吉他信号输入。

② **电源开关。**


③ **USB接口:** 充电/电脑声卡/支持电脑软件编辑预置音色及导入IR文件。

④ **手机接口:** 用于手机内录。

⑤ **耳机输出:** 连接监听耳机。

⑥ **OUT:** 连接音箱或调音台。

CN 前置面板功能图解



- ① **BOOST:** 激励效果调节旋钮
- ② **TREB:** 高频调节旋钮
- ③ **MID:** 中频调节旋钮
- ④ **BASS:** 低频调节旋钮
- ⑤ **COMP:** 压缩效果旋钮
- ⑥ **MOD:** 合唱/相移效果旋钮
- ⑦ **SPACE:** 混响/延时效果干湿比旋钮
- ⑧ **TIME:** 混响/延时-时间速度旋钮
- ⑨ **IR CAB:** 箱体模拟选择旋钮
- ⑩ **VOLUME:** 输出音量增益旋钮
- ⑪ **无线音乐指示灯**
- ⑫ **充电指示灯**
- ⑬ **C功能踩钉**
- ⑭ **B功能踩钉**
- ⑮ **A功能踩钉**
- ⑯ **模块/踩钉指示灯**

CN 效果模块功能介绍

(注意：请在LIVE模式试听以下1-6个模块的音色)

1.激励效果器模块

- **BOOST**：激励效果调节旋钮。

2.均衡调节模块

- **TREB**：高频调节旋钮。
- **MID**：中频调节旋钮。
- **BASS**：低频调节旋钮。

3.压缩效果器模块

- **COMP**：压缩效果调节旋钮。

4.MOD模块

- **MOD旋钮**：左半圈为合唱效果，右半圈为相移效果。旋钮调至中间为关闭MOD模块，在关闭MOD模块时，MOD旋钮指示灯熄灭。

5.SPACE模块

- **SPACE旋钮**：左半圈为混响效果，右半圈为延时效果。旋钮调至中间为关闭SPACE模块，在关闭SPACE旋钮时，SPACE旋钮灯和TIME旋钮灯同时熄灭。
- **TIME旋钮**：调整SPACE模块的回声反馈的时间速度。

6.IR CAB模块

- **IR CAB旋钮**：总共9档，第一档为关闭档位，2至9档为8种不同规格的IR，下表为出厂预设IR。

档位	Ir名称
1	关闭箱模
2	Base on Jensen 10 441
3	Base on Studio 22 441 Edge
4	Base on SWR 15 4050
5	Base on Work 15 441 Edge
6	Base on TP5-PV-421
7	Base on TP5-PV-D112
8	Base on Work 15 4050
9	Base on EV 12V 441


● CUBE-BABY BASS支持用户加载第三方IR，请使用电脑软件CUBESUITE导入第三方IR箱体模拟文件，用户可针对上方列表的载入位置导入覆盖原厂的IR文件。

7.TUNER模块

在TUNER模式下此排旋钮代表贝斯的音名对照表，调校时对应的旋钮会亮起。若您是4弦贝斯，只需要看E、A、D、G弦钮。

在TUNER模式下此排旋钮为音准调校对照：

- ▶ 旋钮亮起时表示此时音高偏低；
- 旋钮亮起时表示此时音高接近准确；
- ◀ 旋钮亮起时表示此时音高偏高。



长踩B+C组合踩钉进入TUNER模式。

8.无线音乐输入功能

● CUBE-BABY BASS包含有BT无线音乐播放功能，方便用户在练习或演奏中播放伴奏，长踩组合踩钉“A+B”开启或关闭BT无线伴奏功能。设备未连接成功时，无线指示灯慢闪，当与手机/平板设置连接成功后，指示灯长亮蓝灯。

9.手机录音功能

● CUBE-BABY BASS支持手机内录功能，通过随机附带的内录专用线，将本设备与您的手机/平板电脑进行连接，使用您手机/平板电脑即可实现高品质录音。

CN LIVE/PRESET/EDIT模式

CUBE-BABY BASS有三种操作模式，LIVE为实时演奏模式，EDIT为编辑模式，PRESET为预置模式。开机初始默认进入PRESET模式，短按组合踩钉“B+C”进行LIVE与PRESET模式的切换，短按组合踩钉“A+B”进行EDIT与PRESET模式的切换。

● PRESET模式为最常规的演奏状态，利用LIVE或者EDIT进行编辑和保存后的三组音色，在PRESET模式下即可用三个踩钉实现自由切换，灵活使用。

● LIVE模式可实现现场可视化操作，旋钮音色效果为所见即所得，适用于自定义音色，现场即兴调节音色参数，或者在现场模拟3组单块的演奏方式。

● EDIT模式适用于微调 and 编辑3组预置音色，也适用于在当前演奏时的最终输出音量值不变的情况下进行自定义音色，更利于与其他的预置音色进行对比。

A、PRESET模式功能介绍

预置位置	音色效果链
A 踩钉	Boost+EQ+Compressor+Jensen 10 441
B 踩钉	Boost+EQ+Compressor+Studio 22 441 Edge
C 踩钉	Boost+EQ+Compressor+Chorus+EV 12V 441

● 在PRESET模式下，VOLUME旋钮为3个预置音色的最终输出音量值。在此模式下，可试听与使用三组预置音色，不可使用旋钮进行编辑音色。A/B/C踩钉代表3组预置音色，被选中的音色，对应的踩钉指示灯闪亮。若3个踩钉指示灯都为熄灭状态，即代表目前处于直通状态。

B、LIVE模式功能介绍

● 进入LIVE模式后，此模式下的默认最终输出音量值80%，此时VOLUME旋钮用于调校当前编辑音色链的输出电平值。

● 在LIVE模式下，A/B/C功能踩钉负责开启/关闭对应的效果模块，对应的踩钉指示灯为闪亮/熄灭，用户可自定义音色效果链，编辑完成后可长踩A/B/C任一踩钉进行覆盖保存。

● LIVE模式下，旋钮灯仅有2种状态：熄灭/常亮。若旋钮灯熄灭状态即代表此旋钮的效果未开启；若旋钮灯常亮状态即代表此旋钮的效果已开启，且目前旋钮的音色跟实际值相符。

C、EDIT模式功能介绍

● 当踩下A+B踩钉切换至EDIT模式时，机器会一直保留切换前的最终输出音量值。也会保留切换前的音色数据，保留在指定的旋钮上，仅保留1次。

● EDIT模式下，旋钮灯有3种状态：熄灭/常亮/闪亮。若旋钮灯熄灭状态即代表此旋钮的效果未开启；若旋钮灯闪亮状态即代表此旋钮效果已开启，但是目前旋钮的音色数据跟实际值不符；把旋钮调节后，即会丢失此旋钮之前保留的数据，旋钮灯转为常亮状态，之前保留的参数会被覆盖为当前旋钮值的参数；常亮状态即代表目前旋钮的音色数据跟实际值相符。

● 在进入EDIT模式时，会一直保留切换前的最终输出音量值，此时VOLUME旋钮用于调校当前编辑音色链的输出电平值。

● 若在EDIT模式编辑音色完毕后，切换到Preset模式，VOLUME旋钮立即成为3个预置音色的最终输出音量值。因此建议用户在退出Edit模式后，请立即把VOLUME旋钮调节到进入Edit模式前的位置，才能恢复到之前演奏状态的最终输出音量值。

● 在EDIT模式下，A/B/C功能踩钉负责开启/关闭对应的效果模块。用户可在EDIT模式下对预置音色进行微调和再次编辑，编辑完成后可长踩A/B/C任一踩钉进行覆盖保存。

CN 如何自定义一个音色

以CUBE-BABY BASS原厂预置‘A’踩钉的音色为例:

- 1、开机初始化完毕后请短按组合踩钉“B+C”切换至LIVE模式，进入LIVE模式后请检查所有旋钮显示灯（除VOLUME旋钮）是否全部关闭，如有未关闭的效果请手动关闭。此时VOLUME旋钮用于调校当前编辑音色链的输出电平值，请将VOLUME旋钮调至适合的位置。
- 2、短按C踩钉开启COMP+EQ模块，将BOOST旋钮调节到时针12点钟位置，将TREB旋钮调节到时针3点钟位置，MID旋钮调节到时针9点钟位置，BASS旋钮调节到时针10点钟位置，COMP旋钮调节到时针12点钟位置。
- 3、接着观察MOD与SPACE模块，此音色不需要使用MOD和SPACE效果，直接让B踩钉指示灯保持熄灭状态即可。
- 4、接着短按A踩钉开启IR CAB模块，将IR CAB旋钮调节至第2档的箱体模拟：Jensen 10 441。
- 5、最后调节音色链的输出电平值，请将VOLUME旋钮调至适合的位置。
- 6、音色已编辑完毕，我选择将音色储存在A踩钉，长踩A踩钉，直至A踩钉的提示灯快速闪烁，接着指示灯恢复慢闪状态，表示音色已经储存完毕。
- 7、此时，我编辑的音色已成功储存在PRESET预置模式，覆盖了A踩钉的音色。

1.自定义IR界面

①IR文件搜索框：通过此搜索框找到预备在电脑里的IR文件。

②IR文件显示框：显示被选中的IR文件，方便点击试听。


③拾音话筒距离模拟器：此旋钮用于调节话筒对音箱的拾音距离，距离越近声音越大，距离越远声音越小（注意：100%距离的情况下，音量为0，需先调整距离，再试听IR）。

④储存位置：CUBE-BABY BASS的IR储存位置序号，可选择1-8的储存位置。

⑤储存按键：当选中第三方IR、调好话筒拾音距离、选择储存位置序号后，点击此按键进行储存。

⑥点击此按键为恢复出厂IR。

⑦点击此按键，为3组预置音色恢复出厂参数。



2.预置参数调节界面

①选择需要调节的预置（3组预置可供选择），软件和设备若处于同一组预置，则可以听到实时调节效果。

②调节当前音色链的输出电平值。

③选择IR箱体模拟。

④调节SPACE模块的回声反馈的时间速度。

⑤参数0-13为混响效果，14-17关闭SPACE模块，18-30为延时效果。

⑥参数0-6为合唱效果，7-8关闭MOD模块，9-14为相移效果。

⑦调节压缩效果大小。

⑧调节低频。


⑨调节中频。

⑩调节高频。

⑪调节激励效果大小。

⑫音色保存按键。

备注：如果已经调节预置的参数，却没点击保存，则设备断电之后，恢复为调节之前的参数。



CN 技术参数

输入	标准 1/4" 单声道接口 /TS
输出	标准 1/4" 单声道接口 /TS
采样率	48KHz/24bit
电池型号规格	603040
电池容量	780mah
电池标称电压	3.7V
尺寸	161(L)X57(W)X17.5(H)mm
重量	260g
附件	说明书、充电线、内录连接线
修订	20240816