


Galaxia

User Manual



I. Preface

To Every Musician Who Has Received "Galaxia":

Thank you for choosing M-VAVE and allowing "Galaxia" to become the first star in your tonal universe.

This digital modeling reverb pedal is like placing an entire galaxy onto your pedalboard — from the warm, intimate space of ROOM, to the expansive soundscape of HALL, from the vintage spring resonance of SPRING, to the refined plate ambience of PLATE, and on to the shimmering starlight of SHIMMER, the soft envelopment of CLOUD, the nostalgic grain of LOFI... Nine reverb modes — nine reverb dimensions across nine distinct corners of the universe.

The stereo input/output design transforms your sound from a single point in mono into a three-dimensional universe that surrounds both ears;

We have poured every romantic vision we hold for sound into this small blue pedal. We hope it will serve as your "Cosmic Reverberator" on your creative journey — turning the melodies in your mind into a boundless ocean of sound, and bringing you an endless source of musical inspiration.

May every strum of your strings ignite a light uniquely your own across this galaxy.

— M-VAVE

II. Attentions

■ The power supply:

Please use 9V(+/-10%) adapter (negative inside and positive outside), otherwise it may cause equipment damage. Please unplug the power when not in use or during thunderstorm weather.

■ The connection:

Be sure to turn off the power of related equipment before connecting or disconnecting the device.

■ The electrical interference:

The electromagnetic wave of radio, television and other equipment may cause interference to the equipment, so please try to stay away from radio , television and other equipment.

■ The location:

To avoid deformation, discoloration, or other serious damage, do not expose this unit to the following conditions:


- a. Heat sources
- b. Magnetic fields
- c. Sunlight
- d. High temperature or moist district
- e. Excessively dusty or dirty locations
- f. Strong vibrations or shocks

III. Features



- Artistically refined aesthetic design featuring a "galaxy" themed visual language, echoing the expansive soundscape imagery of reverb.
- Equipped with 9 custom reverb algorithms spanning three categories — traditional acoustic, atmospheric effects, and lo-fi — to meet the demands of clean, rock, post-rock, vintage, and a wide range of other playing styles.
- Delivers psychedelic, deep tonal shaping capabilities, complemented by exceptional dynamic response performance.
- Full stereo signal chain with stereo input/output support, enabling effortless mono-to-stereo expansion.
- Two power supply options available, adaptable to a variety of usage scenarios.
- Low noise floor with high dynamic processing ensures clean, artifact-free decay tails and a wide dynamic range that preserves the detail of the original signal.
- HOLD footswitch supports freeze effect for instant soundscape switching, offering greater flexibility in live performance and music creation.
- Supports tail fade-out upon bypass, preventing abrupt tonal cutoff and ensuring seamless continuity of performance.

IV. Knob and interface introduction

- ①. **DECAY Knob:** Adjusts the decay time of the reverb effect. The adjustable range varies depending on the selected reverb mode — please refer to the Tone Guide for details.
- ②. **TYPE Knob:** Selects the desired reverb effect. A total of 9 reverb modes are available — please refer to the Tone Guide for details.
- ③. **MIX Knob:** Adjusts the blend ratio between the dry and wet signals.
- ④. **TONE Knob:** Adjusts the tonal brightness of the wet reverb signal.
- ⑤. **LEND Knob:** Adjusts the low-frequency intensity of the reverb tail.
- ⑥. **MOD knob:** Controls the modulation depth for each reverb effect. The function of this knob varies depending on the selected reverb mode — please refer to the Tone Guide for details.
- ⑦. **Power Input:** Use a 9V DC power adapter (center-negative).
- ⑧. **USB-C Port:** Supports 5V power supply; a 5V 1A adapter is recommended.
- ⑨. **Output Jack (MONO):** 1/4" TS Instrument Jack.
- ⑩. **Output Jack (STEREO):** 1/4" TS Instrument Jacks.
- ⑪. **Input Jack (MONO):** 1/4" TS Instrument Jacks.
- ⑫. **Input Jack (STEREO):** 1/4" TS Instrument Jacks.
- ⑬. **LED Indicator:** Displays green when the effect is active; displays yellow when the freeze effect is engaged.
- ⑭. **Footswitch A:** Activates or bypasses the effect module.
- ⑮. **Footswitch B (HOLD):** Press and hold to instantly maximize the wet reverb signal and extend the decay tail indefinitely, achieving an infinite sustain / reverb "freeze" effect. Releasing the footswitch returns the pedal to its normal settings.



Mono input and mono output. Dry and wet signals are mixed together in the mono output.



VI. Tone Introduction

Mode 1: ROOM — Room reverb based on Sinco Space Audio (SSA). Medium-scale matrix modulation simulating a recording studio room environment, suitable for general instruments.

MOD Knob: LENGTH — Controls the intensity of LFO modulation applied to the reverb tail, ranging from subtle natural fluctuation to pronounced vibrato.

DECAY Knob: 0.3–10.0s

Mode 2: HALL — Concert hall reverb based on Sinco Space Audio (SSA), delivering a broad, lightly diffused character that recreates the grandeur of large acoustic environments.

MOD Knob: LENGTH — Controls the intensity of LFO modulation applied to the reverb tail, ranging from subtle natural fluctuation to pronounced vibrato.

DECAY Knob: 3.0–18.0s

Mode 3: PLATE — Plate reverb based on Sinco Space Audio (SSA). Emulates the EMT-140 metal plate with dense diffusion, ideal for drums and vocals.

MOD Knob: LENGTH — Controls the intensity of LFO modulation applied to the reverb tail, ranging from subtle natural fluctuation to pronounced vibrato.

DECAY Knob: 0.3–10.0s

Mode 4: SPRING — Spring reverb based on Sinco Space Audio (SSA). Simulates the ripple characteristics of a metal spring with its signature "boing" resonance.

MOD Knob: DWELL — Controls the number of spring elements.

DECAY Knob: 3.0–10.0s

Mode 5: SHIMMER — Harmonic shimmer reverb based on Sinco Space Audio (SSA), delivering the classic "heavenly" tone.

MOD Knob: PITCH — Adjusts the pitch of the shimmer effect. Minimum value matches the original pitch; maximum value raises it two octaves above the source.

DECAY Knob: 0.3–10.0s

Mode 6: CLOUD — Sky reverb based on Sinco Space Audio (SSA). A lush, large-scale ambient reverb that conjures the sensation of sound cascading from the clouds. A single note unfolds into a vast, multi-layered wash of sound arriving from all directions, creating an exceptionally wide and immersive soundscape.

MOD Knob: DIFFUSION — Adjusts the degree of diffusion and the sense of spatial dimension. Turning the knob clockwise softens the early reflection wet signal, producing a smoother, more seamless blend that blurs the boundary between delay and reverb.

DECAY Knob: 1.0–21.0s

Mode 7: BLOOM — Bloom reverb based on Sinco Space Audio (SSA). Enhanced diffusion is integrated into the reverb to create a gradually blossoming effect. Users are encouraged to experiment with a shorter DECAY paired with a longer LENGTH, or a longer DECAY paired with a shorter LENGTH, to explore how these two parameters interact and complement each other in crafting the desired ambient texture.

MOD Knob: LENGTH — Controls the duration of the bloom effect.

DECAY Knob: 1.0–21.0s

Mode 8: SWELL — Swell reverb based on Sinco Space Audio (SSA). Delivers a smooth, natural transition between signals, producing a gentle rise and an evolving sense of atmosphere — akin to having a volume pedal dedicated to controlling the wet reverb signal.

MOD Knob: RISETIME — Turning the knob clockwise increases the rise time, softening the swell effect for chord and rhythm playing. Turning it counterclockwise shortens the rise time, making it better suited for melodic playing.

DECAY Knob: 0.3–10.0s

Mode 9: LOFI — Lo-Fi reverb based on Sinco Space Audio (SSA). Emulates the wow and flutter, bit degradation, noise floor, and short-tail reverb characteristics of vintage low-fidelity tape recording systems.

TONE Knob: NOISE — Dedicated white noise control that introduces an ethereal, textured grain, allowing users to dial in atmospheric depth at will.

BLEND Knob: CRUSH — Distortion and compression mode that simultaneously engages bit depth reduction and downsampling to create a vintage, fragmented, lo-fi granular texture.

MOD Knob: LENGTH — Tape modulation effect that precisely adjusts the intensity of natural tape wow and flutter, faithfully recreating the languid, organic movement of vintage analog tape.

DECAY Knob: 0.3–10.0s

VII. Technical parameter

Input	Standard 1/4" jack-MONO/TS
Output	Standard 1/4" jack-MONO/TS
Power supply 1	DC 9V $\geq$ 300mA 
Power supply 2	USB 5V $\geq$ 300mA
Size	112(L)X68(W)X40(H)mm
Weight	About 242g

We will continue to improve our products and reserve the right to modify certain functions and specifications (including but not limited to appearance, packaging design, operation manual, accessories, dimensions, specifications, displays, etc.) without prior notice. Please confirm the product functions and specifications with the local distributor before the purchase. Product pictures and color due to the light error and screen admiration setting. It may be different from the physical product effect. Please refer to the physical object accordingly.

VIII. FCC Warning Statement

★ Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located for operating in conjunction with any other antenna or transmitter.


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Galaxia

混响单块效果器

说明书



一、前言

致每一位收到「Galaxia」的音乐人：

感谢您选择 M-VAVE，让「Galaxia」成为您音色宇宙里的第一颗星。

这台数字建模混响效果器，就像把一整片银河装进了您的效果板里——从 ROOM 的暖调小空间，到 HALL 的开阔声场，从 SPRING 的复古弹簧余韵，到 PLATE 的细腻板式回响，再到 SHIMMER 的星光闪烁、CLOUD 的柔雾包裹，LOFI 的复古颗粒……九种混响模式，是九种不同维度的宇宙回响。

立体声输入输出的设计，让您的声音从单声道的点，变成了环绕双耳的立体宇宙；

我们把对声音的所有浪漫想象，都藏进了这块小小的蓝色效果器里，希望它能成为您创作路上的“宇宙回响器”，帮您把脑海里的旋律，铺成一片无边无际的音海，为您带来源源不断的音乐灵感。

愿您的每一次拨弦，都能在这片银河里，撞出独属于您的星光。

——M-VAVE 敬上

二、注意事项

■电源供应：

请使用正确的电源适配器，适配器使用内负外正的9V电源(建议使用9V1A或者5V1A的电源)，擅自使用其他规格电源可能会导致设备损坏！在不需要使用本设备或者雷雨天气时请拔下电源。

■连接：

当连接或者断开设备时，请先关闭其他相关设备。

■电器干扰：

收音机、电视机等电磁波可能会对设备使用造成信号干扰，因此请尽量远离收音机、电视机等其他电子设备。

■放置场所：

为防止变形、变色和其他方面等对产品造成损坏，请尽量避免以下情况：

- a.热源
- b.磁场
- c.阳光直射
- d.高温潮湿
- e.灰尘
- f.强烈震荡或摇晃

三、产品特色

■ 富有艺术感的外观设计，以“银河”为主题的视觉语言，呼应混响的广阔声场意象。

■ 搭载9种定制混响算法，覆盖传统声学、氛围特效、低保真三大类场景，满足清音、摇滚、后摇、复古等多种风格需求。

■ 提供迷幻、深邃的音色塑造能力，同时具备优秀的动态响应表现。

■ 全立体声信号链路，支持立体声输入/输出，单声道转立体声扩展轻松实现。

■ 两种供电方式可选，适配不同使用场景。


■ 低底噪高动态处理，尾音干净无杂音，高动态范围保留原始信号细节。

■ HOLD脚踏支持冻结效果，一键切换声场状态，演出创作更灵活。

■ 关闭模块时支持尾音淡出，避免音色突然切断，保证演奏的连贯性。

四、旋钮以及接口介绍

- ①. **DECAY旋钮**: 调整回声效果的持续时间, 在不同的混响效果下, 参数的可调节范围不完全一样, 请看音色介绍。
- ②. **TYPE旋钮**: 选择要使用的混响效果, 一共9种混响效果, 请看音色介绍。
- ③. **MIX旋钮**: 调节干湿信号的混合比例。
- ④. **TONE旋钮**: 调节混响湿音的音色明暗。
- ⑤. **LEND旋钮**: 调节混响湿音的低频强度。
- ⑥. **MOD旋钮**: 用于每种延迟效果MODULATION的调制, 在不同的混响效果下, 旋钮的功能不完全一样, 请看音色介绍。
- ⑦. **电源接口**: 使用9V直流变压器 (外正内负)。
- ⑧. **USB-C接口**: 支持5V供电, 建议使用5V 1A适配器。
- ⑨. **输出接口 (MONO)**: 1/4"TS Instrument jacks。
- ⑩. **输出接口 (STEREO)**: 1/4"TS Instrument jacks。
- ⑪. **输入接口 (MONO)**: 1/4"TS Instrument jacks。
- ⑫. **输入接口 (STEREO)**: 1/4"TS Instrument jacks。
- ⑬. **LED灯**: 指示绿色效果器激活状态, 指示黄色效果器冻结状态。
- ⑭. **A踩钉**: 激活/关闭模块效果。
- ⑮. **B踩钉**: 踩住 HOLD 脚踏时, 混响的湿声比例瞬间拉满, 尾音持续延长, 实现无限延音 / 混响“冻结”效果, 松开后恢复正常设置。




五、信号路径

输入/输出设置


● 1入1出:

单声道输入和单声道输出。干信号和湿信号在单声道输出中混合在一起。

● 1入2出:



● 2入2出:



六、音色介绍

档位1: ROOM, 基于 Sinco Space Audio(SSA) 的房间混响。中等尺度矩阵调制, 模拟录音棚房间, 适合一般乐器。

MOD旋钮: LENGTH, 用来控制混响尾音被低频振荡器调制的强弱, 让你的尾音产生从轻微自然波动到明显颤音。

DECAY旋钮: 0.3-10.0s

档位2: HALL, 基于 Sinco Space Audio(SSA) 的音乐厅混响, 给人一种宽阔的, 轻微散射的感觉。它能模拟宏大的环境声音。

MOD旋钮: LENGTH, 用来控制混响尾音被低频振荡器调制的强弱, 让你的尾音产生从轻微自然波动到明显颤音。

DECAY旋钮: 3.0-18.0s

档位3: PLATE, 基于 Sinco Space Audio(SSA) 的板式混响。模拟 EMT-140 金属板, 密集扩散, 适合鼓 / 人声。

MOD旋钮: LENGTH, 用来控制混响尾音被低频振荡器调制的强弱, 让你的尾音产生从轻微自然波动到明显颤音。

DECAY旋钮: 0.3-10.0s

档位4: SPRING, 基于 Sinco Space Audio(SSA) 的弹簧混响。模拟波纹弹簧金属特性, 特征是「boing」余振。

MOD旋钮: DWELL, 控制弹簧的数量。

DECAY旋钮: 3.0-10.0s

档位5: SHIMMER, 基于 Sinco Space Audio(SSA) 的协和闪烁混响, 经典「天堂」音色。

MOD旋钮: PITCH, 调节微光声音的音高, 最小值为音高跟原声一致, 最大值为比原声高两个八度。

DECAY旋钮: 0.3-10.0s

档位6: CLOUD, 基于 Sinco Space Audio(SSA) 的天空混响, 一种华丽的大型环境混响, 听起来像是声音从云层卷积而来, 仅仅弹一个音符, 在混响湿音中就出现非常多的声音从各处传来, 声音听起来非常宽广。

MOD旋钮: DIFFUSION, 扩散度, 可调节环境维度感, 当旋钮被顺时针扭大时, 早期反射的混响湿音被软化, 听起来更平滑, 模糊了延迟和混响之间的界限。

DECAY旋钮: 1.0-21.0s

档位7: BLOOM, 基于 Sinco Space Audio(SSA) 的绽放混响, 更多的扩散效果加入到混响效果中, 以得到一种逐渐绽放的感觉。建议用户可尝试用更短的DECAY和更长的LENGTH,或者是更长的DECAY和更短的LENGTH, 来感受这两个参数如何互动与相互补充, 从而得到您想要的一种氛围。

MOD旋钮: LENGTH, 控制绽放效果的时间长度。

DECAY旋钮: 1.0-21.0s

档位8: SWELL, 基于 Sinco Space Audio(SSA) 的浸入混响, 两个信号间进行自然的衔接, 以获得轻微的上升效果和演变氛围感, 就像有个可以控制混响湿音的音量踏板。

MOD旋钮: RISETIME上升时间, 往顺时针调节旋钮时, 上升时间会变长, 听觉上的膨胀效果会减弱, 适合用于演奏和弦节奏; 反之上升时间变短时候, 适合用于演奏旋律。

DECAY旋钮: 0.3-10.0s

档位9: LOFI，基于 Sinco Space Audio(SSA) 的低保真混响。模拟低端磁带录放系统的颤抖、降位、底噪与短尾混响。

TONE旋钮: NOISE，白噪音专属调控，渲染空灵噪点质感，随心增益烘托氛围层次。

LEND旋钮: CRUSH，失真压缩模式，一键联动比特深度弱化与降采样质感拉升，塑造复古破碎颗粒感。

MOD旋钮: LENGTH，磁带调制特效，精准调校磁带 Wow/Flutter 自然抖晃幅度，复刻老式磁带慵懒晃动的模拟味。

DECAY旋钮: 0.3-10.0s

七、技术参数

输入	标准1/4" 单声道接口/TS
输出	标准1/4" 单声道接口/TS
电源供给1	DC9V $\geq$ 300mA 
电源供给2	USB 5V $\geq$ 300mA
尺寸	112(L)X68(W)X40(H)mm
重量	约242g
修订	2026-7-14

我们将不断改进我们的产品并保留修改某些功能和规格（包括但不限于外观、包装设计、操作手册、配件、尺寸、规格参数、显示屏等）的权利，恕不另行通知。

购买前请与当地经销商确认产品功能及规格。产品图片及颜色因拍照光线误差及屏幕设定可能与实物产品效果有所差异。请以实物为准。

All are welcome to use our products!

欢迎各位使用我们的产品！