


ELEMENTAL PRO

User Manual



I. Preface

To Every Musician Who Has Chosen ELEMENTAL PRO

Thank you for choosing M-VAVE and welcoming the ELEMENTAL PRO into your sonic world.

This digital modeling delay processor encapsulates an entire dimension of sonic possibility within your pedalboard. From the warmth of ANALOG echo to the layered depth of DUAL reflections; from the rhythmic breathe of TREMOLO to the spatial sweep of PING PONG; from the otherworldly reverse textures of REVERSE to the crystalline clarity of ICE; from the vintage grain of LOFI to the dynamic sensitivity of DUCK — nine distinct delay modes, each representing a unique expression of time and space.

The stereo input/output architecture transforms your signal from a single point in mono into a fully immersive stereo soundscape. Every detail of sonic vision and engineering craftsmanship has been channeled into this compact purple unit. It is designed to serve as your personal Time Sculptor — helping you transform every melody into a richly layered tapestry of sound, and inspiring boundless creativity throughout your musical journey.

May every note you play send its own unique ripple across the vast universe of sound.

— With Respect, M-VAVE

II. Attentions

■ The power supply:

Please use 9V(+~10%) adapter (negative inside and positive outside), otherwise it may cause equipment damage. Please unplug the power when not in use or during thunderstorm weather.

■ The connection:

Be sure to turn off the power of related equipment before connecting or disconnecting the device.

■ The electrical interference:

The electromagnetic wave of radio, television and other equipment may cause interference to the equipment, so please try to stay away from radio , television and other equipment.

■ The location:

To avoid deformation, discoloration, or other serious damage, do not expose this unit to the following conditions:


- a. Heat sources
- b. Magnetic fields
- c. Sunlight
- d. High temperature or moist district
- e. Excessively dusty or dirty locations
- f. Strong vibrations or shocks

III. Features

- Artistic exterior design.
- A total of 9 delay effects suitable for most music styles.
- ELEMENTAL PRO delivers psychedelic and profound tones with excellent dynamic response.
- Up to 1200ms delay time.
- Two power supply options.
- High-performance digital signal processor for meticulous delay effects.
- TAP tempo function.
- HOLD function for infinite sound sustain.
- Stereo dual-channel mode and ping-pong stereo mode.
- Trails remain and fade out gradually when the effect is turned off.

IV. Knob and interface introduction

- ①. **TIME knob:** Adjusts the delay time. The adjustable parameter range varies depending on the delay effect. Please refer to the sound description.
- ②. **TYPE knob:** Selects the desired delay effect from a total of 9 options. Please refer to the sound description.
- ③. **FEEDBACK knob:** Adjusts the number of delay repeats. (Note: When turned fully clockwise to maximum, the delayed wet signal will sustain indefinitely with looping, unattenuated tails.)
- ④. **MIX knob:** Adjusts the blend ratio between the dry and wet signals.
- ⑤. **PARAM knob:** The function of this knob varies depending on the selected delay effect. Please refer to the sound description.
- ⑥. **MOD knob:** Adds a vibrato effect to the delay wet signal, with this parameter adjusting the speed and depth of the chorus effect.
- ⑦. **Power interface:** For 9V DC power supply (center-negative).
- ⑧. **USB-C interface:** Supports 5V power input. A 5V 1A adapter is recommended.
- ⑨. **Output Jack (MONO):** 1/4" TS Instrument Jacks.
- ⑩. **Output Jack (STEREO):** 1/4" TS Instrument Jacks.
- ⑪. **Input Jack (MONO):** 1/4" TS Instrument Jacks.
- ⑫. **Input Jack (STEREO):** 1/4" TS Instrument Jacks.
- ⑬. **LED Indicator:** Displays the effect unit status. Please refer to the function description.
- ⑭. **Footswitch A:** Activates the module effect. Please refer to the function description.
- ⑮. **Footswitch B:** Activates the module effect. Please refer to the function description.



V. Function Description

- Single press on Footswitch A activates the effect in Standard Mode — the LED indicator flashes green.
- Single press on Footswitch A switches to BYPASS Mode — the LED indicator turns off.
- Long press on Footswitch A switches to Ping-Pong Stereo Mode — the LED indicator flashes red.
- Single press on Footswitch B activates the TAP function — the LED indicator flashes accordingly.
- Long press on Footswitch B activates HOLD Infinite Sustain Mode — the LED indicator remains solid yellow.
- In Standard Mode or Ping-Pong Stereo Mode, press Footswitch B twice or more consecutively to tap in the desired tempo and activate TAP.
- In Standard Mode or Ping-Pong Stereo Mode, long press Footswitch B to activate HOLD — the unit captures the current wet delay signal and holds it indefinitely. The LED indicator remains solid yellow.
- Long press Footswitch A under BYPASS state to enter TAP DIVISION selection mode – the LED indicator flashes yellow at this time.

VI. Mode Introduction

■ **Ping-pong Stereo Mode:** The wet signal bounces between the left and right channels, creating a wide, rhythmic stereo effect. This alternating movement adds depth and motion, making the delay feel spacious, immersive, and vibrant within the mix.

■ **TAP DIVISION Selection Mode:**

This function sets the note value corresponding to the actual delay time configured when you tap the footswitch at quarter-note intervals.

You must set the TAP DIVISION prior to using Tap Delay.


Upon exiting TAP DIVISION Selection Mode, the system automatically saves the selected note value and BPM; rotating the RATE knob will override and update the RATE parameter with priority.

The unit enters TAP DIVISION Setup Mode with the indicator LED flashing orange.

To select TAP DIVISION: Turn the [TYPE] knob to choose a TAP DIVISION value.

The actual delay time corresponding to your selected value is shown in the figure below.

The time interval between pedal taps



VII. Signal Path


Input/Output Settings

● 1 In 1 Out:


Mono input and mono output. Dry and wet signals are mixed together in the mono output.

Note: In Ping-Pong mode, the TIME duration is halved. Please use with caution.

● 1 In 2 Out:



● 2 In 2 Out:



VIII. Tone Introduction

GEAR 1: ANALOG, Analog delay simulates the delay effect of vacuum tube signals, delivering a vintage and warm tone.

PARAM knob: PHASER, Adds a phaser effect to the delayed wet signal and adjusts its intensity.

TIME knob: 100-1200ms

GEAR 2: DUAL, Two independent delay effects. The ratio between the first and second delay times produces intriguing rhythmic delay patterns.

PARAM knob: TIME-MODE, Adjusts the time difference between the two echoes. At minimum, there is virtually no time difference; larger values increase the gap.

TIME knob: 100-1200ms

GEAR 3: DUCK, When processing the delayed wet signal, a ducking effect is applied before the wet sound begins, suppressing the initial portion of the delay. This creates a "swelling" sensation where the delay gradually rises in volume. With very subtle ducking, the delay's dynamics are more "felt" than "heard."

PARAM knob: UNPACK, When increased, this parameter smooths out the sudden volume rise in the latter part of the wet signal, resulting in a more gradual delay dynamic.

TIME knob: 100-1200ms

GEAR 4: TREM, Delay accompanied by synchronized tremolo.

PARAM knob: PATTERN, Adjusts different delay rhythms and their durations.

TIME knob: 100-1200ms

GEAR 5: REVERSE, An enhanced classic reverse delay.

PARAM knob: PHASER, Adds a phaser effect to the delayed wet signal and adjusts its intensity.

TIME knob: 100-1200ms

GEAR 6: dTAPE, It recreates the distinctive delay style of tape machines, delivering not only the warmth and smoothness of professional-grade tape units but also simulating sonic artifacts such as tape wrinkles, wow-flutter, and other authentic tape characteristics.

PARAM knob: GRIT, This parameter adjusts tape bias, ranging from under-bias to over-bias, producing a saturated, overdriven texture in the wet signal. It is used to shape the dynamic range and headroom of the delayed wet sound.

TIME knob: 100-1200ms

GEAR 7: ICE, Ice delay, an effect that cuts off the audio and then plays back the selected audio segment with altered pitch.

PARAM knob: PITCH, Alters the pitch of the played-back audio.

TIME knob: 100-1200ms

GEAR 8: LOFI, A special, vintage, and disruptive delay effect incorporating filters, vinyl crackle, noise, and other lo-fi textures.

PARAM knob: GRIT, This parameter adjusts tape bias, ranging from under-bias to over-bias, producing a saturated, overdriven texture in the wet signal. It is used to shape the dynamic range and headroom of the delayed wet sound.

TIME knob: 100-1200ms

GEAR 9: PATTERN, A creative delay effect featuring more complex rhythmic delay patterns.

PARAM knob: PATTERN, Adjusts different delay rhythms and their durations.

TIME knob: 100-1100ms

IX. Technical parameter

Input	Standard 1/4" jack-MONO/TS
Output	Standard 1/4" jack-MONO/TS
Power supply 1	DC 9V $\geq$ 300mA  
Power supply 2	USB 5V $\geq$ 300mA
Size	112(L)X68(W)X40(H)mm
Weight	About 242g

We will continue to improve our products and reserve the right to modify certain functions and specifications (including but not limited to appearance, packaging design, operation manual, accessories, dimensions, specifications, displays, etc.) without prior notice. Please confirm the product functions and specifications with the local distributor before the purchase. Product pictures and color due to the light error and screen admiration setting. It may be different from the physical product effect. Please refer to the physical object accordingly.

X. FCC Warning Statement

★ Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located for operating in conjunction with any other antenna or transmitter.


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

ELEMENTAL PRO

延迟单块效果器

说明书



一、前言

致每一位收到「ELEMENTAL PRO」的音乐人：

感谢您选择 M-VAVE，让「ELEMENTAL PRO」成为您音色世界里的一道流光。

这台数字建模延迟效果器，就像把一整个时空漩涡装进了您的效果板里——从 ANALOG 的温暖模拟回声，到 DUAL 的双重叠影层次，从 TREMOLO 的呼吸般颤动，到 PINGPONG 的立体声穿梭，再到 REVERSE 的逆序奇幻、ICE 的清冷数字质感、LOFI 的复古颗粒、DUCK 的动态压感……九种延迟模式，是九种不同形态的时空涟漪。

立体声输入输出的设计，让您的声音从单声道的点，变成了穿梭双耳的立体声波；我们把对声音的所有想象与巧思，都藏进了这块小小的紫色效果器里，希望它能成为您创作路上的“时光塑形器”，帮您把每一段旋律，织成一张层次丰富的音网，为您带来源源不断的音乐灵感。

愿您的每一次拨弦，都能在这片音波宇宙里，泛起独属于您的涟漪。

——M-VAVE 敬上

二、注意事项

■电源供应：

请使用正确的电源适配器，适配器使用内负外正的9V电源(建议使用9V1A或者5V1A的电源)，擅自使用其他规格电源可能会导致设备损坏！在不需要使用本设备或者雷雨天气时请拔下电源。

■连接：

当连接或者断开设备时，请先关闭其他相关设备。

■电器干扰：

收音机、电视机等电磁波可能会对设备使用造成信号干扰，因此请尽量远离收音机、电视机等其他电子设备。

■放置场所：

为防止变形、变色和其他方面等对产品造成损坏，请尽量避免以下情况：

- a.热源
- b.磁场
- c.阳光直射
- d.高温潮湿
- e.灰尘
- f.强烈震荡或摇晃

三、产品特点

■ 富有艺术感的外观设计。

■ 一共9种延迟效果，适用于大部分音乐风格。

■ ELEMENTAL PRO会让你得到迷幻、深邃的音色，而且它有良好的动态响应。

■ 最长1200ms的延迟时间。

■ 两种供电方式可选。

■ 高性能数字信号处理器，细致入微的延迟效果。

■ TAP打拍定速功能。


■ HOLD功能让声音无限延音功能。

■ 立体声双通道模式与乒乓立体声模式

■ 关闭模块时保留尾音慢慢淡出

四、旋钮以及接口介绍

- ①. **TIME旋钮**: 调整延迟效果的时间, 在不同的延迟效果下, 参数的可调节范围不完全一样, 请看音色介绍。
- ②. **TYPE旋钮**: 选择要使用的延迟效果, 一共9种延迟效果, 请看音色介绍。
- ③. **FEEDBACK旋钮**: 调节延迟的反馈次数 (注意: 开到最大值时, 延迟湿声会持续不断, 尾音循环留存不衰减)。
- ④. **MIX旋钮**: 调节干湿信号的混合比例。
- ⑤. **PARAM旋钮**: 在不同的延迟效果下, 旋钮的功能不完全一样, 请看音色介绍。
- ⑥. **MOD旋钮**: 在Delay湿声增加颤音效果, 此参数可调节合唱效果的速度及深度。
- ⑦. **电源接口**: 使用9V直流变压器 (外正内负)。
- ⑧. **USB-C接口**: 支持5V供电, 建议使用5V 1A适配器。
- ⑨. **输出接口 (MONO)**: 1/4"TS Instrument jacks。
- ⑩. **输出接口 (STEREO)**: 1/4"TS Instrument jacks。
- ⑪. **输入接口 (MONO)**: 1/4"TS Instrument jacks。
- ⑫. **输入接口 (STEREO)**: 1/4"TS Instrument jacks。
- ⑬. **LED灯**: 指示效果器状态, 请看功能介绍。
- ⑭. **A踩钉**: 激活模块效果, 请看功能介绍。
- ⑮. **B踩钉**: 激活模块效果, 请看功能介绍。



五、功能介绍

- 单次A触发踩钉激活效果器普通模式——此时LED指示灯为绿色闪烁状态。
- 单次A触发踩钉切换BYPASS模式——此时LED指示灯为熄灭状态。
- 长踩A触发踩钉切换乒乓立体声模式——此时LED指示灯为红色闪烁状态。
- 单次B触发踩钉激活TAP功能——此时LED指示灯为闪烁状态。
- 长踩B触发踩钉激活HOLD无限延音模式——此时LED指示灯为黄灯长亮状态。
- 在正常模式与乒乓立体声模式下TAP——连续触发踩钉2次或以上可TAP获取速度。激活TAP。
- 在正常模式或者乒乓立体声模式下长按B踩钉激活HOLD模块——机器会读取此刻的延时湿声, 这个读取后的湿声会一直保持, LED指示灯为黄色状态。
- 在bypass状态下长踩A踩钉进入TAP DIVISION选择模式——功能此时LED指示灯为黄灯闪烁状态。

六、模式介绍

■ **乒乓立体声模式 (Ping-pong Stereo Mode)** 湿信号在左右声道之间反弹，产生宽广、有节奏的立体声效果。这种交替的动作增加了深度和运动，使延迟在混音中感觉宽敞、身临其境且生动。

■ **TAP DIVISION选择模式:**


这样可指定与按四分音符间隔踩下踏板时实际设置的延迟时间相对应的音符值。在使用轻击延迟之前必须先指定该TAP DIVISION。

退出TAP DIVISION选择模式时，系统将自动保存本次选定的音符时值与BPM;旋转RATE旋钮会优先覆盖并更新RATE参数。

该设备现在处于TAPDIVISION设置模式，指示灯呈橙色闪烁。

选择TAPDIVISION。使用[TYPE]旋钮选择TAPDIVISION值。

根据您选择的值，实际延迟时间将按如图所示。



七、信号路径


输入/输出设置

● 1入1出:


单声道输入和单声道输出。干信号和湿信号在单声道输出中混合在一起。

注意：在乒乓模式下TIME的时间减半，请谨慎使用

● 1入2出:



● 2入2出:



八、音色介绍

档位1: ANALOG，模拟延迟是模拟电子管的信号的延迟效果，音色具有复古、温暖等特点。

PARAM旋钮: PHASER，相当于在延迟湿声加入了一点相移效果，调节效果的量。

TIME旋钮: 100-1200ms

档位2: DUAL，两个独立的延迟效果，第一个延时和第二个延时时间的比例达到非常有趣的延迟节奏效果。

PARAM旋钮: TIME-MODE，调节两个回音之间的时差，最小值时候就跟相当于没有时差，数值越大时差越大。

TIME旋钮: 100-1200ms

档位3: DUCK，我们在处理延时湿音时候，在湿音发声前部分加入了降噪效果，从而抑制湿音的前部分声音，达到一种前面闪避的效果，有慢慢增大的声音听感。通过非常轻微的闪避，延迟的动态更多的是“感觉到”而不是“听到”。

PARAM旋钮: UNPACK，解除，参数调大后，可解除湿声后部分音量的突然上升感觉，从而达到一种更平缓的延时动态。

TIME旋钮: 100-1200ms

档位4: TREM，伴随着同步颤音的延迟效果。

PARAM旋钮: PATTERN，调节不同的延迟节奏以及长短。

TIME旋钮: 100-1200ms

档位5: REVERSE，一种经过改进的经典反向延迟。

PARAM旋钮: PHASER，相当于在延迟湿声加入了一点相移效果，调节效果的量。

TIME旋钮: 100-1200ms

档位6: dTAPE，它复刻了磁带机特有的延时风格，你不仅能获得专业级别磁带机的温暖和丝滑，而且能模拟磁带在褶皱、偏差等等真实情况下的声音特效。

PARAM旋钮: GRIT，这个参数调整磁带机的偏差，从欠偏差到过偏差，听起来就像湿音过载的感觉。它用于调整延迟湿音的动态范围和余量。

TIME旋钮: 100-1200ms

档位7: ICE，结冰延迟，一种切断音频，然后回放被选择的音频的延迟效果。可以改变回放音频的音高。

PARAM旋钮: PITCH，改变回放音频的音高。

TIME旋钮: 100-1200ms

档位8: LOFI，一种特殊、复古且具有破坏性的延时效果，增加了过滤器，黑胶唱片，噪音低保真等多种效果。

PARAM旋钮: GRIT，这个参数调整磁带机的偏差，从欠偏差到过偏差，听起来就像湿音过载的感觉。它用于调整延迟湿音的动态范围和余量。

TIME旋钮: 100-1200ms

档位9: PATTERN，一种充满想象力并拥有更复杂的延迟节奏的延迟效果。

PARAM旋钮: PATTERN，调节不同的延迟节奏以及长短。

TIME旋钮: 100-1100ms

九、技术参数

输入	标准1/4" 单声道接口/TS
输出	标准1/4" 单声道接口/TS
电源供给1	DC9V $\geq$ 300mA 
电源供给2	USB 5V $\geq$ 300mA
尺寸	112(L)X68(W)X40(H)mm
重量	约242g
修订	2026-7-17

我们将不断改进我们的产品并保留修改某些功能和规格(包括但不限于外观、包装设计、操作手册、配件、尺寸、规格参数、显示屏等)的权利，恕不另行通知。

购买前请与当地经销商确认产品功能及规格。产品图片及颜色因拍照光线误差及屏幕设定可能与实物产品效果有所差异。请以实物为准。