


USER MANUAL



PRECISION TUNER



CubeSuite for Android/iOS: scan the QR code

Preface

Thank you for purchasing the PRECISION TUNER. This tuner is work on the chromatic mode, it is suitable for most electronic instruments. We do our best to develop this pedal, I hope you like it.

Attentions

■ The power supply:

Please use 9V(+/-10%) adapter (negative inside and positive outside), otherwise it may cause equipment damage. Please unplug the power when not in use or during thunderstorm weather.

■ The connection:

Be sure to turn off the power of related equipment before connecting or disconnecting the device.

■ The electrical interference:

The electromagnetic wave of radio, television and other equipment may cause interference to the equipment, so please try to stay away from radio, television and other equipment.

■ The location:


To avoid deformation, discoloration, or other serious damage, do not expose this unit to the following conditions:

- a. Heat sources
- b. Magnetic fields
- c. Sunlight
- d. High temperature or moist district
- e. Excessively dusty or dirty locations
- f. Strong vibrations or shocks

Features

- This product is a compact metal appearance design.
- This pedal work on high precision and fast response speed.
- Real bypass.
- The screen looks very clear, it can help you get the pitch and note name quickly.
- In the tuning mode, the output is muted.
- For the note names with sharp/flat sign, the system defaults only to use # (sharp sign) to indicate, for example, "C#" is displayed on the screen as "C#".
- When you tuning the string, please look at the display bar, if only the blue lighting up at the center means that the pitch of the string is close to the note name on the screen, if the red lighting up to the left means that the pitch is lower than the note name, if the red lighting up to the right means that the pitch is higher than the note name.

Control panel instruction



①Power jack

Please use 9V DC adapter (negative inside and positive outside).

②USB jack

Support power supply, suggest to use 5V 1A adapter.

③Display bar

Display bar show you the pitch deviation.

④Sharp sign

For example, "C#" is displayed on the screen as "C#".

⑤Screen

Show the note name on the screen.

⑥Output jack

1/4" MONO audio output jack to connect mixer or speaker.

⑦Input jack

1/4" MONO audio input jack to connect instrument.

⑧Footswitch

Enable/bypass the TUNER by tap the footswitch.

Technical parameter

Input	Standard 1/4" jack-MONO/TS
Output	Standard 1/4" jack-MONO/TS
Power supply 1	DC9V $\geq$ 300mA $\oplus\ominus\oplus$
Power supply 2	USB 5V $\geq$ 300mA
Size	90mm(L) x 40mm(W) x 34.5mm(H)
Turning range	12Hz-4186Hz
Turning precision	± 1 cent
Weight	221g

Disclaimer: Specifications are subject to change without notice.