


M-VAVE

USER MANUAL



DIGITAL PITCH

- **Website:** www.m-vave.com
- **CubeSuite for Windows/Mac OS:** <http://www.m-vave.com/appdownload>
- **CubeSuite for Android/iOS:** scan the QR code



Preface

Thank you for purchasing the DIGITAL PITCH. This pedal is a pure-digital product. It provides 9 types of pitch adjustments, you can control the wet or dry independently. We do our best to develop this pedal, I hope you like it.

Attentions

■ The power supply:

Please use 9V(+/-10%) adapter (negative inside and positive outside), otherwise it may cause equipment damage. Please unplug the power when not in use or during thunderstorm weather.

■ The connection:

Be sure to turn off the power of related equipment before connecting or disconnecting the device.

■ The electrical interference:

The electromagnetic wave of radio, television and other equipment may cause interference to the equipment, so please try to stay away from radio, television and other equipment.

■ The location:


To avoid deformation, discoloration, or other serious damage, do not expose this unit to the following conditions:

- a. Heat sources
- b. Magnetic fields
- c. Sunlight
- d. High temperature or moist district
- e. Excessively dusty or dirty locations
- f. Strong vibrations or shocks

Features

- This product is a compact metal appearance design.
- This product comes from our company's professional digital algorithm.
- Real bypass.
- It provides 9 types of pitch adjustments.
- You can control the wet or dry independently.

Control panel instruction



①Power jack

Please use 9V DC adapter (negative inside and positive outside).

②USB jack

Support power supply, suggest to use 5V 1A adapter.

③WET knob

Adjust the volume of wet by turning the WET knob.

④DRY knob

Adjust the volume of dry by turning the DRY knob.

⑤PITCH selection knob

Select the type of Pitch adjustments, please see the Table below.

⑥Output jack

1/4" MONO audio output jack to connect mixer or speaker.

⑦LED

The LED lights up when the effect pedal is enabled, or goes out in bypass mode.

⑧Input jack

1/4" MONO audio input jack to connect instrument.

⑨Footswitch

Enable/bypass the DIGITAL PITCH by tap the footswitch.

Pitch Types

NO.	Harmony /Pitch Shift
1.	-12 semitones
2.	-7 semitones
3.	-3 semitones
4.	-1 semitone
5.	+1 semitone
6.	+3 semitones
7.	+5 semitones
8.	+7 semitones
9.	+12 semitones

Technical parameter

Input	Standard 1/4"jack-MONO/TS
Output	Standard 1/4"jack-MONO/TS
Power supply 1	DC9V≥300mA 
Power supply 2	USB 5V≥300mA
Size	90mm(L) x 40mm(W) x 34.5mm(H)
Weight	221g

Disclaimer: Specifications are subject to change without notice.