


M-VAVE

USER MANUAL



FUZZ

- **Website:** www.m-vave.com
- **CubeSuite for Windows/Mac OS:** <http://www.m-vave.com/appdownload>
- **CubeSuite for Android/iOS:** scan the QR code



Preface

Thank you for purchasing the FUZZ.This pedal was designed for electric guitar,it will let you get a unique and retro distortion timble.We do our best to develop this pedal,I hope you like it.

Attentions

■ The power supply:

Please use 9V(+/-10%) adapter (negative inside and positive outside), otherwise it may cause equipment damage. Please unplug the power when not in use or during thunderstorm weather.

■ The connection:

Be sure to turn off the power of related equipment before connecting or disconnecting the device.

■ The electrical interference:

The electromagnetic wave of radio, television and other equipment may cause interference to the equipment, so please try to stay away from radio , television and other equipment.

■ The location:


To avoid deformation, discoloration, or other serious damage, do not expose this unit to the following conditions:

- a. Heat sources
- b. Magnetic fields
- c. Sunlight
- d. High temperature or moist district
- e. Excessively dusty or dirty locations
- f. Strong vibrations or shocks

Features

- This product is a compact metal appearance design.
- The FUZZ pedal will provide you a classical and retro timble.
- Real bypass.
- If you want to get more distortion to your guitar,the FUZZ can help you,it can let your guitar get a more aggressive,stronger and richer timble.

Control panel instruction



①Power jack

Please use 9V DC adapter (negative inside and positive outside).

②USB jack

Support power supply,suggest to use 5V 1A adapter.

③LEVEL knob

Adjust the output volume by turning the LEVEL knob.

④TONE knob

Adjust the brightness by turning the TONE knob.

⑤GAIN knob

Adjust the gain by turning the GAIN knob.

⑥Output jack

1/4" MONO audio output jack to connect mixer or speaker.

⑦LED

The LED lights up when the effect pedal is enabled ,or goes out in bypass mode.

⑧Input jack

1/4" MONO audio input jack to connect instrument.

⑨Footswitch

Enable/bypass the FUZZ by tap the footswitch.

Technical parameter

Input	Standard 1/4"jack-MONO/TS
Output	Standard 1/4"jack-MONO/TS
Power supply 1	DC9V≥300mA ⏻⏻⏻
Power supply 2	USB 5V≥300mA
Size	90mm(L) x 40mm(W) x 34.5mm(H)
Weight	221g

Disclaimer:Specifications are subject to change without notice.