


USER MANUAL

2.4 GHZ WIRELESS SYSTEM



EN Attentions

Thank you for choosing our Wireless System. The product is designed for musical instruments for wireless connection. We have tried our best to provide you a low noise and latency, high sound quality(48KHz) and long transmission distance wireless device. Enjoy yourself with the wireless system.

Power Supply

The USB cable is mainly for charging. Please use this to connect to USB interface of your devices and make sure you use a qualified adapter. While charging, please make sure that the device is shut down to avoid the loss of electricity during charging, which will lead to longer charging time and shorter battery life.

When the device is not in use, please shut down in time to avoid continuous battery consumption.

Connections

Please always turn off the power of the equipment when connecting or disconnecting with the guitar. It will help to prevent the damage cause to this product and other relevant equipment.

Interference


Operation is subject to the two following conditions:(1)this device may not cause harmful interference, and (2)this device must accept any interference received, including the interference that may cause undesired operation.

Warning

To reduce the risk of fire of electric shock, please do not expose appliance to rain or moisture.

EN Specification

- Sample range: 24bit/48KHz uncompressed digital transmission.
- Latency: <12ms.
- Range: 30 meters outdoor or 15 meters wall distance.
- THD+ Noise: -98dB.
- Dynamic Range: >105dB A weighted.
- Operating Band: 2.4GHz ISM Worldwide.
- Using time: about 7.5h.
- Frequency response: 20~20KHz, +1dB/-3dB.
- Battery Model/Type TX/RX: 603040/602040.
- Battery capacity TX/RX: 780mAh/450mAh.
- Battery Nominal Voltage: 3.7V.
- 280°rotating head,fit for most kind of instruments.
- Support 6 sets of devices work at the same time.
- USB port for charging.



Transmitter

① Signal in, connect to your electronic instrument, such as electronic guitar and bass.

② 280° rotating head, it is available for most of the music instruments.

③ USB port for charging.

④ LED light.

■ RED LED: LED light have two states

Light up: (1) when charging the device or (2) the power of the battery is running out.

■ GREEN LED: LED light are available in three states


Light up: pairing successfully and the power of the battery is in good status.

Flash slowly: just turn on but not in pairing status.

Flash fast: in pairing status.

⑤ Pairing key, long press to turn to pairing status after power on.

⑥ Power, turn the power on or off.



Receiver

- ① Signal out, connect to amplifier or pedal etc.
- ② 280°rotating head, it is available for most of the music instruments.
- ③ USB port for charging.
- ④ LED light.

RED LED:LED light have two states

■ Light up: (1)when charging the device or (2)the power of the battery is running out.

■ GREEN LED:LED light are available in three states


Light up: pairing successfully and the power of the battery is in good status.

Flash slowly: just turn on but not in pairing status.

Flash fast: in pairing status.

⑤ Pairing key, long press to turn to pairing status after power on.

⑥ Power,turn the power on or off.




■ Plug in the transmitter to your guitar signal output port, and plug in the receiver to amplifier or pedal input port.

■ Turn on the power of transmitter and receiver devices. And you can see the LED lights of both are lit in green and flash slowly. That means the devices are not paired.


■ Press and hold the pairing key of receiver. Then the LED lights will flash fast with the meaning of in pairing status; press and hold the pairing key of transmitter, After a short while, the lights of the both devices will turn to GREEN. That means the devices are paired successfully.

■ Please charge your transmitter or receiver via the USB port when the power is running out (LED light can not be lit or keep RED status).

■ Our wireless system can support: (1) 6 pairs of devices work non-interference under the same circumstances and (2) One transmitter transmit signal to several receivers at the same time.



(1)



(2)

1. Q: Device cannot be powered on and doesn't work.

A: If the device unused for a long time, or powered off during low battery but then doesn't charge in time. The battery enters into protection mode due to low battery, and you need to charge it and activate the battery.

2. Q: Device can be powered on, but cannot operate and no sound at all.

A: Please check up whether the green LED is on, if the LED is flashing, then you need to pair the Transmitter and Receiver.

3. Q: Strange noise while in use.

A: There is quite strong electromagnetic interference, or the transmission distance is too far, and thus most communication data is lost. Please try to shorten the transmission distance.

4. Q: Device cannot be charged properly.

A: The lithium battery enters into protection if it's in low battery for a long time, therefore you need to charge it for over 10 minutes to activate the battery.

5. Q: This wireless Transceiver can multiple Receivers pick up from one Transmitter?

A: Yes. While pairing, first let all the Receivers enter into pairing status, then Transmitter enter into pairing status, when the pairing is finished, you can use 1 Transmitter with multiple Receivers.

EN FCC Warning Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible

for compliance could void the user's authority to operate the equipment.


NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a

residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the User is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

用户说明书

2.4 GHz无线耳返传输系统



CN Attentions / 注意事项

首先感谢您选购我们这款无线传输系统。此产品是一款为乐器无线连接使用而开发的设备。我们尽了最大的努力为您呈现这款低噪音，低延迟，并拥有高音质采样率（48KHz）和长有效传输距离的无线设备。希望您会喜欢它。

注意事项

电源供应

无线设备内置锂电池，我们提供了专门的USB充电线，充电时请确保设备为关机状态，以避免充电过程中电量流失，导致充电时间加长且电池使用寿命缩短。在不使用无线设备时请关机，否则电量会持续消耗。

连接

当该无线设备与吉他音箱等设备连接或断开前，请务必关闭电源及其他相关设备，这将有助于避免设备故障和损害其他设备。

干扰


本设备在2.4GHz频段播出，成功避免了电视台，公共广播，手机信号塔和其他高功率信号源造成的干扰。但我们仍建议您使用时远离路由器或其他无线系统设备。

警告

为了减少触电或者火灾等风险发生，请不要在下雨或者潮湿环境下暴露使用该设备。


CN Specification / 产品参数

- 采样率：24bit/48KHz无压缩数据传输
- 延迟：<12ms
- 有效距离：30米室外传输距离或15米穿墙距离
- 失真度：-98dB
- 动态范围：>105dB
- 使用频段：2.4GHz ISM频段
- 使用时间：约7.5小时
- 频率响应：20~20KHz，+1dB/-3dB
- 电池型号规格TX/RX：603040/602040
- 电池容量TX/RX：780mAh/450mAh
- 电池标称电压：3.7V
- 280°可旋转接头，可适合绝大部分电声乐器使用
- 可支持6组设备同时工作
- USB充电接口




Transmitter / 发射器

- ① 输入信号插头，可插入乐器发射端。
- ② 280°可旋转接头。
- ③ USB充电接口。
- ④ LED指示灯。
- 当显示为红灯时：LED指示灯有2种状态。
常亮：表示设备正在充电。
闪烁：提示该设备的电池电量不足。
- 当显示为绿灯时：LED指示灯有3种状态。
慢速闪烁：当前设备处于空闲状态，还没配对。
快速闪烁：当前设备处于配对状态。
常亮：工作状态，已配对成功。
- ⑤ 配对按钮：长按按钮进入配对状态，绿灯快闪。
- ⑥ 电源：打开或关闭设备。



Receiver / 接收器


- ① 输出信号，连接到音箱或者效果器等。
- ② 280°可旋转接头。
- ③ USB充电接口。
- ④ LED指示灯。
- 当显示为红灯时：LED指示灯有2种状态。
常亮：表示设备正在充电。
闪烁：提示该设备的电池电量不足。
- 当显示为绿灯时：LED指示灯有3种状态。
慢速闪烁：当前设备处于空闲状态，还没配对。
快速闪烁：当前设备处于配对状态。
常亮：工作状态，已配对成功。
- ⑤ 配对按钮：长按按钮进入配对状态，绿灯快闪。
- ⑥ 电源：打开或关闭设备。



1. 分别打开接收器Receiver和发射器Transmitter电源，等待设备正常启动后，两设备指示灯均为绿灯慢闪状态。
2. 长按接收器的配对按钮约3秒，使绿灯快闪，进入配对状态。
3. 长按发射器的配对按钮约3秒，使绿灯快闪，进入配对状态。
4. 等待1秒后，自动连接成功，两设备均为绿灯常亮。
5. 发射器连接乐器，接收器连接音箱。
6. 成功配对一次，以后开机都会自动配对。


扩展功能

1. 本产品的无线系统可支持6对独立发射器和接收器在相同的环境下同时工作。



(1)

2. 无线系统可支持一个发射器Transmitter发送信号到多个接收器Receiver上。



(2)

1.问:设备无法开机?

答:如果设备长时间未使用,或电池电量不足时断电却未及时充电。电池电量不足导致电池进入保护模式,需要给电池充电以激活电池。

2.问:设备可以开机,但不能使用,根本没有声音?

答:请检查绿色LED是否点亮,如果LED闪烁,则需要配对发射器和接收器。

3.问:使用时发出奇怪的噪音?

答:可能有很强的电磁干扰、传输距离太远、传输障碍物太多,因此大多数通信数据丢失。请尽量缩短传输距离。

4.问:设备无法正常充电?

答:锂电池长时间处于低电量状态时会进入保护状态,因此需要充电10分钟才能启动电池。

5.问:多个接收器可同时从一个发射器中接收信号吗?

答:可以,配对时先让所有接收器进入配对状态,再让发射器进入配对状态,完成配对即可。