SIGNAL	IN/OUT	DIGITAL/ANALOG
TX	IN	DIGITAL
RX	IN	DIGITAL
BUZZER	OUT	DIGITAL
HEATER	OUT	DIGITAL

NOTE
HIGH when active, LOW otherwise
HIGH when active, LOW otherwise
Always LOW, HIGH when activated
Always LOW, HIGH when activated