SkyGloss

RESIN FILM

Professional Application Guide

Achieve a flawless, factory-fresh finish by following these precise application steps for the SkyGloss RESIN FILM System.

Preparation – Set the Stage for Perfection

1. Wash & Decontaminate

- Thoroughly wash the vehicle to remove all dirt, grease, and debris.
- Polish the surface if necessary to eliminate oxidation or fine scratches.
- Towel-dry completely — no moisture should remain before coating.

2. Remove Wax & Silicone Residue

- If previous wax or silicone products were used, strip them off using a degreasing agent.
- The surface must be completely clean and residue-free for proper bonding.
- Clean surface with IPA before application.

3. Ideal Working Conditions

- Apply indoors or in a controlled, dust-free environment.
- Avoid direct sunlight, wind, or high humidity.
- Ensure the engine is cool — heat from a running engine can affect leveling and curing.

Step 1 – Apply RESIN COAT (Base Layer)

1. Shake the bottle well before use.
2. Apply **5–7 drops** of RESIN COAT onto the microfiber applicator pad.
3. Spread evenly using straight, overlapping motions — work in **sections of 50–70 cm²** at a time.
4. Allow the coating to flash for **2–4 minutes**.
5. Buff gently with the provided microfiber cloth until clear and streak-free.
6. Continue panel-by-panel until the entire vehicle is coated.

Pro Tip: Maintain consistent lighting to easily spot high or uneven spots during application.

Step 2 – Drying & Hardening

- Allow the **RESIN COAT** layer to dry naturally for **2–4 hours** depending on ambient temperature.
- **Infrared lamps may be used** to accelerate curing — *only on the first layer (RESIN COAT).*

Step 3 – Apply FILM COAT (Top Layer)

1. Once the base layer is fully cured, proceed with **FILM COAT**.
2. Shake well, then apply 5–7 drops to a clean applicator.
3. Spread evenly in **50–70 cm²** sections.
4. Wait **2–4 minutes**, then buff with a clean microfiber cloth.
5. Repeat process on all panels.

You've now completed the full **SkyGloss RESIN FILM System** — forming a deep-gloss, self-healing, factory-grade finish.

Aftercare – Protect the Perfection

- Avoid water contact or washing for **24 hours** after application.
- Full curing occurs within **14 days (Self healing properties activate after full cure)** — during this period:
  - Do **not** use automatic car washes.
  - Avoid detergents with strong alkalis or harsh chemicals.

SKYGLOSS, INC. 21575 N 11TH PL, UNIT 120, PHOENIX, AZ 85024 UNITED STATES. 602 705 3343. INFO@SKYGLOSS.COM. SKYGLOSS.COM