# How big is the cache?

For a byte-addressable machine with 16-bit addresses with a cache with the following characteristics:


- It is direct-mapped (as discussed last time)
- Each block holds one byte
- The cache index is the four least significant bits

#### Two questions:

How many blocks does the cache hold?









How many bits of storage are required to build the cache (e.g., for the

data array, tags, etc.)?





## How big is the cache?

For a byte-addressable machine with 16-bit addresses with a cache with the following characteristics:

- It is direct-mapped (as discussed last time)
- Each block holds one byte
- The cache index is the four least significant bits

#### Two questions:

How many blocks does the cache hold?


```
4-bit index \rightarrow 2<sup>4</sup> = 16 blocks
```

How many bits of storage are required to build the cache (e.g., for the data array, tags, etc.)?

```
tag size = 12 bits (16 bit address - 4 bit index)
(12 tag bits + 1 valid bit + 8 data bits) x 16 blocks = 21 bits x 16 = 336 bits
```


## **Direct-mapped caches**

- If the cache contains 2<sup>k</sup> blocks, then the k least significant bits (LSBs) are used as the index.
  - data from address i would be stored in block i mod 2k.
- For example, data from memory address 11 maps to cache block 3 on the right, since 11 mod 4 = 3 and since the lowest two bits of 1011 are 11.



## Tags & Valid bits

- To find data stored in the cache, we need to add tags to distinguish between different memory locations that map to the same cache block.
- We include a single valid bit per block to distinguish full and empty blocks.



## More cache organizations



- Today, we'll explore some cache organizations to improve hit rate
  - How can we take advantage of spatial locality too?
  - How can we reduce the number of potential conflicts?

## Spatial locality


- One-byte cache blocks don't take advantage of spatial locality, which predicts that an access to one address will be followed by an access to a nearby address.
- What can we do?



## Spatial locality

What we can do is make the cache block size larger than one byte.

- Here we use twobyte blocks, so we can load the cache with two bytes at a time.
- If we read from address 12, the data in addresses
   12 and 13 would both be copied to cache block 2.




#### **Block addresses**

- Now how can we figure out where data should be placed in the cache?
- It's time for block addresses! If the cache block size is  $2^n$  bytes, we can conceptually split the main memory into  $2^n$ -byte chunks too.
- To determine the block address of a byte address *i*, you can do the integer division

 $i/2^n$ 

- Our example has two-byte cache blocks, so we can think of a 16-byte main memory as an "8-block" main memory instead.
- For instance, memory addresses 12 and 13 both correspond to block address 6, since 12 / 2 = 6 and 13 / 2 = 6.




## Cache mapping

 Once you know the block address, you can map it to the cache as before: find the remainder when the block address is divided by the number of cache blocks.

re cache organizations


 In our example, memory block 6 belongs in cache block 2, since 6 mod 4 = 2.

 This corresponds to placing data from memory byte addresses
 12 and 13 into cache block 2.




## Data placement within a block

- When we access one byte of data in memory, we'll copy its entire block into the cache, to hopefully take advantage of spatial locality.
- In our example, if a program reads from byte address 12 we'll load all of memory block 6 (both addresses 12 and 13) into cache block 2.
- Note byte address 13 corresponds to the same memory block address! So a read from address 13 will also cause memory block 6 (addresses 12 and 13) to be loaded into cache block 2.
- To make things simpler, byte i of a memory block is always stored in byte i of the corresponding cache block.




## Locating data in the cache


- Let's say we have a cache with  $2^k$  blocks, each containing  $2^n$  bytes.
- We can determine where a byte of data belongs in this cache by looking at its address in main memory.
  - -k bits of the address will select one of the  $2^k$  cache blocks.
  - The lowest n bits are now a block offset that decides which of the  $2^n$  bytes in the cache block will store the data.




Our example used a 2<sup>2</sup>-block cache with 2<sup>1</sup> bytes per block. Thus, memory address 13 (1101) would be stored in byte 1 of cache block 2.




## A picture



#### An exercise



#### An exercise




For the addresses below, what byte is read from the cache (or is there a miss)?

- 1010 (0xDE)
- 1110 (miss, invalid)
- 0001 (0xFE)
- 1101 (miss, bad tag)

## Using arithmetic

 An equivalent way to find the right location within the cache is to use arithmetic again.



- We can find the index in two steps, as outlined earlier.
  - Do integer division of the address by  $2^n$  to find the block address.
  - Then mod the block address with  $2^k$  to find the index.
- The block offset is just the memory address mod  $2^n$ .
- For example, we can find address 13 in a 4-block, 2-byte per block cache.
  - The block address is 13 / 2 = 6, so the index is then 6 mod 4 = 2.
  - The block offset would be 13 mod 2 = 1.


## A diagram of a larger example cache

Here is a cache with 1,024 2 bits Address (32 bits) blocks of 4 bytes each, and 32-bit memory addresses. Index Valid Tag Data 1022 1023 Tag Mux Data Hit

## A larger example cache mapping


- Where would the byte from memory address 6146 be stored in this direct-mapped 2<sup>10</sup>-block cache with 2<sup>2</sup>-byte blocks?
- We can determine this with the binary force.
  - 6146 in binary is 00...01 1000 0000 00 10.
  - The lowest 2 bits, 10, mean this is the second byte in its block.
  - The next 10 bits, 1000000000, are the block number itself (512).
- Equivalently, you could use your arithmetic mojo instead.
  - The block offset is 6146 mod 4, which equals 2.
  - The block address is 6146/4 = 1536, so the index is 1536 mod 1024, or 512.

## A larger diagram of a larger example cache mapping



### What goes in the rest of that cache block?


■ The other three bytes of that cache block come from the same memory block, whose addresses must all have the same index (1000000000) and the same tag (00...01).



#### The rest of that cache block

- Again, byte i of a memory block is stored into byte i of the corresponding cache block.
  - In our example, memory block 1536 consists of byte addresses 6144 to 6147. So bytes 0-3 of the cache block would contain data from address 6144, 6145, 6146 and 6147 respectively.
  - You can also look at the lowest 2 bits of the memory address to find the block offsets.

Block offset	Memory address	Decimal
00	0001 1000000000 00	6144
01	0001 1000000000 01	6145
10	0001 1000000000 10	6146
11	0001 1000000000 11	6147




## Disadvantage of direct mapping

The direct-mapped cache is easy: indices and offsets can be computed with bit operators or simple arithmetic, because each memory address belongs in exactly one block.

But, what happens if a program uses addresses

THRASH ING


26 6 2 6 10



## Disadvantage of direct mapping

The direct-mapped cache is easy: indices and offsets can be computed with bit operators or simple arithmetic, because each memory address belongs in exactly one block.

- However, this isn't really flexible. If a program uses addresses 2, 6, 2, 6, 2, ..., then each access will result in a cache miss and a load into cache block 2.
- This cache has four blocks, but direct mapping might not let us use all of them.
- This can result in more misses than we might like.




## A fully-associative cache

- A fully-associative cache permits data to be stored in any cache block, instead of forcing each memory address into one particular block.
  - When data is fetched from memory, it can be placed in any unused block of the cache.
  - This way we'll never have a conflict between two or more memory addresses that map to a single cache block.
- In the previous example, we might put memory address 2 in cache block
   2, and address 6 in block 3. Then subsequent repeated accesses to 2 and
   6 would all be hits instead of misses.
- If all the blocks are already in use, it's usually best to replace the <u>least</u> recently used one, assuming that if it hasn't used it in a while, it won't be needed again anytime soon.


## The price of full associativity

- However, a fully-associative cache is expensive to implement.
  - Because there is no index field in the address anymore, the entire address must be used as the tag, increasing the total cache size.
  - Data could be anywhere in the cache, so we must check the tag of every cache block. That's a lot of comparators!




## Set associativity

- An intermediate possibility is a set-associative cache.
  - The cache is divided into groups of blocks, called sets.
  - Each memory address maps to exactly one set in the cache, but data may be placed in any block within that set.
- If each set has  $2^x$  blocks, the cache is a  $2^x$ -way associative cache.
- Here are several possible organizations of an eight-block cache.



## Locating a set associative block

- We can determine where a memory address belongs in an associative cache in a similar way as before.
- If a cache has  $2^s$  sets and each block has  $2^n$  bytes, the memory address can be partitioned as follows.



 Our arithmetic computations now compute a set index, to select a set within the cache instead of an individual block.


```
Block Offset = Memory Address mod 2<sup>n</sup>
```

Block Address = Memory Address /  $2^n$ 

Set Index = Block Address mod 2<sup>s</sup>

## Example placement in set-associative caches


- Where would data from memory byte address 6195 be placed, assuming the eight-block cache designs below, with 16 bytes per block?
- 6195 in binary is 00...0110000 011 0011.
- Each block has 16 bytes, so the lowest 4 bits are the block offset.
- For the direct mapped cache, the next three bits (011) are the set index. For the 2-way cache, the next two bits (11) are the set index. For the 4-way cache, the next one bit (1) is the set index.
- The data may go in any block, shown in green, within the correct set.




More cache organizations


## **Block replacement**

- Any empty block in the correct set may be used for storing data.
- If there are no empty blocks, the cache controller will attempt to replace the least recently used block, just like before.
- For highly associative caches, it's expensive to keep track of what's really the least recently used block, so some approximations are used.
   We won't get into the details.






2-way associativity



4-way associativity

## LRU example

- Assume a fully-associative cache with two blocks, which of the following memory references miss in the cache.
  - assume distinct addresses go to distinct blocks




## LRU example

- Assume a fully-associative cache with two blocks, which of the following memory references miss in the cache.
  - assume distinct addresses go to distinct blocks


On a miss, we replace the LRU.

On a hit, we just update the LRU.




## Set associative caches are a general idea

- By now you may have noticed the 1-way set associative cache is the same as a direct-mapped cache.
- Similarly, if a cache has  $2^k$  blocks, a  $2^k$ -way set associative cache would be the same as a fully-associative cache.



## 2-way set associative cache implementation



### Summary

- Larger block sizes can take advantage of spatial locality by loading data from not just one address, but also nearby addresses, into the cache.
- Associative caches assign each memory address to a particular set within the cache, but not to any specific block within that set.
  - Set sizes range from 1 (direct-mapped) to  $2^k$  (fully associative).
  - Larger sets and higher associativity lead to fewer cache conflicts and lower miss rates, but they also increase the hardware cost.
  - In practice, 2-way through 16-way set-associative caches strike a good balance between lower miss rates and higher costs.
- Next time, we'll talk more about measuring cache performance, and also discuss the issue of writing data to a cache.