				_			T	T T	.	т -	, ,		
/floating_point_multiplier_vhd_tst/A	00000000				01001010								
/floating_point_multiplier_vhd_tst/B	00000000				00111100								
/floating_point_multiplier_vhd_tst/CLK				<u> </u>						1		<u> </u>	
/floating_point_multiplier_vhd_tst/IS_READY				<u> </u>									
/floating_point_multiplier_vhd_tst/LOAD_DATA	†	· 			-							·	
/floating_point_multiplier_vhd_tst/P	÷	-				+	-		-	+ +			01001110
/floating_point_multiplier_vhd_tst/RST	†	· 		 	-	+	+	+ +	+	+ +		·	
/floating_point_multiplier_vhd_tst/T	+								+	+ +		·	
· - - · -													
		ı										ı	
0	ps	2000	0 ps	4000	00 ps	60000 ps	800	000 ps 1	00000 ps	12000)0 ps	14000)0 ps