PT Nusantara Kimia - SOP-K3-021
Chemical Transfer and Drum Handling

1. Operators handling corrosive chemicals must wear chemical splash goggles, a face shield, nitrile gloves, a chemical-resistant apron and safety boots.
2. An eyewash station and safety shower must be within 10 meters of the transfer point and unobstructed.
3. Drums must sit on a spill containment pallet. A spill kit must be visible at the work area.
4. No food, drink or smoking in the chemical area. No open flames within 15 meters.
5. Work area must be ventilated; stop work if the area temperature exceeds 35 C.
6. Containers must be labelled; unlabelled containers are forbidden.