Communication Systems EE-351

Lectures 11 and 13

Problems:


Consider an SSB signal when the modulating signal is x(t). $\hat{x}(t)$ is the Hilbert transform of x(t). What is the envelope of SSB?

Solution: $\sqrt{x^2(t) + \hat{x}^2(t)}$

A DSB-SC signal is generated using the carrier $\cos(\omega_c t + \theta)$ and modulating signal is x(t). Find the envelope?

Solution: |x(t)|

Single Sideband Modulation (SSB):



(a) For the upper SSB,


$$S(f) = \begin{cases} \frac{A_c}{2} M(f - f_c), & \text{for } f \ge f_c \\ 0, & \text{for } 0 < f \le f_c \end{cases}$$

(b) For the lower SSB,

$$S(f) = \begin{cases} 0, & \text{for } f > f_c \\ \frac{A_c}{2} M(f - f_c), & \text{for } 0 < f \le f_c \end{cases}$$

$$x(t) = m(t)\cos(2\pi F_c t) - \widehat{m}(t)\sin(2\pi F_c t)$$

$$= \left[\frac{1}{2}M(F - F_c) + \frac{1}{2}M(F + F_c)\right] - \left[\frac{-j}{2}\widehat{M}(F - F_c) + \frac{j}{2}\widehat{M}(F + F_c)\right]$$






FIGURE 3.18 (a) Spectrum of a message signal m(t) with energy gap centered around zero frequency. Corresponding spectra of SSB-modulated waves using (b) upper sideband, and (c) lower sideband. In parts (b) and (c), the spectra are only shown for positive frequencies.

Modulators for SSB:

Frequency Discrimination Method:




FIGURE 3.19 Frequency-discrimination scheme for the generation of a SSB modulated wave.

(a) For the upper SSB,

$$S(f) = \begin{cases} \frac{A_c}{2} M(f - f_c), & \text{for } f \ge f_c \\ 0, & \text{for } 0 < f \le f_c \end{cases}$$

(b) For the lower SSB,

$$S(f) = \begin{cases} 0, & \text{for } f > f_c \\ \frac{A_c}{2} M(f - f_c), & \text{for } 0 < f \le f_c \end{cases}$$

Phase Discrimination Method:




FIGURE 3.20 Phase discrimination method for generating a SSB-modulated wave. Note: The plus sign at the summing junction pertains to transmission of the lower sideband and the minus sign pertains to transmission of the upper sideband.

$$s(t) = \frac{A_c}{2}m(t)\cos(2\pi f_c t) \mp \frac{A_c}{2}\hat{m}(t)\sin(2\pi f_c t)$$

Modulators for SSB:

Frequency Discrimination Method:


- Modulator consists of two components: product modulator followed by band-pass filter.
- Product modulator produces DSB-SC wave with two sidebands.
- BPF is design to transmit one of these bands.
- For the design of the band-pass filter to be practically feasible, there must be a certain separation between the two sidebands that is wide enough to accommodate the transition band of the band-pass filter.
- This requirement limits the applicability of SSB modulation to speech signals for which $f_a \approx 100\,Hz$ but rules it out for video signals and computer data whose spectral content extends down to almost zero frequency.
- BPF is the functional block.

Phase Discrimination Method:

- This second SSB modulator consists of two parallel paths, one called the *in-phase* path and the other called the *quadrature* path.
- The role of the quadrature path embodying the wide-band phase shifter is merely to interfere with the in-phase path so as to eliminate power in one of the two sidebands, depending on whether upper SSB or lower SSB is the requirement.
- Wide-band phase-shifter is the functional block

Coherent Detection of SSB:

- In comparison to demodulation of DSB-SC (suppression of the carrier), the demodulation of SSB is further complicated by the additional suppression of the upper or lower sideband.
- The two sidebands share an important property: they are the *images* of each other with respect to the carrier.



- The coherent detector of Fig. 3.12 applies equally well to the demodulation of both DSB-SC and SSB;
- the only difference between these two applications is how the modulated wave is defined.

▶ **Drill Problem 3.13** Starting with Eq. (3.23) for a SSB modulated wave, show that the output produced by the coherent detector of Fig. 3.12 in response to this modulated wave is defined by

$$\nu_o(t) = \frac{A_c A_c'}{4} m(t)$$

Assume that the phase error $\phi = 0$ in Fig. 3.12.

$$s(t) = \frac{A_c}{2}m(t)\cos(2\pi f_c t) \mp \frac{A_c}{2}\widehat{m}(t)\sin 2\pi f_c t$$
$$r(t) = s(t).A_c\cos(2\pi F_c t)$$

$$= \left[\frac{A_c}{2}m(t)\cos(2\pi F_c t) \mp \frac{A_c}{2}\widehat{m}(t)\sin(2\pi F_c t)\right] \times A_c\cos(2\pi F_c t)$$

$$= \frac{A_c^2}{2}m(t)\cos^2(2\pi F_c t) \mp \frac{A_c^2}{2}\widehat{m}(t)\sin(2\pi F_c t)\cos(2\pi F_c t)$$

$$= \frac{A_c^2}{4}m(t) + \frac{A_c^2 m(t)\cos(4\pi F_c t)}{4} \mp \frac{A_c^2 \widehat{m}(t)\sin(4\pi F_c t)}{4}$$

$$=\frac{{A_c}^2m(t)}{4}$$

Repeat the problem by considering phase error:

$$s(t) \times A_c \cos(2\pi F_c t + \varphi)$$

$$= \left[\frac{A_c}{2}m(t)\cos(2\pi F_c t) \mp \frac{A_c}{2}\widehat{m}(t)\sin(2\pi F_c t)\right] \times A_c \cos(2\pi F_c t + \varphi)$$

$$\cos A \cos B = \frac{1}{2}(\cos(A+B) + \cos(A-B))$$

$$\sin A \cos B = \frac{1}{2}(\sin(A+B) + \sin(A-B))$$

$$= \frac{A_c^2}{4}m(t)\left[\cos(4\pi F_c t + \varphi) + \cos\varphi\right] \mp \frac{A_c^2\widehat{m}(t)\left[\sin(4\pi F_c t + \varphi) - \sin\varphi\right]}{4}$$

$$= \frac{A_c^2}{4}m(t)\cos\varphi \pm \frac{A_c^2}{4}\widehat{m}(t)\sin\varphi$$

Frequency Translation:

- The basic operation performed in single sideband modulation is in fact a form of frequency translation, which is why single sideband modulation is sometimes referred to as frequency changing, mixing, or heterodyning.
- Suppose that we have a modulated wave $s_1(t)$ whose spectrum is centered on a carrier frequency f_1 , and the requirement is to translate it upward or downward in frequency, such that the carrier frequency is changed from f_1 to a new value f_2 .
- This requirement is accomplished by using a mixer (a functional block that consists of a product modulator followed by a band-pass filter).
- Conventional method for SSB modulator but with an important difference: the band-pass filter is now straightforward to design.





FIGURE 3.21 Block diagram of mixer.

Modulated signal with $f_c = f_1$






FIGURE 3.22 (a) Spectrum of modulated signal $s_1(t)$ at the mixer input. (b) Spectrum of the corresponding signal s'(t) at the output of the product modulator in the mixer.

Frequency Translation:

 Two different situations can be identified, depending on the carrier frequency to be translated upward or downward.




FIGURE 3.21 Block diagram of mixer.

Modulated signal with $f_c = f_1$


(i) Up conversion. In this form of mixing, the translated carrier frequency, denoted by f_2 , is greater than the incoming carrier frequency f_1 . The required local oscillator frequency f_l is therefore defined by

$$f_2 = f_1 + f_l$$

Solving for f_l , we therefore have

$$f_l = f_2 - f_1$$

In this situation, the unshaded part of the spectrum in Fig. 3.22(b) defines the upconverted signal $s_2(t)$, and the shaded part of this spectrum defines the *image signal* associated with $s_2(t)$, which is removed by the band-pass filter in Fig. 3.21. For obvious reasons, the mixer in this case is referred to as a *frequency-up converter*.






FIGURE 3.22 (a) Spectrum of modulated signal $s_1(t)$ at the mixer input. (b) Spectrum of the corresponding signal s'(t) at the output of the product modulator in the mixer.

Frequency Translation:




FIGURE 3.21 Block diagram of mixer.

Modulated signal with $f_c = f_1$

(ii) Down conversion. In this second form of mixing, the translated carrier frequency f_2 is smaller than the incoming carrier frequency f_1 , as shown by

$$f_2 = f_1 - f_l$$


The required local oscillator frequency is therefore

$$f_l = f_1 - f_2$$

The shaded part of the spectrum defines the **down-converted signal**, and the unshaded part of this spectrum defines the associated image signal. This second mixer is referred to as a **frequency-down converter**.

In order to avoid sideband overlap, what should be the carrier frequency, f_2 ?

$$f_2 > W$$








FIGURE 3.22 (*a*) Spectrum of modulated signal $s_1(t)$ at the mixer input. (*b*) Spectrum of the corresponding signal s'(t) at the output of the product modulator in the mixer.


Vestigial Sideband (VSB) Modulation:

- Single-sideband modulation works satisfactorily for an information-bearing signal (e.g., speech signal) with an energy gap centered around zero frequency.
- For the spectrally efficient transmission of wideband signals, we have to look to a new method of modulation for two reasons:
 - Typically, the spectra of wideband signals (exemplified by television video signals and computer data) contain significant low frequencies, which make it impractical to use SSB modulation.
 - The spectral characteristics of wideband data befit the use of DSB-SC. However, DSB-SC requires a transmission bandwidth equal to twice the message bandwidth, which violates the bandwidth conservation requirement.





Spectrum of message signal



Relative amplitude Picture carrier Sound carrier Sound 0.5 spectrum 6 1.25 5.25 Relative 0.5 5.75 channel 4 MHz 0.75 MHz frequency Video lower Video upper sideband sideband 4.5 MHz

Spectrum of transmitted TV signal using VSB transmission

Electronics Coach

Vestigial Sideband (VSB) Modulation:

- A scheme that lies somewhere between SSB and DSB-SC in its spectral characteristics.
- Vestigial sideband (VSB) modulation distinguishes itself from SSB modulation in two practical respects:
 - Instead of completely removing a sideband, a trace or *vestige* of that sideband is transmitted; hence, the name "vestigial sideband."
 - Instead of transmitting the other sideband in full, almost the whole of this second band is also transmitted.
- Accordingly, the transmission bandwidth of a VSB modulated signal is defined by

$$B_T = f_v + W$$

Where f_{ν} is the vestige bandwidth and W is the message bandwidth.

Typically, f_v is 25 percent of W, which means that the VSB bandwidth lies between the SSB bandwidth, W, and DSB-SC bandwidth, 2W.

$$DSBSC > VSB > SSB$$

 $2f_m > f_m + f_v > f_m$

Generation of VSB Modulation (Sideband Shaping Filter):

 For VSB modulation, the bandpass filter is referred to as a sideband shaping filter.




FIGURE 3.23 VSB modulator using frequency discrimination.

VSB modulated signal is $x(t) = m(t)cos(2\pi f_c t) * h(t)$

Hence, frequency response of $x(t) = m(t)cos(2\pi f_c t) * h(t)$ is

$$X(F) = \left[\frac{1}{2}M(F - F_c) + \frac{1}{2}M(F + F_c)\right].H(F)$$

Generation of VSB Modulation (Sideband Shaping Filter):

- The spectrum shaping is defined by the transfer function of the filter, which is denoted by H(f).
- The only requirement that the sideband shaping performed by H(f) must satisfy is that the transmitted vestige compensates for the spectral portion missing from the other sideband.
- This requirement ensures that coherent detection of the VSB modulated wave recovers a replica of the message signal, except for amplitude scaling.

Huma Ghafoor NUST-SEECS Spring-2023





FIGURE 3.24 (a) Amplitude response of sideband-shaping filter; only the positive-frequency portion is shown, the dashed part of the amplitude response is arbitrary. (b) Unit-step function defined in the frequency domain. (c) Low-pass transfer function $H_{\nu}(f)$.

VSB Demodulator:

At the receiver (demodulator),



$$r(t) = x(t)cos(2\pi f_c t)$$

$$R(F) = \left[\frac{1}{2} X(F - F_c) + \frac{1}{2} X(F + F_c) \right]$$

VSB Demodulator:

$$R(F) = \left[\frac{1}{2}X(F - F_c) + \frac{1}{2}X(F + F_c)\right]$$

$$= \frac{1}{2}\left\{\left[\frac{1}{2}M(F - 2F_c) + \frac{1}{2}M(F)\right] \cdot H(F - F_c)\right\} + \frac{1}{2}\left\{\left[\frac{1}{2}M(F) + \frac{1}{2}M(F + 2F_c)\right] \cdot H(F + F_c)\right\}$$

$$= \frac{1}{4}M(F - 2F_c)H(F - F_c) + \frac{1}{4}M(F)H(F - F_c) + \frac{1}{4}M(F)H(F + F_c) + \frac{1}{4}M(F + 2F_c)H(F + F_c)$$
These two components correspond to $2F_c$

VSB Demodulator:

Therefore, after filter out,

$$R(F) = \frac{1}{4}M(F)\{H(F - F_c) + H(F + F_c)\}$$

$$R(F) = \frac{1}{4}M(F)$$

Set $H(F - F_c) + H(F + F_c) = 1$ (non-ideal VSB filter must satisfied this condition)

This property is satisfied if VSB filter is symmetric.

Complex Envelope:

• The term "baseband" is used to designate the band of frequencies representing the original signal as delivered by a source of information.

Why Complex Envelope?

• The carrier frequency is large compared to the message bandwidth, which makes the processing of a modulated wave on a digital computer a difficult proposition.

Objective of Complex Envelope:

 The objective is to process a modulated wave on a computer, the efficient procedure is to do the processing on the baseband version of the modulated wave rather than directly on the modulated wave itself.

Baseband representation of a modulated wave:

• A generic, linear modulated wave is

$$s(t) = s_I(t)\cos(2\pi f_c t) - s_Q(t)\sin(2\pi f_c t)$$

$$c(t) = \cos(2\pi f_c t)$$

be the carrier wave with frequency f_c , and

$$\hat{c}(t) = \sin(2\pi f_c t)$$

TABLE 3.1 Different Forms of Linear Modulation as Special Cases of Eq. (3.39), assuming unit carrier amplitude

• •		0	•
Type of modulation	In-phase component $s_I(t)$	Quadrature component $s_Q(t)$	Comments
AM	$1 + k_a m(t)$	0	k_a = amplitude sensitivity m(t) = message signal
DSB-SC	m(t)	0	(1)
SSB:			
(a) Upper sideband transmitted	$\frac{1}{2}m(t)$	$\frac{1}{2}\hat{m}(t)$	$\hat{m}(t)$ = Hilbert transform of $m(t)$ (see part (i) of footnote 4) ⁴
(b) Lower sideband transmitted	$\frac{1}{2}m(t)$	$-\frac{1}{2}\hat{m}(t)$	
VSB:			
(a) Vestige of lower sideband transmitted	$\frac{1}{2}m(t)$	$\frac{1}{2}m'(t)$	m'(t) = response of filter with transfer function $H_Q(f)$ due to message signal $m(t)$.
(b) Vestige of upper sideband transmitted	$\frac{1}{2}m(t)$	$-\frac{1}{2}m'(t)$	The $H_Q(f)$ is defined by the formula (see part (ii) of footnote 4) $H_Q(f) = -j[H(f + f_c) - H(f - f_c)]$ where $H(f)$ is the transfer function of the VSB sideband shaping filter.

Baseband representation of a modulated wave:

• The information content of the message signal and the way in which the modulation strategy is implemented are fully described by the **in-phase component** in both **AM and DSB-SC** or in the combination of the **in-phase component and the quadrature component** in both **SSB** and **VSB**.

• Moreover, the orthogonality of $s_I(t)$ and $s_Q(t)$ with respect to each other prompts us to introduce a new signal called the **complex envelope** of the modulated wave which is formally defined by:

$$\widetilde{s}(t) = s_I(t) + js_Q(t)$$

Purpose of Complex Envelope:

 The use of complex envelope is intended merely to simplify signal processing operations on band-pass signals, which are exemplified by modulated waves based on a sinusoidal carrier.

$$c(t) = \cos(2\pi f_c t)$$

be the carrier wave with frequency f_c , and

$$\hat{c}(t) = \sin(2\pi f_c t)$$

$$\widetilde{c}(t) = c(t) + j\widehat{c}(t)$$

$$= \cos(2\pi f_c t) + j\sin(2\pi f_c t)$$

$$= \exp(j2\pi f_c t)$$

• Accordingly, the modulated wave s(t) is itself defined by


$$s(t) = \operatorname{Re}[\widetilde{s}(t)\widetilde{c}(t)]$$
$$= \operatorname{Re}[\widetilde{s}(t) \exp(j2\pi f_c t)]$$

Advantage of Complex Envelope:

Now we can see the practical advantage of the complex envelope $\tilde{s}(t)$ over the real-valued modulated wave s(t):

- 1. The highest frequency component of s(t) may be as large as $f_c + W$, where f_c is the carrier frequency and W is the message bandwidth.
- 2. On the other hand, the highest frequency component of $\tilde{s}(t)$ is considerably smaller, being limited by the message bandwidth W.

Analyzer and Synthesizer of modulated wave:



Complex Envelope:

Spectrum of x(t) $j \times j = -1$ $-j \times j = 1$

Consider a passband signal x(t),

$$x(t) \longleftrightarrow X(F)$$

Spectrum of $j\hat{x}(t)$

Consider another signal $x(t) + j\hat{x}(t)$ is a pre-envelope (complex signal)

 $\hat{x}(t)$ is Hilbert transform of x(t)

$$X(F) = j\hat{X}(F)$$

$$X(F) = j(-jsgn(F)X(F))$$

Spectrum of $x(t) + j\hat{x}(t)$

Spectrum of $x(t) + j\hat{x}(t) = \text{spectrum of } x(t) + \text{spectrum of } j\hat{x}(t)$

Hence, complex baseband equivalent of passband signal x(t) or complex envelope of x(t) is $\tilde{x}(t)$

$$\tilde{x}(t) = (x(t) + j\hat{x}(t))e^{-j2\pi F_c t}$$

 $e^{-j2\pi F_c t}$ shifts the spectrum to the baseband i.e., around F=0.

$$\operatorname{Re}\{\tilde{x}(t)e^{j2\pi F_{c}t}\} = \operatorname{Re}\{(x(t) + j\hat{x}(t))e^{-j2\pi F_{c}t}e^{j2\pi F_{c}t}\} = \operatorname{Re}\{x(t) + j\hat{x}(t)\} = x(t)$$

Complex envelope is just the frequency shifted version of pre-envelope.

Pre-Envelope (+ve frequencies):

$$X(F) = j(-jsgn(F)X(F))$$

$$X(F) = -(-1) \operatorname{sgn}(F) X(F)$$

Pre-envelope is

$$x(t) + j\hat{x}(t)$$

$$X(F) + \operatorname{sgn}(F) X(F)$$

$$((1 + \operatorname{sgn}(F))X(F)$$

$$sgn(F) = \begin{cases} 1, & F > 0 \\ 0, & F = 0 \\ -1, & F < 0 \end{cases}$$

$$x(preenvelope)(F) = \begin{cases} 2X(F), & F > 0 \\ X(F), & F = 0 \\ 0, & F < 0 \end{cases}$$

Pre-Envelope (-ve frequencies):

$$x(t) - j\hat{x}(t)$$

$$X(F) - \operatorname{sgn}(F) X(F)$$

$$((1 - \operatorname{sgn}(F))X(F)$$

$$sgn(F) = \begin{cases} 1, & F > 0 \\ 0, & F = 0 \\ -1, & F < 0 \end{cases}$$

$$x(preenvelope)(F) = \begin{cases} 0, & F > 0 \\ X(F), & F = 0 \\ 2X(F), & F < 0 \end{cases}$$

Complex Envelope of QCM:

$$s(t) = s_I(t)c(t) - s_Q(t)\hat{c}(t)$$

$$x(t) = x_I(t)\cos(2\pi F_c t) - x_Q(t)\sin(2\pi F_c t)$$

$$x(t) = x_I(t) \left[\frac{e^{j2\pi F_c t} + e^{-j2\pi F_c t}}{2}\right] - x_Q(t) \left[\frac{e^{j2\pi F_c t} - e^{-j2\pi F_c t}}{2j}\right]$$
 Positive freq. band
$$= \frac{1}{2} \left[x_I(t) + jx_Q(t)\right] e^{j2\pi F_c t} + \frac{1}{2} \left[x_I(t) - jx_Q(t)\right] e^{-j2\pi F_c t}$$
 Negative freq. band

Spectrum of complex pre-envelope, $x_p(t)$ = twice the spectrum corresponding to the positive frequency band

$$x_p(t) = x_I(t) + jx_Q(t)e^{j2\pi F_C t}$$

Complex envelope, $\tilde{x}(t) = x_p(t)e^{-j2\pi F_c t}$

 $\tilde{x}(t) = x_I(t) + jx_Q$ i.e., complex envelope or complex baseband equivalent of QCM signal

Examples:

1. $A_c cos \omega_c t$

$$= A_c \left[\frac{e^{j\omega_c t} + e^{-j\omega_c t}}{2} \right] = A_c e^{j\omega_c t} \text{ (pre-envelope)}$$

Complex envelope?

$$= A_c e^{j\omega_c t} e^{-j\omega_c t}$$
$$= A_c$$

$$A_c[1 + m(t)]cos\omega_c t$$

 $A_c[1 + m(t)]e^{j\omega_c t}$ (pre-envelope)

$$A_c[1 + m(t)]$$
 (complex envelope)

Example:

$$x(t)$$

= $cos(2\pi 103t).u(t)$ centered at $100Hz$

$$x_p(t) = u(t)e^{j2\pi 103t}$$
$$x_c(t) = u(t)e^{j6\pi t}$$