

Ln 4, Col 4

Flags : S Z AC P CY

[illegible]

```
MVI A 25h
ADD A
STA 2000h
HLT
```

Starting Address : 8000

Comments :

User Data Grid

[illegible]

Hex Code Grid

[illegible]

1.Data Transfer Group :

MOV	MVI	LDA	STA
LHLD	SHLD	LXI	XCHG
LDAX	STAX	IN	OUT

2. Arithmetic Group :

ADD	ADI	ADC	ACI	DAA
SUB	SUI	SBB	SBI	
INR	DCR	INX	DCX	DAD

3. Logical Group :

ANA	ANI	XRA	XRI	CMA
ORA	ORI	CMP	CPI	CMC
RLC	RRC	RAL	RAR	STC

4.Branch and Machine Control Group

JMP	J_	CALL	C_
RET	R_	EI	DI
PCHL	RST	RIM	SIM
XTHL	SPHL	NOP	HLT

☒ Auto Insert

Instruction Information :

MoVe Immediate 8-bit



General Regs.:	A 12	B 00	C 00	D 00	E 00	H L 00 00	M 00	SP 0000	PC 8000	X
----------------	---------	---------	---------	---------	---------	--------------	---------	------------	------------	---

General Regs.: 12 00 00 00 00 00 00 0000 8000 X

Starting Address : 8000

Hex Code Grid

[illegible]

MOV	MVI	LDA	STA
LHLD	SHLD	LXI	XCHG
LDAX	STAX	IN	OUT

ADD	ADI	ADC	ACI	DAA
SUB	SUI	SBB	SBI	DAD
INR	DCR	INX	DCX	

ANA	ANI	XRA	XRI	CMA
ORA	ORI	CMP	CPI	CMC
RLC	RRC	RAL	RAR	STC

JMP	J_	CALL	C_	
RET	R_	EI	DI	PUSH
PCHL	RST	RIM	SIM	POP
XTHL	SPHL	NOP	HLT	

Instruction Information :
MoVe Immediate 8-bit

[illegible]

General Regs.: 4A 00 00 00 00 00 00 00 0000 8000 X

Starting Address : 8000

Hex Code Grid

[illegible]

MOV	MVI	LDA	STA
LHLD	SHLD	LXI	XCHG
LDAX	STAX	IN	OUT

ADD	ADI	ADC	ACI	DAA
SUB	SUI	SBB	SBI	DAD
INR	DCR	INX	DCX	

ANA	ANI	XRA	XRI	CMA
ORA	ORI	CMP	CPI	CMO
RLC	RRC	RAL	RAR	STC

JMP	J_	CALL	C_
RET	R_	EI	DI
PCHL	RST	RIM	SIM
XTHL	SPHL	NOP	HLL

Instruction Information :

MoVe Immediate 8-bit

[illegible]

General Regs.: 18 3C 00 00 00 00 00 0000 8000 X

Starting Address : 8000

Hex Code Grid

[illegible]

MOV	MVI	LDA	STA
LHLD	SHLD	LXI	XCHG
LDAX	STAX	IN	OUT

ADD	ADI	ADC	ACI	DAA
SUB	SUI	SBB	SBI	
INR	DCR	INX	DCX	DAD

ANA	ANI	XRA	XRI	CMA
ORA	ORI	CMP	CPI	CMC
RLC	RRC	RAL	RAR	STC

JMP	J_	CALL	C_
RET	R_	EI	DI
PCHL	RST	RIM	SIM
XTHL	SPHL	NOP	HLT

Instruction Information :
MOVe – copy from source to destination



General Regs.:	A C4	B 00	C 00	D 00	E 00	H 00	L 00	M 00	SP 0000	PC 8000	X
----------------	---------	---------	---------	---------	---------	---------	---------	---------	------------	------------	---

General Regs.: **C4** **00** **00** **00** **00** **00** **00** **0000** **8000** **X**

Starting Address : 8000

Hex Code Grid

[illegible]

MOV	MVI	LDA	STA
LHLD	SHLD	LXI	XCHG
LDAX	STAX	IN	OUT

ADD	ADI	ADC	ACI	DAA
SUB	SUI	SBB	SBI	
INR	DCR	INX	DCX	DAD

ANA	ANI	XRA	XRI	CMA
ORA	ORI	CMP	CPI	CMC
RLC	RRC	RAL	RAR	STC

JMP	J_	CALL	C_
RET	R_	EI	DI
PCHL	RST	RIM	SIM
XTHL	SPHL	NOP	HLT

Instruction Information :

Ln 4, Col 4

Flags : S Z AC P **CY**

General Regs.:	A C0	B 00	C 00	D 00	E 00	H 00	L 00	M 00	SP 0000	PC 8000	X
----------------	---------	---------	---------	---------	---------	---------	---------	---------	------------	------------	---

```
MVI A 81h
RRC
STA 2000h
HLT
```

Starting Address : 8000

Comments :

User Data Grid

[illegible]

Hex Code Grid

[illegible]

1.Data Transfer Group :

MOV	MVI	LDA	STA
LHLD	SHLD	LXI	XCHG
LDAX	STAX	IN	OUT

2. Arithmetic Group :

ADD	ADI	ADC	ACI	DAA
SUB	SUI	SBB	SBI	
INR	DCR	INX	DCX	DAD

3. Logical Group :

ANA	ANI	XRA	XRI	CMA
ORA	ORI	CMP	CPI	CMC
RLC	RRC	RAL	RAR	STC

4.Branch and Machine Control Group

JMP	J_	CALL	C_
RET	R_	EI	DI
PCHL	RST	RIM	SIM
XTHL	SPHL	NOP	HLT

☒ Auto Insert

Instruction Information :

MoVe Immediate 8-bit

[illegible]

General Regs.: 03 00 00 00 00 00 00 0000 8000 X

Starting Address : 8000

Hex Code Grid

[illegible]

MOV	MVI	LDA	STA
LHLD	SHLD	LXI	XCHG
LDAX	STAX	IN	OUT

ADD	ADI	ADC	ACI	DAA DAD
SUB	SUI	SBB	SBI	
INR	DCR	INX	DCX	

ANA	ANI	XRA	XRI	CMA
ORA	ORI	CMP	CPI	CMO
RLC	RRC	RAL	RAR	STC

JMP	J_	CALL	C_
RET	R_	EI	DI
PCHL	RST	RIM	SIM
XTHL	SPHL	NOP	HLL

Instruction Information :

MoVe Immediate 8-bit



General Regs.:	A 7E	B 3C	C 00	D 00	E 00	H 00	L 00	M 00	SP 0000	PC 8000	X
----------------	---------	---------	---------	---------	---------	---------	---------	---------	------------	------------	---

General Regs.: 7E 3C 00 00 00 00 00 0000 8000 X

Starting Address : 8000

Hex Code Grid

[illegible]

MOV	MVI	LDA	STA
LHLD	SHLD	LXI	XCHG
LDAX	STAX	IN	OUT


ADD	ADI	ADC	ACI	DAA
SUB	SUI	SBB	SBI	
INR	DCR	INX	DCX	DAD

ANA	ANI	XRA	XRI	CMA
ORA	ORI	CMP	CPI	CMC
RLC	RRC	RAL	RAR	STC

JMP	J_	CALL	C_
RET	R_	EI	DI
PCHL	RST	RIM	SIM
XTHL	SPHL	NOP	HLT

Instruction Information :

Load H and L register direct



Microprocessor 8085 Simulator Software Kit 1.0

Ln 5, Col 1

TStates : 40 MCycles : 12 Time of Execution : 40 µs

Flags : S Z AC P CY

General Regs.: A 12 B 00 C 00 D 00 E 00 H 00 L 00 M 00 SP 0000 PC 8000 X

```
MVI A 25h
ORA A
RAR
ANI 7Fh
STA 2000h
HLT
```

Starting Address : 8000

Comments :

User Data Grid

Address	Data
2000	12

Hex Code Grid

Address	Data
8000	3E
8001	25
8002	B7
8003	1F
8004	E6
8005	7F
8006	32
8007	00
8008	20
8009	76

1.Data Transfer Group :

MOV	MVI	LDA	STA
LHLD	SHLD	LXI	XCHG
LDAX	STAX	IN	OUT

2.Arithmetic Group :

ADD	ADI	ADC	ACI	DAA
SUB	SUI	SBB	SBI	DAD
INR	DCR	INX	DCX	

3.Logical Group :

ANA	ANI	XRA	XRI	CMA
ORA	ORI	CMP	CPI	CMC
RLC	RRC	RAL	RAR	STC

4.Branch and Machine Control Group

JMP	J_	CALL	C_
RET	R_	EI	DI
PCHL	RST	RIM	SIM
XTHL	SPHL	NOP	HLT

☒ Auto Insert

Instruction Information :

Load Accumulator direct

