# Lab 1 Graphics, LCD, ADC, Timer and Interpreter

Goals • Introduction to Tiva TM4C123 LaunchPad,

Interrupting serial port,Graphics LCD driver,

• Timer-triggered ADC driver,

• Periodic interrupts using the timer,

• Develop a command line interpreter.

## Starter files Located at http://www.ece.utexas.edu/~valvano/arm/

The following software is included in ValvanoWareTM4C123.zip

• GPIO\_4C123 • ST7735\_4C123

• PeriodicSysTickInts 4C123

• ADCTOATrigger 4C123

• ADCSWTriggerTwoChan 4C123

• UARTInts\_4C123 (includes FIFO code)

• PeriodicTimer2AInts\_4C123

# Data sheets (look for TM4C123 reference material on class website or EE319K site)

- http://www.ece.utexas.edu/~gerstl/ee445m\_s19/resources.html
- http://www.ece.utexas.edu/~valvano/Volume1/

#### **Background**

The overall goal of the class will be to develop a real-time operating system. In this lab, however, you will familiarize yourself with the LaunchPad board,  $\mu$ Vision development system and the TM4C123 ARM Cortex-M4 microcontroller. Most of the fundamental concepts in this lab should be review. Therefore, you will use this lab to explore the details of the development environment.

Look ahead to the next couple of labs. How you design this lab will simplify how you use these programs in subsequent labs. Do the lab in order. Do the preparation before coming to the first day of lab, do each step of the procedure before checking out. Read the entire lab assignment before starting the procedure, so you can gather the right data while you are doing the lab instead of at the end. Write the report the same day you finish checkout. Everything will be fresh in your mind and your lab will still be working so you can take meaningful data.

An important design step occurs in writing the header file for a driver. It is in the header file that you define the interfaces between software components. As part of the preparation in addition to the header files you will include rough pseudo code with descriptions of their approach to what you plan to write in the C files. As part of the preparation, you should have a plan of how you will complete the lab. The TA checks the preparation at the start of lab. This way the TA has an opportunity to set you on the right track by looking at what you have thought of so far.

Simply put, develop a TM4C123 project with 1) an interpreter running via the UART link to the PC, 2) an LCD that has two logically separate displays implemented on one physical display, 3) a periodic interrupt that maintains time, and 4) an ADC device driver that collects data either in a continuous fashion or in blocks of fixed size using timer-triggered sampling. There are a lot of specifications outlined below, however, you are free to modify specifications as long as the above four components are implemented and understood. Part of the preparation is for you to clarify exactly what you will implement.

I recommend you avoid using SysTick, Timer0, Timer1 and Timer3 in this lab because subsequent labs will use these devices. I recommend Timer2 for the ADC, and Timer4, Timer5 or any of the wide timers for this lab.

### **Prepreparation (do this individually)**

0) Go to the ARM site to download the compiler to your laptop <a href="https://www.keil.com/demo/eval/armv4.htm">https://www.keil.com/demo/eval/armv4.htm</a>. Do not get the newest compiler (Version 5.x) because it does not support the TI boards. Any version 4.7 to 4.74 will be OK. Install Keil uVision4 using these instructions <a href="http://www.ece.utexas.edu/~valvano/Volume1/KeilInstall.htm">http://www.ece.utexas.edu/~valvano/Volume1/KeilInstall.htm</a>. Finally, download and install the Launchpad drivers from the TI website: <a href="http://www.ti.com/tool/stellaris\_icdi\_drivers">http://www.ti.com/tool/stellaris\_icdi\_drivers</a>.

- 1) Please review the style guideline presented in style.pdf and c\_and\_h\_files.pdf.
- 2) Search through the UARTInts\_4C123 project to answer these questions about the UART port
- a) This example used UART0. What lines of C code define which port will be used for the UART channel?
- b) What lines of C code define the baud rate, parity, data bits and stop bits for the UART?
- c) Which port pins do we use for the UART? Which pin transmits and which pin receives?
- d) Look in the uart.c driver to find what low-level C code inputs one byte from the UART port.
- e) Similarly, find the low-level C code that outputs one byte to the UART port.
- f) Find in the project the interrupt vector table. In particular, how does the system set the ISR vector?
- g) This code **UARTO\_ICR\_R** = **UART\_ICR\_TXIC**; acknowledges a serial transmit interrupt. Explain how the acknowledgement occurs in general for all devices and in specific for this device.
- h) Look in the data sheet of the TM4C123 and determine the extent of hardware buffering of the UART channel. For example, simple microcontrollers like the 9S12 only have a transmit data register and a transmit shift register. So, the software can output two bytes before having to wait. The serial ports on the PC have 16 bytes of buffering. So, the software can output 16 bytes before having to wait. The 9S12 only has a receive data register and a receive shift register. This means the software must read the received data within 10 bit times after the receive flag is set in order to prevent overrun. Is the TM4C123 like the 9S12 (allowing just two bytes), or is it like the PC (having a larger hardware FIFO buffer)?
- 3) Search through the ST7735 4C123 project to answer these questions about the LCD interface
- a) What synchronization method do we use for the low-level command writedata?
- b) Explain the parameters of the function ST7735\_DrawChar. I.e., how do you use this function?
- c) Which port pins do we use for the LCD? Find the connection diagram needed to interface the LCD.
- d) Specify which other device shares pins with the LCD.
- 4) Search through the **PeriodicSysTickInts\_4C123**, **ST7735\_4C123**, and **GPIO\_4C123** projects to answer these questions about the SysTick interrupts.
- a) What C code defines the period of the SysTick interrupt?
  - b) Look at these projects GPIO\_4C123 PeriodicSysTickInts\_4C123, and ST7735\_4C123. How does the software establish the bus frequency? Find the code that sets the SYSCTL\_RCC and SYSCTL\_RCC2 registers. Look these two registers up in the data sheet. Look at these three projects to explain how the system clock is established. We will be running at 80 MHz for most labs in the class.
  - c) Look up in the data sheet what condition causes this SysTick interrupt and how we acknowledge this interrupt? In particular, what sets the COUNT flag in the NVIC\_ST\_CTRL\_R and what clears it?
- 5) Look up the explicit sequence of events that occur as an interrupt is processed. Read section 2.5 in the TM4C123 data sheet (<a href="http://www.ti.com/lit/ds/symlink/tm4c123gh6pm.pdf">http://www.ti.com/lit/ds/symlink/tm4c123gh6pm.pdf</a>). Look at the assembly code generated for an interrupt service routine.
- a) What is the first assembly instruction in the ISR? What is the last instruction?
- b) How does the system save the prior context as it switches threads when an interrupt is triggered?
- c) How does the system restore context as it switches back after executing the ISR?

# Preparation (do this before your lab period)

1) Design an extended version of the device driver for the LCD so that there are two logically separate displays, one display using the top half and one display for the bottom half. There should be at least 4 lines per display. The new command will have a prototype of something like

void ST7735\_Message (int device, int line, char \*string, int32\_t value);

where **device** specifies top or bottom, **line** specifies the line number (0 to 3), **string** is a pointer null terminated ASCII string, and **value** is a number to display. You may add other functions as you wish. In this lab, you may assume all public functions are called from the interpreter running as the main program; hence they need not handle pre-emption and reentrancy. However, in the next lab you will add semaphores so your LCD driver can be used by separate threads in a multi-thread environment. In labs 2 and beyond there will be multiple independent main programs, each performing output to its own LCD. For the preparation, add prototypes for your public functions to

the ST7735.h header file. All your public functions must begin with an ST7735. Your implementations will be written and debugged in the file ST7735.c as part of the procedure.

2) Design a device driver for the ADC using timer-triggered sampling. Sampling rates should vary from 100 to 10000 Hz, and data will be collected on any one of the ADC inputs ADC0 to ADC11. You are expected to use the existing driver functions. You are free to use whatever synchronization mode you wish. Feel free to use any existing code, as long as you completely understand how it works. In lab 2 you perform real-time sampling by triggering the conversion from a timer and interrupting on ADC completion. In this way, there will be no sampling jitter. For the preparation, write an ADC.h header file separating the public functions from the private functions. All public functions must begin with an ADC. The implementation file ADC.c for this driver will be written and debugged as part of the actual procedure. One possibility for the driver is (the first two are sufficient for Lab 1)

The function **ADC\_Collect** starts the conversion and the function **ADC\_Status** returns 0 when it is done. Read the errata about timer-triggered ADC sampling. In order to not conflict with the ultrasonic sensors in Labs 6 and 7, we suggest you use Timer2 for ADC triggering.

# Procedure (do this during your lab period)

1) Develop a main program that implements an interpreter that accepts commands over the serial port using interrupting I/O. Both input and output channels must interrupt. Using the hardware FIFOs is optional, but you will need two software FIFOs so that the operating system can block and unblock threads performing serial I/O. The serial channel is implemented as part of the USB link. You simply access the UART ports on the TM4C123 and run a terminal program like HyperTerminal to interact with your system through the command interpreter. Implement commands that assist in debugging the LCD, ADC and timer drivers for this lab. We will add commands as the semester progresses so make this interpreter flexible. Provide for numeric input, numeric output and ease of use. There are two potential approaches, and you should choose the one you understand the best, because you will need to modify it in subsequent labs. First, you can start with the UARTInts project, which has a receive FIFO and a transmit FIFO. The second approach is to use the stdio library and remap the serial stream to the UART. See the retarget.c file in the Keil\ARM\Boards\Keil\MCBSTM32\Blinky project included in the Keil installation. In particular, you need to create a fputc function like this

```
int fputc(int ch, FILE *f) {
   UARTO_OutChar(ch);
   return (1);
}
int fgetc (FILE *f) {
   return (UARTO_InChar());
}
int ferror(FILE *f) {
   /* Your implementation of ferror */
   return EOF;
}
```

- 2) Implement and test the LCD driver.
- 3) Implement and test the ADC driver. You may restrict your testing to one channel for the ADC, but in subsequent labs multiple channels will be used at a time. In particular, your robot will employ four distance sensors that utilize the ADC. Please limit the analog inputs to the ADC to 0 to 3.3V.
- 4) Design, implement and test a system time driver using 32-bit periodic timer interrupts. Feel free to use any of the timers except the one you plan to use for hardware-triggered ADC sampling (ADC\_Collect). The overall operation will be to execute a software task at a periodic rate. You will pass a function pointer into this driver during initialization. E.g.,

where **task** is a pointer to the function to execute every **period** milliseconds, and **priority** is the value to be specified in the NVIC for this thread. You are free to specify the units of **period** however you wish. A 32-bit global counter will also be incremented at this rate. In order to simplify transition into Lab2, I suggest you name this implementation file **Os.c**, with a header file **Os.h**. One public function will reset the 32-bit counter to 0.

```
void OS_ClearPeriodicTime(void);
```

A second public function will return the current 32-bit global counter. The units of this system time are the period of interrupt passed in by the user when initializing with **OS AddPeriodicThread**.

```
uint32_t OS_ReadPeriodicTime(void);
```

Looking at disassembled code for the ISR count the number of instructions required to run once instance of the timer ISR. For this measurement, assume the user task is a do-nothing function like this

```
void dummy(void) { };
```

You will not be able to estimate the execution time from the assembly code because so many operations on the ARM architecture occur in parallel. Using debugging instruments and a scope or logic analyzer measure the actual time required to run the timer ISR. In the next lab, you will also need a system time function with a resolution on the scale of usec. See the Lab2 starter file OS.h, and look particularly at the functions OS Time.

#### **Checkout (show this to the TA)**

You should be able to demonstrate to the TA the technique you used to measure the overhead of running one of the periodic timer interrupt service routines. The successful completion of Lab 2 will depend on your knowledge of how interrupts are processed and how the serial port driver uses its two FIFO queues. Be prepared for questions addressing interrupts and the FIFO queue. Demonstrate each of the interpreter commands.

### Deliverables (exact components of the lab report and lab submission)

- A) Objectives (1/2 page maximum)
- B) Hardware Design (none in this lab)
- C) Software Design (software documentation in the report and checkin of all files into the submission repository)
  - 1) Low level LCD driver (ST7735\_.c and ST7735\_.h files)
  - 2) Low level ADC driver (ADC.c and ADC.h files)
  - 3) Low level timer driver (OS.c and OS.h files)
  - 4) High level main program (the interpreter)
- D) Measurement Data
  - 1) Estimated time to run the periodic timer interrupt
  - 2) Measured time to run the periodic timer interrupt
- E) Analysis and Discussion (1 page maximum) This section will consist of explicit answers to these questions
  - 1) What are the range, resolution, and precision of the ADC?
  - 2) List the ways you can start the ADC conversion. Explain why you choose the way you did.
  - 3) You can measure the time to run the periodic interrupt directly by setting a bit high at the start of the ISR and clearing that bit at the end of the ISR. You could also calculate it indirectly by measuring the time

- lost when running a simple main program that toggles an output pin. How did you measure it? Compare and contrast your method to these two methods.
- 4) Divide the time to execute once instance of the ISR by the total instructions in the ISR it to get the average time to execute an instruction. Compare this to the 12.5 ns system clock period (80 MHz).
- 5) What are the range, resolution, and precision of the SysTick timer? I.e., answer this question relative to the NVIC\_ST\_CURRENT\_R register in the Cortex M4 core peripherals.

#### Hints

- 1) It is appropriate to copy-paste software from the example files. You must, however, clearly document which code is copied, which code is modified, and which code is original.
- 2) Even though you are allowed to copy-paste software, there should be no magic in this class. In other words, you are responsible for understanding all the details of how your system runs.
- 3) Read ahead into Labs 2 and 3 to see how these drivers will be used. In particular, look at the user program that your Lab 2 RTOS will be running.
- 4) I suggest you modify the starter project **SensorTestProject UARTINTS** or **ST7735** into your Lab 1 solution.
- 5) You can find this FIFO in the fifo.h file of the UARTINES project

```
#define AddFifo(NAME,SIZE,TYPE, SUCCESS,FAIL) \
unsigned long volatile PutI ## NAME;
unsigned long volatile GetI ## NAME;
TYPE static Fifo ## NAME [SIZE];
void NAME ## Fifo Init(void){
  PutI ## NAME= GetI ## NAME = 0;
int NAME ## Fifo_Put (TYPE data){
  if(( PutI ## NAME - GetI ## NAME ) & ~(SIZE-1)){ \
   return(FAIL);
 Fifo ## NAME[ PutI ## NAME &(SIZE-1)] = data; \
 PutI ## NAME ## ++;
  return(SUCCESS);
int NAME ## Fifo_Get (TYPE *datapt){ \
  if( PutI ## NAME == GetI ## NAME ){ \
   return(FAIL);
                       ١
  *datapt = Fifo ## NAME[ GetI ## NAME &(SIZE-1)]; \
  GetI ## NAME ## ++;
  return(SUCCESS);
}
```

- 6) The TM4C123 has 8 UARTs. UART0 (PA1, PA0) is connected to the PC through the USB cable
- 7) If your board has not arrived yet, ask your TA on how to configure Keil for simulation. Lab 1 can be performed in simulation, if you restrict your code to UART0 busy-wait, ADC0 software triggered busy-wait, and 32 bit periodic interrupts on Timer0, Timer1, Timer2 and Timer3.
- 8) If you have a LaunchPad, but no ST7735R LCD, you can perform Labs 1,2,3,4,5 using any LCD (in particular we have some Nokia5110 LCDs to lend). You will find software drivers at <a href="http://www.ece.utexas.edu/~valvano/arm/Nokia5110\_4C123.zip">http://www.ece.utexas.edu/~valvano/arm/Nokia5110\_4C123.zip</a>