
Pogo adapter: touch board H1 -> FFC

One spring pin per used H1 pad (value = pad).
Odd pads = H1 left column, even = right column
(seen from the board's back).



H1 pads without a pin: 2 VBAT, 8 3V3, 9 RST, 11 IO1, 13 IO2, 14/16 USB D+/D−.
Same conductor order as the hub's J4 (FFC_PINS); FFC_MIRROR flips it if the cable type demands.

Passive: pins + FFC connector only. Generated by gen_schematics.py.
15 spring pins on the touch board's H1 pads -> 16-pin FFC to the hub.
aikos-home / RoomKey

Sheet: /
File: roomkey-pogo.kicad_sch

Title: RoomKey pogo adapter (moves with the key)

Size: A4	Date: 2026-10-08	**Rev: A (draft)**
KiCad E.D.A. 10.0.7		Id: 1/1