

102\*70mm  
70g 双胶纸

408 mm

## OPENFREE User Manual


280 mm

### Safety Precautions

1. Power Regulation: Turn off the device in areas where wireless devices are prohibited.
2. Maintenance Distance: Keep at least 15cm away from implanted medical devices (e.g., pacemakers).
3. Volume Control: Set an appropriate volume to avoid hearing damage or pain.
4. Temperature Range: Use the device and accessories between 5°C and 35°C. Extreme temperatures may cause malfunction.
5. Storage: Store in a well-ventilated, cool place away from direct sunlight (e.g., not on car dashboards or windows).
6. Keep Away from Children: This device is not a toy. Use under adult supervision and store out of children's reach to avoid damage or choking hazards.
7. Avoid Distractions: Do not use while driving, operating machinery, or performing tasks requiring full attention.
8. Avoid Thunderstorms: Do not use during thunderstorms to prevent malfunction or electric shock risks.
9. Avoid Heat and Impact: Keep away from heat sources or open flames; avoid strong impacts or vibrations.
10. Cleaning: Use a dry, soft cloth for cleaning. Do not use harsh chemicals or heating tools (e.g., hair dryers) to clean.
11. Unauthorized Repairs: Do not disassemble or modify the device.
12. Use Approved Chargers: Only use approved or compatible chargers to prevent faults, fire, or explosion risks.

### Bluetooth ペアリング

1. 充電ケースを初めて開け、イヤホンを取り出すと自動的にペアリングモードに入ります。
2. イヤホンとペアリングするデバイスの Bluetooth スイッチをオンにし、[ROSE OpenFree] というイヤホン名を検索してペアリング接続してください。



### Pairing

1. Open the charging case for the first time and remove the earbuds to automatically enter pairing mode.
2. Turn on the Bluetooth on the device you want to pair with, and search for the earbuds named [ROSE OpenFree] to connect.

### Resetting

1. Place the earbuds in the charging case with the case lid open. Press and hold the reset button on the charging case for 5 seconds until the indicator light on the case pulses three times, indicating a successful reset.
2. After the reset, close and reopen the charging case to automatically enter pairing mode.

### Warranty

- (In case of discrepancies, national laws and regulations take precedence)
1. We offer a 1-year (i.e. 365 days) warranty coverage for our products (excluding carry cases, ear tips and other accessories). Warranty period starts from the date of purchase.
  2. Our warranty covers any damages that affect the product's functionality. It does not cover any man-made damage due to human error, negligence and accidents.
  3. Once we have confirmed that your item is defective due to manufacturing issues, we will arrange for a replacement, partial refund or a full refund upon return (if applicable).
  4. Before proceeding in our warranty policy, please provide the order number and state the issue clearly.

#### \* The warranty does not cover the following situations:

1. Expired Warranty: The warranty period has ended or the product's validity cannot be verified.
2. No Proof of Purchase: Absence of a valid purchase receipt (order screenshot or invoice).
3. Improper Use: Damage caused by not following the user manual's instructions for use, maintenance, or care.
4. Accidents: Damage due to accident.
5. Unauthorized Repair: Damage resulting from unauthorized disassembly or modifications.
6. External Factors: Damage caused by unavoidable events (e.g., fire, earthquake, lightning).
7. Normal Wear and Tear: Scratches and other damage due to natural wear.

### Charging

1. Place the earbuds in the charging case and close the lid to charge.
2. Use a USB-C cable to charge the charging case.



\* Battery status: ○ White light >70% ● Green light 30%-70% ● Orange light <30% ● Orange light pulsing <10%.

\* Charging: White light pulsing. Charging completed: White light off.

### Touch Control (Customizable in the app)

Action	Left Earbud (L)	Right Earbud (R)
Previous Track	***	/
Next Track	/	***
Play / Pause	**	**
Answer Call	*	*
End Call	*	*
Reject Call	**	**
Volume Down	*	/
Volume Up	/	*
Voice Assistant	---	---
Game Mode	*****	*****

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

### Statement

We provide customer service only for products purchased directly from Rose Technics or Rose Technics authorized distributors. If you have purchased from a different seller, please contact them for any exchange or refund request.

Thank you for purchasing authentic Rose Technics products. For any assistance, please contact us freely.

### タッチ機能 (カスタムタッチはアプリで設定可能)

機能	左イヤホン (L)	右イヤホン (R)
前の曲	***	/
次の曲	/	***
再生/一時停止	**	**
通話を受けける	*	*
通話を終了する	*	*
拒否	**	**
音量を下げる	*	/
音量を上げる	/	*
音声アシスタント	---	---
ゲームモード	*****	*****



## OPENFREE 使用说明书

280 mm

### 安全信息

在使用和操作设备前, 请阅读并遵守下面的注意事项, 避免出现危险或非法的情况。

### 提示

1. 在禁止使用无线设备的场所, 请遵守该场所的规定, 并关闭设备。
2. 在使用本设备时, 请与植入式医疗设备 (如起搏器等) 保持至少15厘米的距离。
3. 当您使用设备收听音乐或通话时, 建议使用音乐或通话所需的最小音量, 以免损伤听力; 长时间接触高音量可能会导致永久性听力损失。
4. 请在温度5℃~35℃范围内使用及存放设备及配件, 当环境温度过高时或过低时, 可能会引起设备故障。
5. 请勿将设备及配件放置在通风、阴凉、无阳光直射的地方。
6. 请将设备及配件放置在儿童触碰不到的地方, 儿童可能在无意中损坏本设备及其配件, 或吞下小零件导致窒息或其他危险。
7. 本设备并非玩具, 儿童应在成人监护下使用设备。

## OPENFREE 使用說明書

280 mm

### 觸控功能 (自定义的触控可以在APP中设置)

功能	左耳塞(L)	右耳塞(R)
上一曲	***	/
下一曲	/	***
播放/暂停	**	**
接听	*	*
挂断	*	*
音量减	*	/
音量加	/	*
语音助手	---	---
游戏模式	*****	*****


### 安全信息

1. 在禁止使用无线设备的场所, 请遵守该场所的规定。
2. 在使用本设备时, 请与植入式医疗设备 (如起搏器等) 保持至少15厘米的距离。
3. 请设置合适的音量大小, 避免损伤听力。
4. 请在5℃~35℃范围内使用及存放设备及配件, 避免过高或过低的环境温度可能引起设备故障。
5. 将设备及配件保存在通风、阴凉、无阳光直射的地方, 如汽车仪表盘上方、窗台等。
6. 本设备并非玩具, 儿童应在成人监护下使用, 将设备及配件保存在儿童接触不到的地方, 避免意外损毁。
7. 请勿在驾驶、操作机器或从事其他需要集中注意力的工作时使用。
8. 请勿在雷暴天气下使用设备, 避免设备受到强雷击或电气危险。
9. 切勿将设备靠近热源或裸露的火源, 避免设备受到强烈的衝擊或高温。
10. 切勿将设备靠近强磁场或强磁性设备, 使用乾燥的软布擦拭即可, 勿使用加热工具对设备进行乾燥处理, 如吹风、微波炉等。
11. 勿擅自拆卸或改装设备。
12. 使用未经认可或不兼容的充电适配器, 可能导致故障、起火、爆炸等危险。

408 mm


### 藍牙配對

1. 首次打开充电盒, 取出耳机, 自动进入配对状态。
2. 在使用本设备后设置, 首次开机耳机将进入配对状态。
3. 打开与耳机配对设备的蓝牙开关, 接受耳机名称并配对连接。



### 恢复出厂设置

1. 耳机放入充电盒中, 保持充电盒盖闭合状态, 长按充电盒盖键5s, 充电盒白光交替闪烁3次, 即恢复耳机出厂设置。
2. 恢复出厂设置完成后, 关闭充电盒盖, 重新打开进入配对模式。



### 售后服务说明

以下若有与国家政策不符或遗漏之处, 以国家政策为准。


1. 自购买之日起日内, 因产品质量问题可退货; 30日内, 因质量问题可换货; 12个月内, 因产品本身原因造成的性能故障, 消费者可享受保修服务。
2. 在三包有效期内, 用户必须出具购机发票和有效三包凭证才能享受包退、包换、包修的权利。
3. 本公司产品若出现其他质保 (如包装袋等), 不承担三包责任。
4. 所有在保修期内被维修或更换下来的零件、部件和附件等归本公司所有。

在用户使用过程中, 符合下列情况之一者不在保修范围内:

1. 超过三年有效期。
2. 无三包凭证及购机发票, 且无法证明该产品在三包有效期内。
3. 未按产品说明书要求使用、维护、保养而造成损坏。
4. 在使用过程中产品被擅自拆卸、改装, 人为原因造成的故障。
5. 由于撞车、跌落、摔打、挤压等原因造成的损坏。
6. 由于不可抗因素 (如火灾、地震、雷击等) 而造成故障或损坏。
7. 未按说明书或操作手册中的要求使用而造成损坏的。
8. 产品自然磨损 (如外壳)。

### 藍牙配對

1. 首次打開充電盒, 取出耳機即可自動進入配對狀態。
2. 打開與耳機配對設備的藍牙開關, 搜索耳機名稱[ROSE OpenFree]進行配對連接。



### 充电

1. 将耳机放入充电盒内, 充电盒充电。
2. 使用USB-C充电线为充电盒充电。



\* 白色指示灯 >70% ● 绿色指示灯 30%-70% ● 橙色指示灯 <30% ● 橙色指示灯闪烁 <10%。

\* 充电指示: ○白色灯亮后熄灭。●绿色灯亮30%以下。○橙色灯亮30%以上。●橙色灯快闪1s为周期10%以下。

\* 充电完成: 白色灯熄灭。

### 功能使用

- 可以使用手机下载“ROSELINK”APP, 自定义耳机的操作功能;

- 在应用商店搜索“ROSELINK”APP或者扫描左侧二维码下载安装。

### 产品中有害物质的名称及含量

部件名称	有害物质或元素					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBB)	多溴二苯醚(PBDE)
金属零件	X	O	O	O	O	O
电池	O	O	O	O	O	O
塑料部件	O	O	O	O	O	O
线缆	X	O	O	O	O	O
电路板组件	X	O	O	O	O	O

本表依据EU 2015/863指令的范围制定。

O: 表示该有害物质在该部件中的含量在GB/T 26572规定的限量要求以下。

X: 表示该有害物质的含量在该部件的某一物质材料中的含量超出GB/T 26572规定的限量要求, 且目前业界没有成熟替代方案, 负责方应提供替代方案。

GB/T 26572: 电子电气产品的有害物质限制使用标准, 2016年版。

本产品的“电子电气产品有害物质限制使用标准”为10年, 其标识如左图所示。

本产品及其组件上的使用期限标识可能有所不同, 组件上的使用期限标识优先于产品上任何与之相冲突的或不同的环保使用期限标识。

本产品及其组件上的使用期限标识可能有所不同, 组件上的使用期限标识优先于产品上任何与之相冲突的或不同的环保使用期限标识。

本产品及其组件上的使用期限标识可能有所不同, 组件上的使用期限标识优先于产品上任何与之相冲突的或不同的环保使用期限标识。

本