



MS1	MS2	MS3	Resolution
ON	ON	ON	Full Step
OFF	ON	ON	1/2 Step
ON	OFF	ON	1/4 Step
OFF	OFF	ON	1/8 Step
OFF	OFF	OFF	1/16 Step

Motor microstep switches: These DIP-Switches are **optional** and you are free to not use them. By default the BigEasyDrivers runs with 1/16 step. They are only required if you want 1/8, 1/4, 1/2 or full steps for your system.

