



5V GND

Arduino-PCB

Base-PCB

GND

5V

12V

Capacitor Diode

Resistência

Vin-

12 V

GND

INA126

MAX3232

8

-5

Vs+

7

Vin+

-6

Vo

C1 C3 C2 C4

TxD RxD

Tx' Ard

Rx' Ard

v2

Rx RS-232 Tx RS-232

Jumper