Rocker Switch Quick Reference

FLA COE
FLB COE
FLD Conventional
Business Class
FLC 112 Conventional
Century Class Conventional

> Argosy COE Cargo > Columbie Eagle Metropolitan Walk-in Van Recreational Vehicle Shuttle Bus School Bus Condor Coronado Business Class M2 Freightliner Parts Technical Bulletin

Description of Revisions: This bulletin replaces the version dated March 2005. Part numbers A06-30769-133 through A06-30769-144 have been added.

Rocker Switch Quick Reference								
Switch Description	Switch Part Number	Switch Type	Graphic	Function				
				Pos. A Lower	Pos. B Center	Pos. C Upper	Mod	
Marker Intrpt.	A06-30769-000	Paddle	Marker Int.	None	On	Off (Mom)	304	
Eng. Rtrdr, Lo/ Off/Hi	A06-30769-001	Paddle	Eng. Brk.	Lo	Off	Hi	129	
Mirror Heat	A06-30769-002	Rocker	Mirr. Heat	None	Off	. On	744	
Utility Lamp	A06-30769-003	Rocker	Utly. Lamp	None	Off	On	312	
Road Lamp	A06-30769-004	Rocker	Road Lamp	None	Off	Оп	314	
Footwell Lamp	A06-30769-005	Rocker	Foot Well	None	Off	On	324	
Rear Fog Lamp	A06-30769-006	Rocker	Rear Fog Lp.	None	Off	On	315	
Hdwy. Adj.	A06-30769-007	Paddle	Hdwy+Hdwy-	On (Mom)	Off	On (Mom)	736	
Drv. Side Pwr. Wind.	A06-30769-008	Rocker	Exp.	On (Mom)	Off	On (Mom)	656	
Eng. Ck/Diagn, Req.	A06-30769-009	Rocker	Chk, Eng.	None	Off	On (Mom)	283	
Hdlp/Marker	A06-30769-010	Paddle	Hdip. Mrkr.	On	Off	On	304	
On/Off, Cruise	A06-30769-011	Rocker	Spd. Cntl	On	Off	None	149	
Set/Res, Cruise	A06-30769-012	Paddle	Rsm/Acc,Set/Cst	On (Mom)	Off	On(Mom)	149	
Dome	A06-30769-013	Rocker	Dome	None	Off	On (Mom)	324	
Optional (Blank)	A06-30769-014	Rocker	Blank	None	Off	On	329	
Shutdown Override	A06-30769-015	Rocker	Shdn. Ovrd.	None	Off	On (Mom)	152	
Engine Fan	A06-30769 - 016	Rocker	Eng. Fan	None	On	Off	276	
Aux Blwr. Hi/lo	A06-30769-017	Rocker	Aux Hi/Aux Lo	Lo	Off	Hi	723	
Bunk Heater	A06-30769-018	Rocker	Bunk On/Bunk Off	None	Off	On	703	
Hdwy Alert	A06-30769-019	Rocker	Hdwy Alert	On (Mom)	On	Off (Mom)	736	
ATC Norm/Spin	A06-30769-020	Rocker	Nrm/Spin ATC	None	Off	On (Mom)	330	
Fuel Heater	A06-30769-021	Rocker	Fuel Heat	None	Off	On	220	
Ecas Load Transfer	A06-30769-022	Rocker	ECAS Xref	On (Mom)	Off	On	87D	
Spot Lamp Master	A06-30769-023	Rocker	Spot Lamp	None	Off	On	316	
Advertising Light	A06-30769-024	Rocker	Adv. Lamp	None	Off	On	319	
Trailer Aux	A06-30769-025	Rocker	Trlr. Aux	None	Off	On	294	
Door Lock	A06-30769-026	Rocker	Dr. Lock	On (Mom)	Off	On (Mom)	655	

Freightliner Parts Technical Bulletin FLA COE FLB COE FLD Conventional Business Class FLC 112 Conventional Century Class Conventional > Argosy COE Cargo > Columbia Eagle Metropolitan Walk-in Van

Recreational Vehicle Shuttle Bus School Bus Condor > Coronado Business Class M2

Rocker Switch Quick Reference								
Switch Description	Switch Part Number	Switch Type	Graphic	Function				
				Pos. A Lower	Pos. B Center	Pos. C Upper	Mod	
Pass. Side Pwr Wind	A06-30769-027	Rocker	Up/Down	On (Mom)	Off	On (Mom)	656	
Volume Adj.	A06-30769-028	Rocker	Hdwy Vol+/-	On (Mom)	Off	On (Mom)	736	
Beacon	A06-30769-029	Rocker	Bcn Lamp	None	On	Off	327	
Incr/Decr	A06-30769-030	Rocker	Incr/Decr	On (Mom)	Off	On (Mom)	283	
Engine Brake	A06-30769-031	Rocker	Eng. Brk.	None	Off	On	129	
Bunk Control	A06-30769-032	Rocker	Hi/Bunk/Lo	Off	On	On	723	
Qcom Msg Buzzer	A06-30769-033	Rocker	Off/Msg. Bzr	None	On	On	786	
Rear Dome	A06-30769-034	Rocker	Dome	None	Off	On	325	
Trip Information	A06-30769-035	Rocker	Trip Info	None	Off	On (Mom)	329	
LH Step	A06-30769-036	Rocker	Off/LH Step	None	On	Off (Mom)	67E	
RH Step	A06-30769-037	Rocker	Off/RH Step	None	On	Off (Mom)	67E	
Axle Shift	A06-30769-062	Rocker	Axle Shift	Off	None	On	876	
Exhaust Brake	A06-30769-064	Rocker	Exhst Brk	Off	None	On	129	
Set/Resume	A06-30769-065	Rocker	Rsm/Acc, Set/Cst	On (Mom)	Off	On (Mom)	149	
Speed Control	A06-30769-066	Rocker	Spd Cntl	Off	None	On	149	
Check Engine	A06-30769-067	Rocker	Chk. Eng.	Off	None	On (Mom)	283	
Mirror Heat	A06-30769-069	Rocker	Mirr. Heat	Off	None	On	744	
ATC Norm/Spin	A06-30769-070	Rocker	Nrm/Spin ATC	None	Off	On	330	
Eng Brk. Lo/Med/ Hi	A06-30769-071	Paddle	Hi/Lo Eng Brk	On	On	On	129	
Eng Brk. On/Off	A06-30769-072	Paddle	Eng Brk	None	Off	On	129	
Cab Tilt	A06-30769-073	Rocker	Cab Tilt	On	On	On	670	
Mirror Adjust	A06-30769-074	Rocker	Mirr Adj	On (Mom)	Off	On (Mom)	744	
Alt Flasher	A06-30769-075	Rocker	Alt Fishr	Note	Off	On	312	
Optional (Blank)	A06-30769-076	Rocker	Blank	Off	None	On (Mom)	329	
Trailer Aux	A06-30769-077	Rocker	Trlr. Aux	Off	None	On (Mom)	329	
Engine Brake	A06-30769-078	Paddle	Eng Brk	None	Off	On	129	
Eng Brake Hi-Lo	A06-30769-079	Paddle	HiLo Eng Brk	On	Off	On	129	
DRL Ovrd FLX/ FLH	A06-30769-080	Rocker	DRL Ovrd	Off	Noлe	On (Mom)	311	
Backup Alarm	A06-30769-081	Rocker	Bkup Alrm	Off	On	On (Mom)	156	
Axle Lift	A06-30769-082	Rocker	Axle Lift	None	Off	On	296	
Dome	A06-30769-083	Rocker	Dome	None	On	On	325	
Dome	A06-30769-084	Rocker	Dome	None	On	On	324	

Rocker Switch Quick Reference

FLA COE
FLB COE
FLD Conventional
Business Class
FLC 112 Conventional
Century Class Conventional

> Argosy COE Cargo > Columbia Eagle Metropolitan Walk-in Van

Recreational Vehicle Shuttle Bus School Bus Condor > Coronado Business Class M2 Freightliner Parts Technical Bulletin

Rocker Switch Quick Reference								
Switch Description	Switch Part Number	Switch Type			Function			
			Graphic	Pos. A Lower	Pos. B Center	Pos. C Upper	Mod	
Dome	A06-30769-085	Rocker	Dome	None	On	On	325	
RPM Control	A06-30769-086	Rocker	RPM Cntl	None	On	On	148	
RPM+/RPM-	A06-30769-087	Rocker	Rmp+ RPM-	On (Mom)	Off	On (Mom)	148	
Lane Alert	A06-30769-088	Rocker	Lane Alert	None	Off	On (Mom)	73B	
Engine Brake Hi-Lo	A06-30769-090	Paddle	HiLo Eng Brk	On	Off	On	129	
Snow Plow	A06-30769-091	Rocker	Plow Lamp	None	Off	On	312	
Fog Lamp	A06-30769-092	Rocker	Fog Lamp	None	Off	On	315	
Engine Fan	A06-30769-093	Rocker	Eng Fan	None	Off	On	276	
Data Logger	A06-30769-094	Rocker	Save Event	None	Off	On (Mom)	813	
HVAC Override (Bunk)	A06-30769-095	Rocker	Bunk Ovrd	On (Mom)	Off	On (Mom)	703	
PTO	A06-30769-096	Rocker	PTO	None	Off	On	360	
DRL Override	A06-30769-097	Rocker	DRL Ovrd	Off	None	On (Mom)	311	
Trans Retarder	A06-30769-098	Paddle	Trans Rtdr	None	Off	On	129	
Data Logger	A06-30769-100	Rocker	Save Event	None	Off	On (Mom)	813	
Shift Tower	A06-30769-101	Paddle	Open-Close	Off	None	On	329	
HVAC Override (Bunk)	A06-30769-102	Rocker	Bunk Ovrd	On (Mom)	Off	On (Mom)	703	
O/D Override	A06-30769-103	Rocker	Off O/D	None	Off	On	34B	
ABS Check	A06-30769-104	Rocker	ABS Chk	None	On	On (Mom)	330	
Hdlp/Marker	A06-30769-105	Rocker	Hdlt	Off	On	On	304	
B c n-Cargo	A06-30769-106	Rocker	Bon Cargo	On	Off	On	329	
Sander Bcn	A06-30769-107	Rocker	Sndr Bon	None	Off	On	329	
Sander Lamp	A06-30769-108	Rocker	Sndr Lamp	None	Off	On	329	
Tailgate Latch	A06-30769-109	Rocker	T.Gate Latch	None	Off	On	329	
Trailer Latch	A06-30769-110	Rocker	Trlr Latch	None	Off	On	329	
Spot Lamp	A06-30769-111	Rocker	Spot Lamp	None	Off	On	329	
Front Strobe	A06-30769-112	Rocker	Front Strb	None	Off	On	329	
Rear Strobe	A06-30769-113	Rocker	Rear Strb	None	Off	On	329	
Salt Light	A06-30769-114	Rocker	Salt Light	None	Off	On	329	
Pump	A06-30769-115	Rocker	Pump	None	Off	On	329	
Cntr Bal	A06-30769-116	Rocker	Cntr Bal	None	Off	On	329	
Blank	A06-30769-117	Rocker	Blank	None	Off	On	329	
Mirror Adjust	A06-30769-118	Rocker	Mirr Adj	On (Mom)	Off	On (Mom)	744	

Freightliner Parts Technical Bulletin FLA COE
FLB COE
FLD Conventional
Business Class
FLC 112 Conventional
Century Class Conventional

> Argosy COE Cargo > Columbia Eagle Metropolitan Walk-In Van Recreational Vehicle Shuttle Bus School Bus Condor > Coronado Business Class M2

		Rocker	Switch Quick Ref	erence			
Switch Description	Switch Part Number	Switch Type	Graphic	Function			
				Pos. A Lower	Pos. B Center	Pos. C Upper	Mod
Exhaust Brake	A06-30769-119	Rocker	Exhst Brk	None	Off	On	129
Axle Lift 1	A06-30769-120	Rocker	Axle Lift 1	Non e	Off	On	87F
Axle Lift 2	A06-30769-121	Rocker	Axle Lift 2	None	Off	On	87F
Axle Lift 3	A06-30769-122	Rocker	Axle Lift 3	None	Off	On	87F
Lo Range	A06-30769-123	Rocker	Lo Range	None	On	On	-
Axle Engage	A06-30769-124	Rocker	Locked Frt Axle	None	On	On	
Axle Shift	A06-30769-125	Rocker	Axle Shift	None	On	On	_
Exhaust Brake	A06-30769-126	Rocker	Exh Brk	Off	None	On	_
Min-Max	A06-30769-127	Rocker	Max Min	On	On	On	
Aux Heat Engine	A06-30769-128	Rocker	Aux Heat	None	Off	On	142
Off/Start Engine	A06-30769-129	Rocker	Start Off	On (Mom)	Off	On (Mom)	156
Work Light	A06-30769-130	Rocker	Work Light	None	Off	On	315
Blank	A06-30769-131	Rocker	Blank	On	Off	On	329
Exhaust Brake	A06-30769-132	Guarded Paddle	Eng Brk	On	Off	On	129
AWD	A06-30769-133	Rocker	Locked/AWD	On	On	None	87B
Diff. Lock	A06-30769-134	Rocker	Locked/Diff Locked	On	Off	None	87B
HI-LO Range	A06-30769-135	Rocker	Hi-Lo Range	On	Off	None	87B
H-N-L Range	A06-30769-136	Rocker	LO, N-TRL HIGH RANGE	On	On	On	87B
Tag Dump	A06-30769-137	Paddle	Tag Dump Auto Off	On	On	Off	87F
Engine Air	A06-30769-138	Rocker	Eng. Air	On	Off	None	188
Batt. Disc. Spw. X	A06-30769-139	Rocker	Battery Symbol	On (Mom)	None	Off	293
Aux Engine Heat	A06-30769-140	Rocker	Aux Heat	On	Off	None	293
Inter. Axle	A06-30769-142	Rocker	Locked/Inter. Axle	On	Off	None	142
DPF Regeneration	A06-30769-143	Rocker	Regen	On (Mom)	None	Lock Off	28F
Hazard Warning	A06-30769-144	Rocker	Haz Symbol	On	None	Off	-

Table 1, Rocker Switch Quick Reference

NOTE: Switch Hole Plug, ETN/17-19544-2