Volvo Pre-Fix: VIPPart Number

Mack Pre-Fix: 11-VIP Part number

VIP Part Number **Hendrickson** # **Valley Chrome # OE Brand Description** Weight G05B0010050000 HC-0010-06 BUMPER-PB 378 & 379 0804SQ Peterbilt 86 **CONV** G05B0010140000 HC-0010-02 BUMPER-PB 378 & 379 804 Peterbilt 76 **CONV** E01B0210050000 **BUMPER-KW W900L** 0515SQ FE-0210-06 Kenworth 86 E01B0010050000 **BUMPER-KW W900L** 0522SO FE-0010-06 Kenworth 86 G05C0010050000 Peterbilt BUMPER-PB 378 & 379 7804SQ (N/A)115 CONV BUMPER-PB 378 & 379 G05B2010140000 805 HC-2010-02 Peterbilt 76 **CONV** G05C0010140000 7804 (N/A)BUMPER-PB 378 & 379 Peterbilt 103 **CONV** B04B0010140000 Freightliner **BUMPER-FRGHTLNR** 76 0209NL CB-0010-02 COE CONV BUMPER-KW W900L E01B001005M500 0574SO FE-0010-06-009 Kenworth 86 **CONVENTIO BUMPER-KW W900L** E01B2210050000 0514SQ FE-2210-06 Kenworth 86 B04B0010050000 0209NLSQ CB-0010-06 Freightliner **BUMPER-FRGHTLNR** 86 **CONV 92"** D08B0210050000 0415NLSQ ER-0210-06 International **BUMPER-**86 INTERNATIONAL 9900 E15C0011630000 75X0NL (N/A) Kenworth **BUMPER-T800 CONV** 101 SET BACK D08B2210140000 415 ER-2210-02 **BUMPER-INTNTNL** 76 International 9900I W/TO G05B0010250000 0807SQ HC-0010-11 Peterbilt BUMPER-PB 378 & 379 93 **CONV** E05B0210050000 **BUMPER-KENWORTH** 0502SQ FE-0210-06 Kenworth 86 W900B (N/A)E07C0011630000 7530 Kenworth **BUMPER-KENWORTH** 101 T800 E15C2011630000 75X0 (N/A)Kenworth **BUMPER-T800 CONV** 101 SET BACK G05B2010050000 0805SQ HC-2010-06 Peterbilt BUMPER-PB 378 & 379 86 **CONV** G05B001005L600 HC-0010-06-R15 Peterbilt BUMPER-PB 378 & 379 86 0884SQ **CONV** E05C0210050000 7502SQ (N/A)Kenworth **BUMPER-KENWORTH** 115 W900B G05C2010140000 Peterbilt BUMPER-PB 378 & 379 103 7805 (N/A)CONV BUMPER-T800 CONV E15C00116A0000 75X2NL (N/A)Kenworth 85 SET BACK E07C20116A0000 **BUMPER-KENWORTH** 7543 (N/A)Kenworth 85 T800 CONV

Volvo Pre-Fix: VIPPart Number

Mack Pre-Fix: 11-VIP Part number

VIP Part Number **Hendrickson** # **Valley Chrome # OE Brand Description** Weight G05B0010120000 0804IN12 HC-0010-01 BUMPER-PB 378 & 379 Peterbilt 65 **CONV** E01B001005L600 **BUMPER-KW W900S** 0584SQ FE-0010-06-R15 Kenworth 86 **CONVENTIO BUMPER-KW W900L** E01C0210140000 7515 (N/A)Kenworth 103 E01C0210050000 **BUMPER-KW W900L** 7515SO (N/A)Kenworth 115 B15B0210140000 Freightliner **BUMPER-**216 N/A 76 **FREIGHTLINER** G05B001005M500 HC-0010-06-009 Peterbilt BUMPER-PB 378 & 379 86 0874SQ **CONV** E07C2011630000 **BUMPER-KW T800** 7531 (N/A)Kenworth 101 CONVENTION Freightliner B15B0210050000 0216SQ18 N/A **BUMPER-**86 **FREIGHTLINER** BUMPER-KW T800 E07C00116A0000 7540 (N/A)Kenworth 85 **CONVENTION** BUMPER-KENWORTH E05B2210050000 0503SQ FE-2210-06 Kenworth 86 W900B E07C00916A0000 **BUMPER-KW T800** 7542 (N/A)Kenworth 85 CONVENTION E01B0010250000 FE-0010-11 **BUMPER-KW W900L** 0522SQ18 Kenworth 93 F15C0000610000 7643 GQ-0000-27 Mack BUMPER-MACK RD 688. 78 690 D08B2210050000 ER-2210-06 BUMPER-INTRNTNL 86 0415SQ International 9900I 18" BUMPER-FORD A01B0010140000 BA-0010-02 76 100 Ford. LN,LT,LNL,LTL E01C0010050000 **BUMPER-KENWORTH** 7522SQ (N/A)Kenworth 115 W900L BUMPER-PB 378/379 G05B0010260000 0809SQ20 HC-0010-51 Peterbilt 107 CONVN/' **BUMPER-KENWORTH** E07B0011630000 530 FG-0101-25 Kenworth 75 T800 CONV E15C20116A0000 75X2 (N/A)Kenworth **BUMPER-T800 CONV** 85 SET BACK E05C0010050000 **BUMPER-KENWORTH** 115 7512SQ (N/A)Kenworth W900B E05B0010050000 0512SQ FE-0010-06 Kenworth **BUMPER-KENWORTH** 86 W900B E05C0210140000 **BUMPER-KENWORTH** 7525 (N/A)Kenworth 103 W900B **BUMPER-KW W900L** E01C2210050000 7514SO (N/A)Kenworth 115 G05B0090140000 HC-0090-02 BUMPER-PB 378 & 379 894 Peterbilt 76 CONVE G05B001005M200 0844SQ HC-0010-06-004 Peterbilt BUMPER-PB 378/379 86

Volvo Pre-Fix: VIPPart Number

Mack Pre-Fix: 11-VIP Part number

**VIP Part Number** Hendrickson # **Valley Chrome # OE Brand Description** Weight CONV 87 G05B001025L600 0887SQ HC-0010- R15 Peterbilt BUMPER-PB 378 & 379 93 CONVE G05B0010060000 0804SQ20 HC-0010-41 Peterbilt BUMPER-PB 378 & 379 96 CONVE E07B00116A0000 540 FG-0101-26 Kenworth **BUMPER-KW T800** 78 **CONVENTION** BUMPER-PB 352 COE G03C0010140000 7800 (N/A)Peterbilt 103 359 CON BUMPER-KENWORTH 78 E07B20116A0000 543 FG-2101-26 Kenworth T800 CONV **BUMPER-KW W900L** E01C2210140000 7514 Kenworth 103 (N/A)E05B0210140000 525 FE-0210-02 Kenworth BUMPER-KENWORTH 76 W900B G03B0010050000 0800SQ HA-0010-06 **BUMPER-PB 352 COE** 86 Peterbilt 359 CON BUMPER-BLANK XXXB0000050000 0700SQ 00-0000-06 86 E08B0010120000 0526IN12 **FJ**-0010-01 **BUMPER-KENWORTH** 65 Kenworth W900S CO A01B0010050000 0100SQ BA-0010-06 Ford **BUMPER-FORD** 86 LN,LT,LNL,LTL BUMPER-FL CLASSIC B15B2210050000 0213SQ N/A Freightliner 86 E07C0091630000 7534 (N/A)Kenworth BUMPER - KW T800 101 E07C20916A0000 Kenworth **BUMPER-KW T800** 85 7544 (N/A)**CONVENTION** E11C00916A0000 75M1 BUMPER-KENWORTH 85 Kenworth (N/A)HF-0010-02 G06B0010140000 813 Peterbilt BUMPER-PB 352 & 359 76 **CONV** FE-0010-51 **BUMPER-KW W900L** 107 E01B0010260000 0521SQ Kenworth **CONV BUMPER-T800 CONV** E15C00916A0000 75X3NL (N/A)Kenworth 85 SET BACK G05B0000140000 HC-0000-02 BUMPER-PB 378 & 379 76 0804NT Peterbilt **CONV** G05B0010270000 0809SO22 HC-0010-52 Peterbilt **BUMPER-PB 378/379** 111 CONV/87 **BUMPER-KENWORTH** E01B001005M100 0567SQ FE-0010-06-002 Kenworth 86 W900L **BUMPER-T800 CONV** E15C20916A0000 75X3 (N/A)Kenworth 85 SET BACK D02B2010140000 EI-2010-02 **BUMPER-INTRNTNL** 0416R International 76 9670 BUMPER-INTRNTNL D02B2210140000 411 EI-2210-02 International 76 9670 0216SQ20 B15B0210260000 N/AFreightliner **BUMPER-FL CLASSIC** 107

Volvo Pre-Fix: VIPPart Number

Mack Pre-Fix: 11-VIP Part number

**VIP Part Number Hendrickson** # **Valley Chrome # OE Brand Description** Weight J02B2010050000 0907SQ IC-2010-06 **BUMPER-WESTERN** Western Star 86 **STAR** BUMPER-PETERBILT G05C0090120000 7823IN12 (N/A)Peterbilt 88 357/379 G05B0010150000 0804IN18 BUMPER-PB 378 & 379 HC-0010-03 Peterbilt 92 **CONV** G05B001025M500 0877SQ HC-0010-009 Peterbilt BUMPER-PB 378 & 379 93 **CONV** HF-0010-01 G06B0010120000 0813IN12 Peterbilt BUMPER-PB 357/359 65 **LOGGER** G06B0090140000 896 HF-0090-02 Peterbilt BUMPER-PB 357 & 379 76 LOGGE E01B0210150000 0515IN18 FE-0210-03 Kenworth **BUMPER-KW W900L** 92 **CONVENTIO** E01S0210050000 0515STQ FE-0210-06 (SS) **BUMPER-KW W900L** 92 Kenworth SST G05C2010050000 7805SO (N/A)Peterbilt BUMPER-PB 378 & 379 115 CONV E15C20126A0000 75X4 **BUMPER-T800 CONV** 85 (N/A)Kenworth **SET BACK** G05B001005M300 HC-0010-06-006 Peterbilt BUMPER-PB 378 & 379 86 0864SQ CONV E01B2010050000 **BUMPER-KW W900L** 0520SO FE-2010-06 Kenworth 86 **CONV** E07B00916A0000 542 FG-0091-26 Kenworth **BUMPER-KENWORTH** 78 T800 CONV E07B2011630000 531 FG-2101-25 BUMPER-KW T800 75 Kenworth **CONVENTION** E07B2210630000 FG-2210-25 **BUMPER-KENWORTH** 541 Kenworth 75 T800 J01B0000050000 0910SQ IB-0000-06 Western Star **BUMPER-WESTERN** 86 STAR CONVE G05B0000050000 0804NTSQ HC-0000-06 Peterbilt BUMPER-PB 378 & 379 86 **CONV BUMPER-PB 378/379** G05B001005M100 0824SO HC-0010-06-002 Peterbilt 86 87NEWER G03C0010050000 7800SO (N/A)Peterbilt **BUMPER-PB 352 COE** 115 359 CON BUMPER-KW W900L E01B0000050000 0522NTSQ FE-0000-06 Kenworth 86 CONV E01B0000250000 0551SO18 FE-0000-11 Kenworth **BUMPER-W900L CONV** 93 '82 & N E01B0000060000 0549SQ20 FE-0000-41 **BUMPER-KENWORTH** 96 Kenworth W900L BUMPER-KW W900L E01B0000270000 0551SQ22 FE-0000-52 Kenworth 111

Mack Pre-Fix: 11-VIP Part number Volvo Pre-Fix: VIPPart Number OE Brand **VIP Part Number** Hendrickson # **Valley Chrome # Description** Weight **CONVENTIO** E01B001005M400 0594SQ FE-0010-06-008 Kenworth **BUMPER-KW W900L** 86 CONV '82 BUMPER-KW W900L 93 E01B001025L600 0584SQ18 FE-0010- R15 Kenworth E01B0210250000 BUMPER-KW 900L 93 0554SQ18 FE-0210-11 Kenworth D05B0010140000 0401NL EF-0010-02 International **BUMPER-INTRNTNL** 76 2200 D08B0000050000 0424SO ER-0000-06 International **BUMPER-**86 INTERNATIONAL 9900 D08B0210140000 0415NL ER-0210-02 International BUMPER-76 **INTERNATIONAL 9900** BUMPER-FORD A01B4010050000 0108SQ BA-4010-06 Ford 86 LN,LT,LTN,LTL B04B001005M500 0262SQ CB-0010-06-009 Freightliner **BUMPER-FRGHTLNR** 86 COE B04B0100140000 CB-0100-02 Freightliner **BUMPER-FRGHTLNR** 76 206 **COE CONV** G05B0000260000 0810SQ20 BUMPER-PB 378 & 379 107 HC-0000-51 Peterbilt CONV G05B001026L600 0887SQ20 HC-0010-51-R15 Peterbilt BUMPER-PB 378 & 379 107 **CONV** G05C0010120000 7804IN12 (N/A) Peterbilt BUMPER-PB 378 & 379 88 CONV G05C0010250000 BUMPER-PB 378 & 379 124 7807SQ (N/A)Peterbilt **CONV** (N/A) G05C0090140000 7894 Peterbilt -BUMPER-PETERBILT 103 E15C2091630000 BUMPER-T800 CONV 101 75X1 (N/A)Kenworth SET BACK J02B0010140000 908 IC-0010-02 Western Star **BUMPER-WESTERN** 76 STAR CRNR 0808SQ HA-0010-11 BUMPER-PB 352 COE G03B0010250000 Peterbilt 93 359 CON G05B0000250000 0807NTSQ HC-0000-11 Peterbilt BUMPER-PB 378 & 379 93 **CONV** G05B001025M200 0844SQ18 HC-0010-004 Peterbilt BUMPER-PB 378 & 379 93 G05B0090120000 0894IN12 HC-0090-01 **BUMPER-PETERBILT** Peterbilt 65 378/379 BUMPER-PB 378 & 379 G05B009006L600 N/A HC-0090-41-R15 Peterbilt 96 **CONV** G07B0010050000 0806SQ HK-0010-06 Peterbilt BUMPER-PB 362 COE 86 G05C001005M500 7874SQ (N/A)Peterbilt **BUMPER-STL CHR 7 PB** 115 TSO 1

E01B221005L500

05L1SO

FE-2210-06-R10

Kenworth

**BUMPER-KENWORTH** 

W900L

86

Mack Pre-Fix: 11-VIP Part number  VIP Bumper Cross Reference  Volvo Pre-Fix: VIPPart Number							
VIP Part Number	Hendrickson #	Valley Chrome #	OE Brand	<u>Description</u>	Weight		
E01C0010250000	7522SQ18	(N/A)	Kenworth	BUMPER-KENWORTH W900L	124		
E01C001025M500	7574SQ18	(N/A)	Kenworth	BUMPER-STL CHR 7 KW BOX 1	124		
E05C2210050000	7503SQ	(N/A)	Kenworth	BUMPER-KENWORTH W900B	115		
E07C2091630000	7533	(N/A)	Kenworth	BUMPER - KW T800	101		
G05B0000270000	0810SQ22	HC-0000-52	Peterbilt	BUMPER-PB 378 & 379 CONVE	111		
G06B2090120000	0897IN12	HF-2090-01	Peterbilt	BUMPER-PETERBILT 357/379	65		
G05C0010260000	7809SQ20	(N/A)	Peterbilt	BUMPER-PB 378 & 379 CONVE	134		
G06C2010140000	7837	(N/A)	Peterbilt	BUMPER-PB 357 & 359 CONV	103		
E01B0210060000	0515SQ20	FE-0210-41	Kenworth	BUMPER-KW W900L CONVENTIO	96		
E07B20106A0000	536	FG-2100-26	Kenworth	BUMPER-KENWORTH T800 CONV	78		
E07B20916A0000	544	FG-2091-26	Kenworth	BUMPER-KENWORTH T800 CONV	78		
E12C0090630000	7534NVWH	(N/A)	Kenworth	BUMPER-KENWORTH T800	101		
F07B0211140000	0605NL	GA-02 02	Mack	BUMPER-MACK R,RL,U,F,FL,F	76		
J02B0000050000	0909SQ	IC-0000-06	Western Star	BUMPER-WESTERN STAR CORNE	86		
J02B0010050000	0908SQ	IC-0010-06	Western Star	BUMPER-WESTERN STAR	86		
J02B2010140000	907	IC-2010-02	Western Star	BUMPER-WESTERN STAR CRNR	76		
G03B0000050000	0800NTSQ	HA-0000-06	Peterbilt	BUMPER-PB 352 COE 359 CON	86		
G03B0000070000	0866SQ22	HA-0000-42	Peterbilt	BUMPER-22" PB 352/359 TEX	109		
G03B001005M500	0870SQ	HA-0010-06-009	Peterbilt	BUMPER-PETERBILT 359 CONV	86		
G03B1010050000	0801SQ	HA-1010-06	Peterbilt	BUMPER-PB 352 COE 359 CON	86		
G05B001025D600	0887SQF	HC-0010- R15- B4	Peterbilt	BUMPER-PETERBILT 378 & 37	93		
G05B2010120000	0805IN12	HC-2010-01	Peterbilt	BUMPER-PB 378 & 379 CONV	65		
G05B2090120000	0895IN12	HC-2090-01	Peterbilt	BUMPER-PETERBILT 378 & 37	65		

Volvo Pre-Fix: VIPPart Number

Mack Pre-Fix: 11-VIP Part number

**VIP Part Number Hendrickson** # **Valley Chrome # OE Brand Description** Weight G06B0000120000 HF-0001-01 BUMPER-STL CHR 10 PB 0816IN12 Peterbilt 65 **TPRD** HM-0010-25 BUMPER-PB 320 LOW 75 G08B0010630000 830 Peterbilt **CAB FOR** G08D0210630000 (N/A)Peterbilt BUMPER-PETERBILT 0834B 75 320 **BUMPER-PETERBILT** G03S2010140000 0800RSSS HA-2010-02 (SS) Peterbilt 83 352/359 G05S0010050000 HC-0010-06 (SS) **BUMPER-SS PETERBILT** 92 0804STQ Peterbilt 378/3 G03C0010120000 7800IN12 (N/A)Peterbilt **BUMPER-PB 359 CON** 88 352 COE G03C1010140000 7801 (N/A)Peterbilt BUMPER-PB 352 COE 103 359 CON G05C001005L600 7884SQ (N/A)Peterbilt BUMPER-PB 378 & 379 115 **CONV** G05C001025M300 7864SO18 (N/A)Peterbilt **BUMPER-PETERBILT** 124 379 G05C001025D600 **BUMPER-PETERBILT** 7887SOF (N/A)Peterbilt 124 379 G05C0010160000 7804IN20 (N/A)Peterbilt **BUMPER-PETERBILT** 129 379 G05C001026M200 Peterbilt BUMPER BOX END 2 7844SO20 (N/A)134 **OVAL HOL** BUMPER-PETERBILT G05C0090120000 7894IN12 (N/A)Peterbilt 88 378/379 BUMPER-378 & 379 (N/A) 7805NT G05C2000140000 Peterbilt 103 **CONVENTI BUMPER-KW W900L** E01B021005M200 0555SQ FE-0210-06-004 Kenworth 86 BUMPER-KW W900L E01B021005M300 0565SQ FE-0210-06-006 Kenworth 86 **CONVENTIO** E01B021005M400 **BUMPER-KW W900L** 0595SO FE-0210-06-008 Kenworth 86 **CONVENTIO** E01B2210250000 0514SQ18 FE-2210-11 Kenworth **BUMPER-KENWORTH** 93 W900L E03B0100050000 **BUMPER-KENWORTH** 0507SQ FB-0100-06 Kenworth 86 K100E E07B0010630000 539 FG-0100-25 Kenworth **BUMPER-KENWORTH** 75 T800 CONV E07B00106A0000 537 FG-0100-26 Kenworth **BUMPER-KW T800** 78 CONVENTION E01S001005M200 FE-0010-06-004 **BUMPER-KENWORTH** 92 0575STQ Kenworth W900L (SS)E01C0210150000 **BUMPER-KENWORTH** 7515IN18 (N/A)Kenworth 124 W900L

Mack Pre-Fix: 11-VIP Part number  VIP Bumper Cross Reference  Volvo Pre-Fix: VIPPart Number							
			OF Brand				
VIP Part Number	Hendrickson #	Valley Chrome #	OE Brand	<u>Description</u>	<u>Weight</u>		
E01C0210250000	7554SQ18	(N/A)	Kenworth	BUMPER-KENWORTH	124		
				W900L			
E05C001005M500	7572SQ	(N/A)	Kenworth	BUMPER-KENWORTH	115		
F05G0210120000	7500D110	(3.1/4.)	77 .1	W900B	00		
E05C0210120000	7502IN12	(N/A)	Kenworth	BUMPER-KENWORTH W900B 198	88		
E07C0010630000	7539	(N/A)	Kenworth	BUMPER-STL CHR 7 KW	101		
		,		OPEN			
E07C10116A0000	7545	(N/A)	Kenworth	BUMPER-KW T800	85		
				CONVENTION			
E07C10916A0000	7546	(N/A)	Kenworth	BUMPER-KW T800	85		
				CONVENTION			
E07C2210630000	7541	(N/A)	Kenworth	BUMPER-KW T800	101		
				CONVENTION			
E12C2090630000	7533NVWH	(N/A)	Kenworth	BUMPER-KENWORTH	101		
				T800 WIDE			
E15C0091630000	75X1NL	(N/A)	Kenworth	BUMPER-T800 CONV	101		
				SET BACK			
F07C0211140000	7605NL	GA-02 02	Mack	BUMPER-MACK	103		
				R,RL,U,F,FL,F			
F07B1211050000	0605SQ	GA-12 06	Mack	BUMPER-MACK	86		
				R,RL,U,F,FL,F			
F08B2110140000	608	GB-2110-02	Mack	BUMPER-MACK	76		
				ULTRALINER	_		
F08B0211050000	0609SQ	GB-02 06 (10 ga)	Mack	BUMPER-MACK	86		
F00P0010070000	0.0001000	TEGELT)	- PEF	SUPERLINER	0.6		
F09B0010050000	0603NGSQ	GC-0010-06 (10 ga)	Mack	BUMPER-Mack R Model	86		
F09B0211050000	0603SQ	GC-02 06 (10 ga)	Mack	BUMPER-MACK R700	86		
F10B0111140000	606	GE-01 02	Mack	BUMPER-MACK	76		
				VALUELINER			
F15E0000610000	N/A	(N/A)	Mack	BUMPER-MACK RD 688,	78		
		, ,		690			
F15B0000610000	N/A	GQ-0000-27 (10	Mack	BUMPER-MACK RD 688,	58		
		ga)		690			
J01B0000140000	910	IB-0000-02	Western Star	BUMPER-WESTERN	76		
				STAR CONV			
J01B0100140000	N/A	IB-0100-02	Western Star	BUMPER-WESTERN	76		
				STAR CONVE			
J01B0100050000	N/A	IB-0100-06	Western Star	BUMPER-WESTERN	86		
				STAR			
G03B001005L600	0880SQ	HA-0010-06-R15	Peterbilt	BUMPER-PETERBILT	86		
				359 CONV			
G05B000005L500	0846SQ	HC-0000-06-R10	Peterbilt	BUMPER-PB 378 & 379	86		
				CONVE			
<del></del>	<del></del>	<del></del>					

Volvo Pre-Fix: VIPPart Number

Mack Pre-Fix: 11-VIP Part number

**VIP Part Number Hendrickson** # **Valley Chrome # OE Brand Description** Weight G05B0000060000 0811SO20  $HC-000\overline{0-41}$ BUMPER-378 & 379 96 Peterbilt **CONV 198** BUMPER-378/379 CONV 109 G05B0000070000 0811SQ22 HC-0000-42 Peterbilt 87 & G05B000026L600 0887NTSO20 HC-0000-51-R15 Peterbilt BUMPER-20" BOXED, 10 107 **GAUG** G05B000027D500 0882FQ22 HC-0000-52-Peterbilt **BUMPER-PETERBILT** 111 378/379 R15-B3 HC-0010-006 93 G05B001025M300 0864SQ18 Peterbilt **BUMPER-PETERBILT** 379 G05B001025B200 0807SQF HC-0010- B4 Peterbilt **BUMPER-PETERBILT** 93 379 G05B0010160000 0804IN20 HC-0010-31 Peterbilt BUMPER-PB 378 & 379 96 **CONV** G05B001026M500 0879SQ20 HC-0010-51-009 Peterbilt **BUMPER-PETERBILT** 107 378 & 37 G05B201005M400 0875SO HC-010-06-008 Peterbilt **BUMPER-PETERBILT** 86 378&379 G05B2010260000 N/A HC-2010-51 BUMPER-PB/378/379 107 Peterbilt CONV 87 G06B0010050000 0813SQ HF-0010-06 Peterbilt **BUMPER-PETERBILT** 86 357/379 G06B2010140000 HF-2010-02 Peterbilt BUMPER-PB 357 & 379 837 76 **LOGGE** G07B0000050000 0806NTSO HK-0000-06 Peterbilt **BUMPER-PB 362 COE** 86 G05S001005L600 HC-0010-06-R15 BUMPER-PETERBILT 0884STQ Peterbilt-92 (SS)G03C0010250000 7808SO (N/A)**BUMPER-PETERBILT** 124 Peterbilt **359 CONV** G05C0000260000 7810SQ20 (N/A)Peterbilt BUMPER-PB W.MNT 20" 134 **BOXED** G05C001025M200 7844SO18 (N/A)Peterbilt **BUMPER-PETERBILT** 124 378/379 G05C001025L600 7887SQ (N/A)Peterbilt BUMPER-PB 378 & 379 124 **CONV** BUMPER-PETERBILT 134 G05C001026M500 7879SQ20 (N/A)Peterbilt 378 & 37 G05C001026L600 7887SQ20 (N/A)Peterbilt **BUMPER-PETERBILT** 134 378 & 37 G05C001026D600 7884FQ20 (N/A)Peterbilt **BUMPER-PB W/TOW 379** 134 20 BO N/A BUMPER-PB 378 & 379 147 G05C0010270000 (N/A)Peterbilt **CONV** G07C0010140000 7806 Peterbilt **BUMPER-PB 362 COE** 103 (N/A)G07C0110140000 7802 Peterbilt **BUMPER-PB 362 COE** 103 (N/A)

Volvo Pre-Fix: VIPPart Number

Mack Pre-Fix: 11-VIP Part number

**VIP Part Number** Hendrickson # **Valley Chrome # OE Brand Description** Weight E01B0010060000 **BUMPER-KW W900L** 96 0522SQ20 FE-0010-41 Kenworth E01B001007M500 0574SO22 FE-0010-42-009 Kenworth **BUMPER-KW W900L** 109 **CONVENTIO** E01B0010270000 0521SQ22 FE-0010-52 Kenworth **BUMPER-KENWORTH** 111 W900L **BUMPER-KENWORTH** E01B021015M200 0555IN18 FE-0210-03-004 Kenworth 92 W900L **BUMPER-KW W900L** E01B021006L600 0585SQ20 FE-0210-41-R15 Kenworth 96 E01B0210260000 0554SQ20 FE-0210-51 Kenworth **BUMPER-KW W900L** 107 1982 +E01B0210270000 Kenworth BUMPER-22"BOXED-10 0554SQ22 FE-0210-52 111 GA./FO 0508SQ Kenworth **BUMPER-KENWORTH** E03B2100050000 FB-2100-06 86 K100E E03B2110050000 0509SO FB-2110-06 **BUMPER-KENWORTH** Kenworth 86 K100E E04B0000260000 FD-0000-51 **BUMPER-KENWORTH** 0524SQ20 Kenworth 107 W900A CON E04B0010050000 **BUMPER-KENWORTH** 0510SO FD-0010-06 Kenworth 86 W900A E04B1210050000 Kenworth **BUMPER-KENWORTH** 0501SQ FD-1210-06 86 W900A E05B0010060000 0512SQ20 FE-0010-41 Kenworth **BUMPER-KW W900B** 96 **CONVENTIO** E05B0010060001 FE-0010-41-006-Kenworth **BUMPER-KW W900B** N/A 96 L01 CONV FE-0010-51 BUMPER-KW W900B E05B0010260000 0568SQ20 Kenworth 107 **CONV** E05B0210010000 **BUMPER-STL CHR 10** 0502SQ10 FE-0210-00 Kenworth 58 **KW TSQ BUMPER-KENWORTH** E07B10116A0000 545 FG-10 26 Kenworth 78 T800 CONV E08B0010060000 0526SO20 FJ-0010-41 Kenworth **BUMPER-KENWORTH** 96 W900S BUMPER-KW W900L E01S021005M200 0555STQ Kenworth FE-0210-06-004 92 (SS)E01C0010140000 7522 (N/A)Kenworth **BUMPER-KENWORTH** 103 W900L CON **BUMPER-KW W900L** E01C001005M500 7574SQ (N/A)Kenworth 115 **CONVENTIO** E01C0010260000 7521SQ **BUMPER-KENWORTH** 134 (N/A)Kenworth W900L **BUMPBER-KW W900L** E01C001026L600 7581SQ (N/A)Kenworth 134 E01C021005M100 **BUMPER-KW W900L** 7525SQ (N/A)Kenworth 115 E01C2010050000 7520SQ Kenworth **BUMPER-KW 900WL** (N/A)115

Mack Pre-Fix: 11-VIP Part number Volvo Pre-Fix: VIPPart Number **VIP Part Number Hendrickson** # **Valley Chrome # OE Brand Description** Weight **CONV** E04C0010140000 7510NG (N/A)Kenworth **BUMPER-KENWORTH** 103 W900A E04C0010050000 7510SQ Kenworth **BUMPER-KENWORTH** 115 (N/A)W900A E05C0010120000 Kenworth **BUMPER-KW W900B** 88 7512IN12 (N/A)E05C2010050000 7513SQ (N/A)Kenworth **BUMPER-KENWORTH** 115 W900B **BUMPER-KENWORTH** E07C00106A0000 7537 (N/A)Kenworth 85 T800 E07E0011630000 7530B (N/A)Kenworth **BUMPER-KENWORTH** 101 T800 E07E00916A0000 7542B Kenworth BUMPER-T800 7 GA 85 (N/A)14"TAPER N/A **BUMPER-FORD** A01C0010120000 (N/A)Ford 88 LN,LT,LNL,LTL A01C0010140000 7100 (N/A)Ford **BUMPER-FORD** 103 LN,LT,LNL,LTL N/A HC-2200-06-006 **BUMPER-PETERBILT** 86 G05B220005M300 Peterbilt 378&379 G05S0020050000 N/A BUMPER-PB 378 & 379 92 HC-0020-06 (SS) Peterbilt **CONV SS** E07C12116A0000 N/A **BUMPER-KENWORTH** (N/A)Kenworth 85

VALUE • INTEGRITY • PERFORMANCE

T800 CONV